

N00164.AR.001220
NSA CRANE
5090.3a

FINAL SAMPLING AND ANALYSIS PLAN SOIL DELINEATION AND CHARACTERIZATION
INVESTIGATION FOR SOLID WASTE MANAGEMENT UNIT 16 CAST HIGH EXPLOSIVES
FILL BUILDING 146 INCINERATOR NSA CRANE IN
8/1/2011
TETRA TECH NUS

**Final
Sampling and Analysis Plan
(Field Sampling Plan and
Quality Assurance Project Plan)**

**Soil Delineation and Characterization
Investigation
SWMU 16 - Cast High Explosive Fill/
Building 146 Incinerator**

**Naval Support Activity Crane
Crane, Indiana**



Naval Facilities Engineering Command Midwest

Contract Number N62470-08-D-1001

Contract Task Order F277

August 2011

Title and Approval Page

(UFP-QAPP Manual Section 2.1)

FINAL
SAMPLING AND ANALYSIS PLAN
(Field Sampling Plan and Quality Assurance Project Plan)
August 2011

SOIL DELINEATION AND CHARACTERIZATION INVESTIGATION

SWMU 16 – CAST HIGH EXPLOSIVE FILL/BUILDING 146 INCINERATOR
NAVAL SUPPORT ACTIVITY CRANE
CRANE, INDIANA

Prepared for:

Naval Facilities Engineering Command Midwest
201 Decatur Avenue, Building 1A
Great Lakes, Illinois 60088

Prepared by:

Tetra Tech NUS, Inc.
234 Mall Boulevard, Suite 260
King of Prussia, Pennsylvania 19406
610-491-9688

Prepared under:

Comprehensive Long-Term Environmental Action Navy
Contract No. N62470-08-D-1001
Contract Task Order F277

Review Signatures:

 8-8-11
Tom Johnston, PhD/CLEAN Quality Assurance Manager/Date
Tetra Tech NUS, Inc.

 8/8/11
for Ralph R. Basinski/Project Manager/Date
Tetra Tech NUS, Inc.

Approval Signatures:

Thomas J. Brent/Crane Project Manager/Date
NSA Crane Environmental Restoration Site Manager

Peter Ramanauskas/Remedial Project Manager/Date
United States Environmental Protection Agency

Jon Tucker/Government Chemist/Date
NAVFAC QA Review

Chino Ortiz/Laboratory Project Manager/Date
RTI Laboratories, Inc

Hak Cho/ Corrective Action Section Chief /Date
United States Environmental Protection Agency

Jose Cisneros/ USEPA Remediation and Reuse Chief/ Date
United States Environmental Protection Agency

Allen Debus/ Quality Assurance Manager/ Date
United States Environmental Protection Agency

Project-Specific SAP
Site Name/Project Name: NSA Crane SWMU 16
Site Location: Crane, Indiana

Title: SAP for SWMU 16
Revision Number: 0
Revision Date: May 2011

Title and Approval Page

(UFP-QAPP Manual Section 2.1)

DRAFT
SAMPLING AND ANALYSIS PLAN
(Field Sampling Plan and Quality Assurance Project Plan)
May 2011

SOIL DELINEATION AND CHARACTERIZATION INVESTIGATION

SWMU 16 – CAST HIGH EXPLOSIVE FILL/BUILDING 146 INCINERATOR
NAVAL SUPPORT ACTIVITY CRANE
CRANE, INDIANA

Prepared for:
Naval Facilities Engineering Command Midwest
201 Decatur Avenue, Building 1A
Great Lakes, Illinois 60088

Prepared by:
Tetra Tech NUS, Inc.
234 Mall Boulevard, Suite 260
King of Prussia, Pennsylvania 19406
610-491-9688

Prepared under:
Comprehensive Long-Term Environmental Action Navy
Contract No. N62470-08-D-1001
Contract Task Order F277

Review Signatures:

 5-25-11

Tom Johnston, PhD/CLEAN Quality Assurance Manager/Date
Tetra Tech NUS, Inc.




Ralph R. Basinski/Project Manager/Date
Tetra Tech NUS, Inc.

Approval Signatures:

Thomas J. Brent/Crane Project Manager/Date
NSA Crane Environmental Restoration Site Manager

Peter Ramanauskas/RPM/Date
United States Environmental Protection Agency



Jon Tucker/Government Chemist/Date
NAVFAC QA Review

Digitally signed by TUCKERJONATHAN.P.1239524180
Date: 2011.06.27 11:06:47 -04'00'

EXECUTIVE SUMMARY

Tetra Tech NUS, Inc. (Tetra Tech) has prepared this Sampling and Analysis Plan (SAP) that encompasses Field Sampling Plan (FSP) and Quality Assurance Project Plan (QAPP) requirements for an investigation to provide data necessary to refine estimates of contaminated soil for a remedial design at Solid Waste Management Unit (SWMU) 16 –Cast High Explosives Fill/Building 146 Incinerator at Naval Support Activity (NSA) Crane, Crane, Indiana under Contract Task Order (CTO) F277, Contract N62470-08-D-1001, Comprehensive Long-Term Environmental Action Navy (CLEAN).

The SAP contained herein was generated for and complies with applicable United States (U.S.) Department of the Navy (Navy), U. S. Environmental Protection Agency (USEPA) Region 5, and Indiana Department of Environmental Management (IDEM) requirements, regulations, guidance, and technical standards. This includes the Department of Defense (DoD), Department of Energy (DOE), and USEPA Intergovernmental Data Quality Task Force (IDQTF) environmental requirements regarding federal facilities

This SAP outlines the organization, project management, objectives, planned activities, measurement, data acquisition, assessment, oversight, and data review procedures associated with the planned investigations at SWMU 16. Protocols for sample collection, handling and storage, chain-of-custody, laboratory and field analyses, data validation, and reporting are also addressed in this SAP.

SWMU 16, which is approximately 16 acres in size, is located in the north-central portion of NSA Crane. [Figure 4-1](#) shows the general location of NSA Crane in southern Indiana, and the location of SWMU 16 within NSA Crane. Buildings and gravel parking lots cover most of the northern portion of SWMU 16 in the vicinity of Building 146, and mostly grassy and wooded areas are located south and east of Building 146 ([Figure 4-2](#)). Building 146, which has an area of approximately two-thirds acre, was an explosives fill and pressure washout facility and included a trichloroethene (TCE) degreaser, which discharged to sumps located outside of Building 146. Prior to 1978, outfalls from the sumps, which are located north, east, and west of Building 146, discharged to swales that ultimately discharged to Boggs Creek via Turkey Creek. The degreaser has been removed and the drain lines from Building 146 have been plugged. Three oil-fired, rotary kiln incinerators, with fuel storage tanks were located on the south end of Building 146. These incinerators were used for the destruction of the explosive constituent of small munitions items and components. Ashes from the incinerator were stored in a pile, which was located near the incinerators. The incinerators were closed in the early 1990s, and the waste ash piles were removed along with some obviously contaminated soil.

The Navy has determined that an interim measures action will be conducted to reduce the risks, which were identified in the RFI. Efficient implementation of the interim measure requires a more precise delineation of the extent of soils contamination. The sampling and analytical program, which is necessary to delineate the soils contamination, is described in this SAP. The results will be utilized in the SWMU 16 Interim Measures Work Plan (IMWP).

The sampling strategy for SWMU 16 is to implement soil contamination delineation sampling for the Interim Measures phase of the project at two discrete areas (TCE Contamination Area and Metals Contamination Area) in order to provide for prescriptive sampling prior to soil excavation. The IMWP will include the horizontal and vertical extent of soil excavations needed to meet media cleanup standards (MCSs). No confirmation sampling will be required.

In addition, a UST was identified after the completion of Resource Conservation and Recovery Act (RCRA) Facility Investigation (RFI) field activities. Therefore, it was not investigated during the RFI, and no information is available regarding the occurrence of releases or soil quality near the tank. Soil samples will be collected in the vicinity of the UST to determine the presence or absence of contamination associated with the tank, and if present, the extent of target analyte concentrations greater than applicable MCSs. All soils with target analyte concentrations greater than the corresponding MCS will be included for excavation in the IMWP.

Investigation procedures will comply with site-specific field Standard Operating Procedures (SOPs), included in [Appendix A](#), and laboratory analytical procedures will comply with laboratory SOPs. The field work and sampling are scheduled to begin in August 2011.

The field activities under this SAP will be conducted in accordance with the site-specific health and safety plan to be prepared for these activities.

SAP Worksheets

Page No.

| | |
|--|----|
| Title and Approval Page..... | 1 |
| EXECUTIVE SUMMARY | 3 |
| Acronyms and Abbreviations | 7 |
| 1.0 -- Project Organizational Chart | 10 |
| 2.0 -- Communication Pathways | 11 |
| 3.0 -- Project Planning Session Participants Sheet | 15 |
| 4.0 -- Conceptual Site Model | 17 |
| 4.1 SITE DESCRIPTION | 17 |
| 4.2 SUMMARY OF RFI RESULTS..... | 17 |
| 4.3 SUMMARY OF PROPOSED INTERIM MEASURES..... | 18 |
| 5.0 -- Project Quality Objectives/Systematic Planning Process Statements | 20 |
| 5.1 PROBLEM STATEMENT | 20 |
| 5.2 DATA NEEDS..... | 21 |
| 5.3 STUDY BOUNDARIES..... | 22 |
| 5.4 ANALYTIC APPROACH..... | 23 |
| 5.5 PERFORMANCE CRITERIA..... | 23 |
| 5.6 SAMPLING DESIGN AND RATIONALE | 24 |
| 6.0 -- Field Quality Control Samples | 25 |
| 7.0 -- Sampling Design and Rationale | 26 |
| 7.1 TCE CONTAMINATION AREA | 28 |
| 7.2 METALS CONTAMINATION AREA | 28 |
| 7.3 UST AREA SOIL SAMPLING..... | 29 |
| 8.0 -- Field Project Implementation (Field Project Instructions) | 30 |
| 8.1 FIELD PROJECT TASKS..... | 30 |
| 8.2 -- FIELD SOPs REFERENCE TABLE | 37 |
| 9.0 -- Reference Limits and Evaluation Tables | 46 |
| 10.0 -- Analytical SOP Reference Table | 50 |
| 11.0 -- Laboratory QC Samples Tables..... | 52 |
| 12.0 -- Data Verification and Validation (Steps I and IIa/IIb) Process Table | 57 |
| REFERENCES..... | 62 |

LIST OF TABLES

| | | |
|-----|---|----|
| 8-1 | Sample Details Table | 36 |
| 8-2 | Analytical SOP Requirements Table..... | 41 |
| 8-3 | Field Quality Control Sample Summary Table..... | 42 |

LIST OF FIGURES

- 4-1 Base and Site Location Map
- 4-2 Site Map SWMU 16 – Cast High Explosives Fill/B146 Incinerator
- 4-3 TCE/DCE Concentrations in Soil Rounds 1 through 3
- 4-4 Antimony Concentrations in Soil
- 4-5 Copper Concentrations in Soil
- 4-6 Lead Concentrations in Soil
- 4-7 Zinc Concentrations in Soil
- 4-8 TCE Area of Concern
- 4-9 Select Metals Area of Concern
- 7-1 Proposed Soil Delineation Sample Locations – TCE Area of Concern
- 7-2 Proposed Soil Delineation Sample Locations – Select Metals Area of Concern
- 7-3 Proposed Soil Sample Locations - UST Area of Concern

LIST OF APPENDICES

- A - Site-Specific Field Standard Operating Procedures
- B - Laboratory DoD ELAP Accreditation and EPA Performance Evaluation Results

ACRONYMS AND ABBREVIATIONS

| | |
|-------------|---|
| 1,1,2-TCA | 1,1,2-Trichloroethane |
| °C | Degrees Celsius |
| %R | Percent Recovery |
| %RSD | Percent Relative Standard Deviation |
| bgs | Below Ground Surface |
| CA | Corrective Action |
| CAS | Chemical Abstracts Service |
| CFR | Code of Federal Regulations |
| cis-1,2-DCE | cis-1,2-Dichloroethene |
| CLEAN | Comprehensive Long-Term Environmental Action Navy |
| CMD | Corrective Measure Design |
| CMP | Corrective Measure Proposal |
| CMS | Corrective Measure Study |
| COC | Chemical of Concern |
| CTO | Contract Task Order |
| DAF | Dilution Attenuation Factor |
| DL | Detection Limit |
| DoD | Department of Defense |
| DOE | Department of Energy |
| DPT | Direct-Push Technology |
| DQI | Data Quality Indicator |
| DQO | Data Quality Objective |
| DRO | Diesel Range Organic |
| DVM | Data Validation Manager |
| Eco SSL | Site-Specific Ecological Soil Screening Level |
| EDD | Electronic Data Deliverable |
| ELAP | Environmental Laboratory Accreditation Program |
| ERA | Ecological Risk Assessment |
| ERSM | Environmental Restoration Site Manager |
| FID | Flame Ionization Detector |
| FOL | Field Operations Leader |
| FSP | Field Sampling Plan |
| FTMR | Field Task Modification Request |
| g | Gram |
| GC/MS | Gas Chromatography / Mass Spectrometry |

| | |
|---------|---|
| GPS | Global Positioning System |
| HASP | Health and Safety Plan |
| HSM | Health and Safety Manager |
| ICP/MS | Inductively Coupled Plasma/Mass Spectroscopy |
| IDEM | Indiana Department of Environmental Management |
| IDQTF | Intergovernmental Data Quality Task Force |
| IDW | Investigation-Derived Waste |
| IMWP | Interim Measures Work Plan |
| IS | Internal Standard |
| IUPPS | Indiana Underground Plant Protection Services |
| LCS | Laboratory Control Sample |
| LCSD | Laboratory Control Sample Duplicate |
| LOD | Limit of Detection |
| LOQ | Limit of Quantitation |
| LTM | Long Term Monitoring |
| LUC | Land Use Control |
| MCL-SSL | Maximum Contaminant Level-Based Migration-to-Groundwater Soil Screening Level |
| MCS | Media Cleanup Standard |
| mg/kg | Milligram per Kilogram |
| mL | Milliliter |
| MPC | Measurement Performance Criterion |
| MS | Matrix Spike |
| MSD | Matrix Spike Duplicate |
| NA | Not Applicable |
| NAD | North American Datum |
| NAVFAC | Naval Facilities Engineering Command |
| Navy | U. S. Department of the Navy |
| NEDD | NIRIS Electronic Data Deliverable |
| NFA | No Further Action |
| NIRIS | Naval Installation Restoration Information Solution |
| NSA | Naval Support Activity |
| OSHA | Occupational Safety and Health Administration |
| oz | Ounce |
| PID | Photoionization Detector |
| PM | Project Manager |
| PPE | Personal Protective Equipment |
| PQLG | Project Quantitation Limit Goal |


| | |
|---------------|---|
| QA | Quality Assurance |
| QAM | Quality Assurance Manager |
| QAPP | Quality Assurance Project Plan |
| QC | Quality Control |
| QSM | Quality Systems Manual |
| RBSSL | Risk-Based Migration-to-Groundwater Soil Screening Level |
| RCRA | Resource Conservation and Recovery Act |
| R-DCL | Residential Default Closure Level |
| RFI | Resource Conservation and Recovery Act Facility Investigation |
| RPD | Relative Percent Difference |
| RPM | Remedial Project Manager |
| RT | Retention Time |
| RTI | RTI Laboratories, Inc. |
| SAP | Sampling and Analysis Plan |
| SOP | Standard Operating Procedure |
| SPCS | State Plan Coordinate System |
| SSL | Soil Screening Level |
| SSO | Site Safety Officer |
| SWMU | Solid Waste Management Unit |
| TBD | To Be Determined |
| TCE | Trichloroethene |
| Tetra Tech | Tetra Tech NUS, Inc. |
| TPH | Total Petroleum Hydrocarbons |
| trans-1,2-DCE | trans-1,2-Dichloroethene |
| UFP-SAP | Uniform Federal Policy for Sampling Analysis Plan |
| UFP-QAPP | Uniform Federal Policy for Quality Assurance Project Plan |
| U.S. | United States |
| USEPA | United States Environmental Protection Agency |
| UST | Underground Storage Tank |
| VOC | Volatile Organic Compound |

1.0 -- Project Organizational Chart

(UFP-QAPP Manual Section 2.4.1 – Worksheet #5)

Lines of Authority —————

..... Lines of Communication



DVM - Data Validation Manager
 ERS - Environmental Restoration Site Manager
 FOL - Field Operation Leader
 HSM - Health and Safety Manager
 PM - Project Manager

QAM - Quality Assurance Manager
 RPM - Remedial Project Manager
 TBD - To Be Determined
 USEPA - United States Environmental Protection Agency

2.0 -- Communication Pathways

([UFP-QAPP Manual Section 2.4.2 – Worksheet #6](#)) The communication pathways for the Sampling and Analysis Plan (SAP) are shown below.

| Communication Drivers | Responsible Entity | Name | Phone Number | Procedure (Timing, Pathway To/From, etc.) |
|------------------------------|---|------------------------------------|-----------------------------------|---|
| Regulatory Agency Interface | USEPA RPM U.S. Department of the Navy (Navy) RPM | Peter Ramanauskas Howard Hickey | 312-866-7890 847-688-2600 x243 | The Navy RPM will contact the regulatory agency via phone and/or e-mail within 24 hours of recognizing the issue whenever issues arise. |
| Field Progress Reports | Tetra Tech NUS, Inc. (Tetra Tech) FOL Tetra Tech PM | John Floyd Ralph Basinski | 502-568-6688 412-921-8308 | The Tetra Tech FOL will contact the Tetra Tech PM on a daily basis via phone, and every 1-2 days summarizing progress via e-mail. |
| Gaining site access | Tetra Tech FOL Naval Support Activity (NSA) Crane ERSM | John Floyd Tom Brent | 502-568-6688 812-854-6160 | The Tetra Tech FOL shall contact the NSA Crane ERSM verbally or via e-mail at least 3days prior to commencement of field work to arrange for access to the site for all field personnel. |
| Obtaining utility clearances | Tetra Tech FOL | John Floyd | 502-568-6688 | The Tetra Tech FOL shall contact the Indiana Underground Plant Protection Services (IUPPS) verbally or via e-mail at least 3 days prior to commencement of field work to complete a utility clearance ticket for the areas under investigation. |

| Communication Drivers | Responsible Entity | Name | Phone Number | Procedure (Timing, Pathway To/From, etc.) |
|--|---|---|---|--|
| Stop Work due to Safety Issues | Tetra Tech FOL/Site Safety Officer (SSO) Tetra Tech PM Tetra Tech HSM Navy RPM NSA Crane ERSM | John Floyd Ralph Basinski Matt Soltis Howard Hickey Tom Brent | 502-568-6688412-921-8308 412-921-8612 847-688-2600 x243 812-854-6160 | If Tetra Tech is the responsible party for a stop work command, the Tetra Tech FOL will inform onsite personnel, subcontractor(s), the Naval Support Area (NSA) Crane ERSM, and the identified Project Team members within 1 hour (verbally or by e-mail). If a subcontractor is the responsible party, the subcontractor PM must inform the Tetra Tech FOL within 15 minutes, and the Tetra Tech FOL will then follow the procedure listed above. |
| Sampling and Analyses Plan (SAP) Changes prior to Field/ Laboratory work | Tetra Tech FOL/SSO Tetra Tech PM Navy RPM NSA Crane ERSM | John Floyd Ralph Basinski Howard Hickey Tom Brent | 502-568-6688412-921-8308 847-688-2600 x243 812-854-6160 | The Tetra Tech PM will document the proposed changes via a Field Task Modification Request (FTMR) form within 5 days and send the Navy RPM a concurrence letter within 7 days of identifying the need for change if necessary. SAP amendments will be submitted by the Tetra Tech PM to the Navy RPM and NSA Crane ERSM for review and approval. The Tetra Tech PM will send scope changes to the Project Team via e-mail within 1 business day. |

| Communication Drivers | Responsible Entity | Name | Phone Number | Procedure (Timing, Pathway To/From, etc.) |
|--------------------------|---|--|---|--|
| SAP Changes in the Field | Tetra Tech FOL/SSO Tetra Tech PM Navy RPM NSA Crane ERSM | John Floyd Ralph Basinski Howard Hickey Tom Brent | 502-568-6688412-921-8308 847-688-2600 x243 812-854-6160 | <p>The Tetra Tech FOL will verbally inform the Tetra Tech PM on the day that the issue is discovered. The Tetra Tech PM will inform the Navy RPM and the NSA Crane ERSM (verbally or via e-mail) within 1 business day of discovery.</p> <p>The Navy RPM will issue a scope change (verbally or via e-mail), if warranted. The scope change is to be implemented before further work is executed.</p> <p>The Tetra Tech PM will document the change via an FTMR form within 2 days of identifying the need for change and will obtain required approvals within 5 days of initiating the form.</p> |
| Field Corrective Actions | Tetra Tech PM Tetra Tech QAM Navy RPM | Ralph Basinski Tom Johnston Howard Hickey | 412-921-8308 412-921-8615 847-688-2600 x243 | <p>The Tetra Tech QAM will notify the Tetra Tech PM verbally or by e-mail within one business day that the corrective action has been completed. The Tetra Tech PM will then notify the Navy RPM (verbally or by e-mail) within 1 business day</p> |

| Communication Drivers | Responsible Entity | Name | Phone Number | Procedure (Timing, Pathway To/From, etc.) |
|-------------------------------|--|--|---|--|
| Analytical Corrective Actions | RTI Laboratories, Inc. (RTI) Laboratory PM Tetra Tech Project Chemist Tetra Tech DVM Tetra Tech PM Navy RPM | Chino Ortiz Ed Sedlmyer Joseph Samchuck Ralph Basinski Howard Hickey | 734-422-8000 412-921-8704 412-921-8510 412-921-8308 847-688-2600 x243 | <p>The Laboratory PM will notify (verbally or via e-mail) the Tetra Tech Project Chemist within 1 business day of when an issue related to laboratory data is discovered.</p> <p>The Tetra Tech Project Chemist will notify (verbally or via e-mail) the DVM and the Tetra Tech PM within 1 business day.</p> <p>Tetra Tech DVM or Project Chemist notifies Tetra Tech PM verbally or via e-mail within 48 hrs of validation completion that a non-routine and significant laboratory quality deficiency has been detected that could affect this project and/or other projects. The Tetra Tech PM verbally advises the – Navy RPM within 24 hours of notification from the Tetra Tech Project Chemist or DVM. The Navy RPM takes corrective action appropriate for the identified deficiency. Examples of significant laboratory deficiencies include data reported that has a corresponding failed tune or initial calibration verification. Corrective actions may include a consult with the Navy Chemist.</p> |

3.0 -- Project Planning Session Participants Sheet

(UFP-QAPP Manual Section 2.5.1 – Worksheet #9)

| Project Name: Soil Contamination Study Projected Date(s) of Sampling: <u>Spring 2011</u> Project Manager: <u>Ralph Basinski</u> | | Site Name: <u>Solid Waste Management Unit (SWMU) 16 – Cast High Explosive Fill/Building 146 Incinerator</u> Site Location: <u>Crane, Indiana</u> | | | |
|---|--------------------------------|---|--------------|-------------------------------|-----------------------|
| Date of Session: April 20, 2011 Scoping Session Purpose: Data Quality Objective (DQO) Scoping Meeting | | | | | |
| Name | Title | Affiliation | Phone # | E-Mail Address | Project Role |
| Ralph Basinski | Crane Activity Coordinator/ PM | Tetra Tech | 412-921-8308 | ralph.basinski@tetrattech.com | Management/ Oversight |
| Joe Lucas | Senior Scientist | Tetra Tech | 412-921-8882 | joe.lucas@tetrattech.com | Technical Support |
| Tom Johnston | DQO Facilitator | Tetra Tech | 412-921-8615 | tom.johnston@tetrattech.com | DQO Facilitator |
| John Ducar | Senior Geologist | Tetra Tech | 412-921-8089 | john.ducar@tetrattech.com | Technical Support |

Background: The Navy has determined that soil remediation (excavation) must be conducted at SWMU 16 to remove soils contaminated above Media Cleanup Standards (MCSs). Sources for MCS values are identified in Section 5.2 of this SAP. The boundary between contaminated and non-contaminated areas needs to be more precisely defined to minimize excavation volume and costs. The Navy has directed Tetra Tech to develop a sampling and analytical program to collect the data required to refine the contaminated and non-contaminated soil boundaries in a single field event.

Comments/Decisions: Discussed SWMU 16 historical use and available data. Discussed the steps for implementing soil delineation sampling for the Corrective Measure Design (CMD), which will be conducted as an interim measure, in accordance with the Navy's Uniform Federal Policy-Sampling and Analyses Plan Tier II SAP format.

Action Items: Tetra Tech assigned the task to prepare the draft Tier II SAP.

Consensus Decisions: The meeting participants developed the overall strategy for the soil delineation sampling to facilitate a cost-effective soil removal remedial action. Consensus decisions included the following:

- Surface and subsurface soil sampling will be conducted to refine the delineation of the areas of soil impacted with trichloroethene (TCE), and surface soil sampling only will be conducted to refine the

delineation of the areas of soil impacted with metals which were generally identified during the Resource Conservation and Recovery Act Facility Investigation (RFI) at concentrations above MCSs.”

- Surface and subsurface soil samples will be conducted to determine the presence/absence of contamination in the area of the suspected underground storage tank (UST), and if present, the extent of contamination above an MCS.
- Surface soil samples will be collected from 0 to 2 feet below ground surface (bgs) in select areas identified based on RFI data in the TCE Contamination Area.
- Surface soil samples only will be collected in the Metals Contamination Area.
- For the TCE Contamination Area, subsurface soil samples will be collected from 2 to 6 feet bgs and from the 2- foot interval above bedrock (expected to be approximately 6 to 8 feet bgs in the area of sampling).
- Surface and subsurface soil samples will be collected in the area of the UST to determine if there are any target analytes that may be associated with the UST at concentrations above MCSs.

4.0 -- Conceptual Site Model

[\(UFP-QAPP Manual Section 2.5.2 – Worksheet #10\)](#)

This worksheet presents general background information about SWMU 16 – Cast High Explosives Fill/Building 146 Incinerator (Site).

4.1 SITE DESCRIPTION

SWMU 16, which is approximately 16 acres in size, is located in the north-central portion of NSA Crane. [Figure 4-1](#) shows the general location of NSA Crane in southern Indiana, and the location of SWMU 16 within NSA Crane.

Buildings and gravel parking lots cover most of the northern portion of SWMU 16 in the vicinity of Building 146, and mostly grassy and wooded areas are located south and east of Building 146 ([Figure 4-2](#)). Building 146, which has an area of approximately two-thirds acre, was an explosives fill and pressure washout facility and included a TCE degreaser, which discharged to sumps located outside of Building 146. Explosives were washed out of containers such as bomb casings, with water and the washout materials were directed to sumps. Prior to 1978, outfalls from the sumps, which are located east, and west of Building 146 discharged to swales that ultimately discharged to Boggs Creek via Turkey Creek. The degreaser has been removed and the drain lines from Building 146 have been plugged to prevent fluid flow through the pipes. Three oil-fired, rotary kiln incinerators, with fuel storage tanks were located on the south end of Building 146. These incinerators were used for the thermal destruction of the explosives material from small munitions items and components. Ashes from the incinerator were stored in a pile which was located directly south of the incinerators. The incinerators were closed in the early 1990s, and the waste ash piles were removed along with contaminated soil.

4.2 SUMMARY OF RFI RESULTS

An RFI was conducted at NSA Crane SWMU 16 in 2003 and 2004 (Tetra Tech, 2011a). The RFI included the investigation of soil, sediment and groundwater quality.

The results of the RFI indicated that TCE contamination is present in the soil beneath Building 146 and extends from the building approximately 100 feet, primarily toward the west. The source of TCE is suspected to be sumps and associated piping leading from floor drains in Building 146. TCE was identified as a chemical of concern (COC) for site groundwater in the RFI, based on human health residential standards.

In addition, metals contamination was identified in surface soil south of Building 146, and is most likely associated with past incinerator operations. The contamination is present where the waste ash piles were formerly located, and in an adjacent area where contaminated ashes were deposited from runoff from the piles. The COCs that were identified in the ecological risk assessment (ERA) for soil invertebrates, invertivorous birds, and terrestrial plants receptors were antimony, copper, lead, and zinc, which are constituents of shell casings and bullets.

The RFI recommended that a Corrective Measures Study (CMS) be conducted to evaluate remedial options for the following media.

- Groundwater to address human health risks associated with TCE and metals
- Surface soils to address ecological risks associated with metals.

4.3 SUMMARY OF PROPOSED INTERIM MEASURES

The Navy has determined that an interim measures action will be conducted to reduce the risks which were identified in the RFI. Efficient implementation of the interim measure requires a more precise delineation of the extent of soils contamination. The sampling and analytical program, which is necessary to delineate the soils contamination, is described in this SAP. The results will be utilized in the SWMU 16 Interim Measures Work Plan (IMWP).

The Navy has determined that the following interim measures will be conducted:

- Removal of chlorinated solvent contaminated soils that may be serving as a source to groundwater,
- Removal of metals contaminated soils which present unacceptable ecological risk,
- Removal of sumps, and
- Removal of a UST and any adjacent contaminated soils.

The MCS for VOCs in soils, including TCE and its degradation products, are soil criteria established for protection of groundwater. These contaminants in soil are serving as an ongoing source of groundwater contamination. [Figure 4-3](#) presents the concentrations of TCE in the surface and subsurface soils at SWMU 16 that are in exceedance of the MCS for TCE. [Figure 4-4](#) shows the boundary between the contaminated and non-contaminated soils, and the current estimated extent of TCE soil contamination excavation.

The screening criteria used to identify the metals COCs (i.e., antimony, copper, lead and zinc) during the RFI were not appropriate for use as the MCS because they were developed using conservative exposure

assumptions and do not consider site-specific factors. Toxicity/bioaccumulation testing was conducted to determine site-specific MCSs for protection of ecological receptors exposed to surface soils. The testing was conducted in accordance with a UFP-SAP (Tetra Tech, 2010). The results of the toxicity/bioaccumulation testing were presented in the Draft Final Technical Memorandum, Ecological Media Cleanup Goals, Surface Soil, SWMU 16 (Tetra Tech, 2011c). The site-specific MCS and RFI data were used to determine the extent of metals contaminated soil. [Figures 4-5 through 4-8](#) show the concentrations of these metals in soils of this area at concentrations above MCS. [Figure 4-9](#) presents the estimated extent of known contamination for all four metals, and the estimated maximum extent of all metals contamination in the soil.

5.0 -- Project Quality Objectives/Systematic Planning Process Statements

[\(UFP-QAPP Manual Section 2.6.1 – Worksheet #11\)](#)

5.1 PROBLEM STATEMENT

The extents of antimony, copper, lead, zinc, and TCE contamination in soil at two separate areas of SWMU 16 (near Building 146 and the metals contamination area) were delineated to support human health and ERAs. The human health risk assessment identified unacceptable levels of health risk for residential human receptors exposed to TCE- and metals-contaminated groundwater. The ERA identified unacceptable levels of risk for ecological receptors (i.e., soil invertebrates, invertivorous birds, and terrestrial plants) exposed to surface soil contaminated with antimony, copper, lead, and zinc. A remedy has been selected to reduce these risks to acceptable levels. The selected remedy comprises soil excavation to remove contaminated soil that serves as a groundwater contaminant source, groundwater monitoring to verify continued reduction of groundwater contaminant levels, and LUCs to prevent unacceptable human exposures.

The Navy and USEPA Region 5 agreed to incorporate a prescriptive soil remediation into the Corrective Measures Design (CMD), which will be implemented as an interim measure. In this remedy, the horizontal and vertical extent of soil contamination must be delineated sufficiently to support soil excavations in a way that minimizes the cost of soil excavation and disposal, but ensures removal of all soil with contaminant concentrations greater than established MCSs. This approach alleviates the need for confirmation sampling following remedy implementation because the extent of contamination is well defined.

The boundary of the contaminated soil (see [Figures 4-4 and 4-9](#)) is only known with a relatively coarse degree of spatial resolution that was sufficient for the risk assessments. Consequently, excavation from the most contaminated locations to the nearest locations at which contaminant concentrations are less than MCSs, would cause more soil to be excavated than is probably necessary to attain MCS concentrations across the Site and result in unnecessary expenditure for the Navy. Therefore, the Project Team must collect data to delineate the SWMU 16 soil contamination with a spatial resolution that supports a “no further action” (NFA) recommendation for soil once the contaminated soils are removed. In addition, the data collection must be accomplished in a single field event.

Also, because the SWMU 16 UST and surrounding soil were not investigated during the RFI, no information is available regarding the occurrence of contaminant releases from the UST. Contaminants could have included chlorinated and non-chlorinated VOCs, fuel oils, and lead (from leaded gasoline). Data must be collected near the UST to determine the presence or absence of soil contamination

associated with the tank, and if present, the extent of contaminant concentrations greater than the applicable MCSs. The Project Team must, however, attempt to collect enough data to delineate contamination if it is present, thus potentially limiting additional data collection prior to excavation.

5.2 DATA NEEDS

Data that are required to resolve the problem described in [Section 5.1](#) are as follows:

- Target Analyte Concentrations in soil. The list of target analytes varies with area of contamination. Refer to [Section 5.3](#) for area-specific identification of target analytes. These data (both previously collected and new data) must be obtained using laboratory analyses of soil. A complete list of target analytes is also presented in [Worksheet No. 9.0](#).
- Media Cleanup Standards. The chemical-specific values for the TCE Contamination Area and the UST Area are the USEPA groundwater protection Maximum Contaminant Level (MCL)-based values at a dilution attenuation factor (DAF) of 20 or, if these values are unavailable, the USEPA groundwater protection risk-based values at a DAF of 20. If neither of these is available for a specific compound, the MCS is the Indiana Department of Environmental Management (IDEM) Residential Closure Levels for Soil migration to groundwater standards. The chemical-specific values for the Metals Contamination Area are the site-specific ecological risk-based values derived from the toxicity/bioaccumulation testing conducted by Tetra Tech (Tetra Tech, 2011c). Details are provided on [Worksheet No. 9.0](#).

Note: The DAF of 20 was chosen because the US EPA User Guide specifies that the screening values which are established at a DAF of 1 are not to be used as MCSs. MCSs, which are established at a DAF of 20 are similar to soil groundwater protection values established by IDEM.

- Global positioning system (GPS) coordinates (sub-meter accuracy) of previous and new data collection points in soil. The previous data locations are required to serve as points of reference for new data collection points. Data collection point coordinates must be documented in the State Plane Coordinate System (SPCS) North American Datum (NAD) 1983 Indiana West (feet).
- Depths of soil intervals to be investigated. The depth of the soil interval investigated must be obtained in accordance with Standard Operating Procedure (SOP)-05.
- Quality Control Sample Data. It is necessary to use cooler temperature blanks in coolers containing samples scheduled for all laboratory analyses except the metals. Field duplicate samples will be collected at a frequency of one duplicate sample for every 20 environmental samples. Equipment

rinsate blanks are not needed because the Navy accepts the liability of accidentally contaminating a sample such that its concentration appears to exceed an MCS, when it really does not exceed the MCS.

- Analytical data reported by the laboratory use the following reporting conventions: All results below the Detection Limit (DL) will be considered nondetects. Positive results reported at concentrations between the DL and LOQ will be reported with a "J" qualifier; and analytes not found (not detected) in a sample will be reported as the Limit of Detection (LOD) with a "U" qualifier.

5.3 STUDY BOUNDARIES

Two populations of soil are of interest for each of the areas identified to have contaminant concentrations greater than MCSs. One population is the soil contaminated as a result of past site operations. The other population is soil not contaminated by site operations that helps to delineate the extent of site-related contamination. The populations of interest are subdivided into surface soil (generally 0 to 2 ft bgs) and subsurface soil (2 ft bgs to the top of bedrock). VOC contamination is not expected to be prevalent in the top 6-inches of soil; therefore, the surface soil interval for investigation of VOCs is 0.5 to 2 feet bgs.

Figures 4-4 and 4-9 identify the "contaminated" (i.e., >MCS) and "clean" (i.e., ≤ MCS) soils boundaries, based on RFI data for TCE and metals of concern, respectively. Previous delineation of contamination shows that soil contamination is generally limited to a depth of 8 feet or less, and 8 feet bgs is the maximum planned excavation depth. Bedrock is within approximately 8 feet of ground surface with an average depth of approximately 5 feet bgs in the planned area of excavation. Excavation of bedrock is not planned. Groundwater at SWMU 16 is present within a bedrock aquifer located more than 20 feet bgs; therefore, excavations are not expected to encounter groundwater. The shallow bedrock surface represents the greatest vertical extent of possible soil contamination.

Data collection is limited to a single field event.

The areas to be investigated, and the associated target analytes, are as follows:

- TCE Contamination Area (near Building 146): TCE and 1,1,2-trichloroethane (1,1,2-TCA), and the TCE degradation products cis- and trans-1,2-dichloroethene (DCE) and vinyl chloride, concentrations in surface and subsurface soil. Hereafter, this analyte list will be referred to as "TCE Contamination Area VOCs".
- Metals Contamination Area: antimony, copper, lead, and zinc concentrations in surface soil only.

- UST Area: lead, VOCs (see [Worksheet No. 9.0](#)) and Total Petroleum Hydrocarbons (TPH) Diesel Range Organics (DRO) and Gasoline Range Organics (GRO) concentrations in surface and subsurface soil. Hereafter, the VOC list will be referred to as “UST Area VOCs”.

5.4 ANALYTIC APPROACH

To resolve the problem statement presented in [Worksheet No. 5.1](#) for the TCE and metal contamination areas, the following decision rule will be used:

TCE and Metals Contamination Area Decision Rule

If all data have been collected as planned (See [Tables No. 8-1 and No. 8-3](#)) and contamination has been delineated to below the MCS, with no significant quality deficiencies, consider the delineation of soil contamination to be complete and document this in the project report; otherwise, convene the Project Team to determine the appropriate course of action. The Project Team will consider during this evaluation whether the inability to collect data was a result of site conditions (e.g., encountering refusal prior to reaching the targeted maximum depth) or factors that indicate a need to more completely delineate contamination, either prior to, or in conjunction with, the planned excavation.

Note: Because of the high sampling density anticipated, the need for additional data collection is expected to be very low unless it is due to data quality deficiencies or a decision by the Navy RPM to reduce excavation costs further.

UST Area Decision Rule

To determine whether soil contamination is present at the UST Area, the following decision rule will be applied to the data obtained in this investigation:

If all data have been collected as planned (See [Tables No. 8-1 and No. 8-3](#)) and contamination has been delineated to below the MCS, with no significant quality deficiencies, consider the delineation of soil contamination to be complete and document this in the project report; otherwise, convene the Project Team to determine the appropriate course of action. If the measured concentration of any UST Area target analyte in any soil sample for the scheduled sampling locations in the UST Area exceeds its MCS, and contamination has been delineated then calculate the volume of soil to be excavated; otherwise recommend no soil excavation for the UST Area.

5.5 PERFORMANCE CRITERIA

The only performance criterion applicable to this project is a need to collect all planned data with no significant quality deficiencies. If this is achieved, the data collected will be considered sufficient to

support the planned remediation. To evaluate data quality, the processes and criteria described in [Worksheet No. 12.0](#) will be used. Data quality deficiencies must be brought to the attention of all Project Team members for their consideration as to how the deficiencies effect attainment of project objectives (see also [Worksheet No. 5.4](#)). If any data gaps are identified, including missing or rejected data, the Project Team will assess whether project objectives can be achieved despite the existence of data gaps. This assessment will depend on the number and type of identified data gaps. All Project Team stakeholders will be involved in rendering the final conclusion regarding adequacy of the data. U-flagged values will not be used to classify a sampling point as contaminated.

5.6 SAMPLING DESIGN AND RATIONALE

The Project Team considered the volume of soil that corresponds to lateral spacing between sampling locations and agreed that approximately 10 to 40 feet between sampling locations would limit the total potential excavation costs reasonably well. This decision was based on an expectation that very few locations need to be investigated deeper than approximately 5 feet bgs in the TCE Area and 2 feet bgs in the metals contamination area, as well as the relatively small size of the UST Area. To simplify implementation of this SAP, all samples will be submitted for laboratory analysis of area-specific target analytes listed in [Worksheet No. 5.3](#) (rather than using field screening to aid delineation of contamination).

Additional details are provided in [Worksheet Nos. 7.0 and 9.0, and Table 8-1](#).

6.0 – Field Quality Control Samples

([UFP-QAPP Manual Section 2.6.2 – Worksheet #12](#))

| Quality Control (QC) Sample | Analytical Group | Frequency | Data Quality Indicators (DQIs) | Measurement Performance Criteria (MPCs) | QC Sample Assesses Error for Sampling (S), Analytical (A) or Both (S&A) |
|------------------------------|---|---|--------------------------------|--|---|
| Trip Blanks | VOCs (both TCE Contamination and UST Areas) | One per cooler containing VOC samples. | Bias/Contamination | No analytes $\geq \frac{1}{2}$ limit of quantitation (LOQ), except common laboratory contaminants, which must be $< \text{LOQ}$. | S & A |
| Duplicate Samples | All analytical groups | One per 20 field samples collected per matrix | Precision | Values $> 5x \text{LOQ}$: Relative Percent Difference (RPD) $\leq 50\%$. If duplicate values are $< 5x \text{LOQ}$, absolute difference should be $< 4x \text{LOQ}$. | S & A |
| Cooler Temperature Indicator | All analytical groups | One per cooler. | Representativeness | Temperature must be between 0 and 6 degrees Celsius ($^{\circ}\text{C}$). | S |

Note: Equipment rinsate blanks are not needed because the Navy accepts the liability of accidentally contaminating a sample such that its concentration appears to exceed an MCS, when it really does not exceed the MCS.

7.0 -- Sampling Design and Rationale

[\(UFP-QAPP Manual Section 3.1.1 – Worksheet #17\)](#)

TCE Contamination Area: The RFI identified chlorinated-solvent contaminated groundwater as presenting excess risk and recommended that a CMS be conducted. The primary risk drivers were Carbon Tetrachloride, cis-1,2-Dichloroethene, 1,1,2-Trichloroethane, Trichloroethene, Tetrachloroethene and Vinyl Chloride. During the evaluation of corrective measures source removal (i.e. excavation) of chlorinated-solvent contaminated soils followed by monitored natural attenuation (MNA) was identified as the recommended alternative for groundwater. This excavation will be conducted as an interim measure. In order to accomplish the interim measure additional data is required to determine the extent of soil contaminated above MCS for the constituents which are the primary risk drivers for groundwater use.

UST Area: The UST, which was discovered after completion of the RFI, is suspected to have been used for the storage of fuels. The constituent target list was chosen based on potential constituents which might have been released from the tank if used to store fuels. These target constituents are Appendix IX VOCs, DRO and GRO.

Metals Contamination Area: The RFI identified four metals, antimony, copper, lead and zinc as presenting excess risk to ecological receptors and recommended that a CMS be conducted. Excavation of contaminated surface soils was identified as the recommended alternative for remediation of excess ecological risk. This excavation will be conducted as an interim measure. As part of the CMS process toxicity testing was conducted to develop site-specific media cleanup standards. In order to efficiently accomplish the soil removal additional data is required to determine the extent of soils contaminated above the site-specific MCS for antimony, copper, lead and zinc.

The sampling strategy for SWMU 16 is to implement soil delineation sampling for the IMWP phase of the project at two discrete areas (TCE Contamination Area and Metals Contamination Area) in order to provide for prescriptive sampling prior to soil excavation. The IMWP will define the horizontal and vertical extent of soil excavations to meet each MCS. No confirmation sampling will be required.

In addition, a UST was identified after the completion of RFI field activities. Therefore, it was not investigated during the RFI, and no information is available regarding the occurrence of releases or soil quality near the tank. Soil samples will be collected in the vicinity of the UST to determine the presence (i.e., >MCS) or absence (i.e., ≤ MCS) of contamination associated with the tank. If present in concentrations above the MCS, determine the horizontal and vertical extent of contamination.

The following discusses the sampling locations, media to be sampled, and analyses. Sampling locations are illustrated on [Figures 7-1 through 7-3](#), and a matrix table of samples is provided in [Table 8-1](#). Soil borings will be advanced using direct-push technology (DPT) (macrocore samplers) or hand auger methods to collect surface and subsurface soil samples, surface soil only locations (Metals Contamination Area) will be sampled using a hand auger.

In the TCE and Metals Contamination Areas, soil sample locations were selected to target areas with unknown soil concentrations of the COCs, located between the “contaminated” (i.e., >MCS) and “clean” (i.e., ≤ MCS) soils boundaries, based on RFI data for TCE and metals of concern in order to refine the areas of soil contamination requiring removal.

In the TCE Contamination Area, soil borings will consist of up to three soil samples to be collected from each soil boring location; one surface soil (0.5 to 2 feet bgs for VOCs) from select locations, one subsurface soil from 2 to 6 feet bgs, and one subsurface soil sample from the 2-foot soil interval directly above the bedrock surface. Sample collection for VOC parameters will follow the methodology described in SOP-07. Bedrock is expected to be approximately 6 to 8 feet bgs in the area of sampling. In the Metals Contamination Area, only surface soil samples (0 to 2 feet bgs) will be collected from each sample location.

The sampling locations represent areas not previously investigated. The spacing between sampling locations was driven primarily by the need to delineate contamination laterally, especially in the TCE and metals contamination areas that have already been investigated. In these areas, bedrock depth is shallow and sampling deeper than approximately 5 feet bgs is not possible at many locations. The intent is to bound the total volume of soil to be excavated to an acceptable maximum volume. This will be done by connecting the innermost sampling locations that have target analyte concentrations less than MCSs so that, when connected to form a three-dimensional polygon, they enclose the minimum volume of soil with target analyte concentrations greater than MCSs.

In the UST Area, surface and subsurface soil samples will be collected to determine the presence/absence of contamination, and if present, whether it is present above MCS.

Groundwater occurs in bedrock in the area of SWMU 16; therefore, groundwater will not be encountered during this soil investigation.

Sampling and other field task methodologies are described in [Worksheet No. 8.1](#).

7.1 TCE CONTAMINATION AREA

Soil Borings

Thirty-six soil borings (16SB118 through 16SB153) will be advanced with the use of a DPT drill rig within the area west and north of Building 146 within SWMU 16 ([Figure 7-1](#)). Up to three soil samples will be collected from each soil boring location: one surface soil (0.5 to 2 feet bgs), and up to two subsurface soil samples, depending on soil depth above bedrock. Only one subsurface soil sample will be collected if the bedrock is less than 6 feet bgs. The subsurface soil samples will be collected from 2 to 6 feet bgs and the 2-foot soil interval above the bedrock surface.

The soil samples will be analyzed for TCE Contamination Area VOCs.

NOTE: Collection of the soil sample from the appropriate interval for VOC analyses is critical. When determining the specific location within the soil boring for sample collection, the following hierarchy must be followed:

If elevated volatile organics are measured via the PID, collect the VOC samples from the specific interval where the highest PID reading is measured. If no above-background PID readings are measured, then the VOC sample will be collected from a specific interval where visual signs of contamination (staining, etc.) are observed. If no above-background PID reading is measured, and no discoloration or odor in the soil core indicates potential contamination, then collect the VOC sample from near the center of the core at the bottom of the interval.

7.2 METALS CONTAMINATION AREA

Surface Soil

Thirty-seven hand auger soil borings (16SB154 through 16SB190) will be advanced within the area south of Building 146 ([Figure 7-2](#)). The sample locations were selected to further delineate and refine the area of known metals contamination, based on RFI data. One surface soil sample (0 to 2 feet bgs) will be collected from each soil boring location.

The soil samples will be analyzed for antimony, copper, lead, and zinc.

7.3 UST AREA SOIL SAMPLING

Soil Borings

Eight soil borings (16SB191 through 16SB198) will be advanced within the area surrounding the UST, which is located approximately 120 feet north of Building 146 within SWMU 16 ([Figure 7-3](#)). The boring locations were selected to identify and delineate the potential presence of soil contamination associated with the tank. Up to three soil samples will be collected from each soil boring location: one surface soil (0.5 to 2 feet bgs), and two subsurface soil samples. The subsurface soil samples will be collected from 2 to 6 feet bgs and 6 to 10 feet bgs, or the 2-foot soil interval above the bedrock surface, if bedrock is encountered at a depth shallower than 10 feet bgs.

The historic or current contents of the UST are unknown; however, the highest probability is that it was used to store fuel oil (most likely diesel/fuel oil No. 2). As a conservative measure, the soil samples will be analyzed for UST Area VOCs, TPH-GRO, TPH DRO, and lead (in case the tank contained leaded gasoline at one time).

NOTE: See the discussion regarding the collection of soil samples for VOC analyses in Section 7.1.

8.0 – Field Project Implementation (Field Project Instructions)

([UFP-QAPP Manual Section 5.2.3](#))

8.1 FIELD PROJECT TASKS

([UFP-QAPP Manual Section 2.8.1 – Worksheet #14](#))

Site-specific SOPs have been developed for field activities at NSA Crane and are located in [Appendix A](#). Field tasks are summarized below with a short description for each task.

- Mobilization/Demobilization
- Utility Clearance
- Site-Specific Health and Safety Training
- Sample Collection Tasks
- Surface and Subsurface Soil Sampling
- GPS Locating
- Investigation-Derived Waste (IDW) Management
- Field Decontamination Procedures
- Sample Handling
- QC

Mobilization/Demobilization

Mobilization will consist of the delivery of all equipment, materials, and supplies to the site, complete assembly in satisfactory working order of all such equipment at the site, and satisfactory storage at the site of all such materials and supplies. The Tetra Tech FOL or designee will coordinate with the NSA Crane ERSW to identify appropriate locations for the storage of equipment and supplies. Site-specific health and safety training for all Tetra Tech field personnel and subcontractors will be provided as part of site mobilization.

Demobilization will consist of the prompt and timely removal of all equipment, materials, and supplies from the site following completion of the work. Demobilization includes the cleanup and removal of waste generated during the performance of the investigation.

Utility Clearance

One week prior to the commencement of any subsurface intrusive activities, the Tetra Tech FOL or designee will contact IUPPS to complete a utility clearance ticket for the areas under investigation. Work

permits, if required by the facility, will be obtained prior to conducting field activities. The Tetra Tech FOL will be responsible for coordinating these activities.

Site-Specific Health and Safety Training

There are no specialized/non-routine project-specific training requirements or certifications needed by personnel to successfully complete the project or tasks. All field personnel will have appropriate training to conduct the field activities to which they are assigned. Each site worker will be required to have completed the Occupational Safety and Health Administration (OSHA) 40-hour course (and 8-hour refresher, if applicable) in health and safety training. Safety requirements are addressed in greater detail in the site-specific Health and Safety Plan (HASP).

Sample Collection Tasks

The sampling and analysis program is outlined in [Worksheet No. 7.0 and Table 8-1](#). Sample collection will be in accordance with the site-specific SOPs listed in [Worksheet No. 8.2](#) and provided in [Appendix A](#). The sampling requirements for each type of analysis (i.e., bottleware, preservation, holding time) are listed in [Table 8-2](#). Field and laboratory QC samples will also be collected as outlined in [Table 8-3](#).

Surface and Subsurface Soil Sampling

Surface and subsurface soil samples will be collected in accordance with [SOP-05](#) (Borehole Advancement and Soil Coring Using DPT and Hand Auger Techniques, [Appendix A](#)). Surface soil only samples will be collected with a hand auger within the area of metals contamination delineation and where DPT access may be limited. Combined surface soil and subsurface soil samples locations (all other locations) will be collected using a DPT. The soil borings will be described by the field personnel in accordance with [SOP-06](#) (Soil Sample Logging, [Appendix A](#)). Any qualitative visual signs of potential contamination (such as soil staining) will be noted on the soil boring log. The surface and subsurface soil samples will be collected in accordance with [SOP-07](#) (Surface and Subsurface Soil Sampling, [Appendix A](#)).

Global Positioning System Locating

A GPS unit will be used to locate all soil sampling points in accordance with [SOP-09](#) (Global Positioning System, [Appendix A](#)). The GPS equipment will be checked on control monuments before and after each day's use; these checks will be documented in the field notebook. To ensure sub-meter accuracy, the GPS SOP requires a minimum of six satellites to capture a position.

Investigation-Derived Waste Management

Solid or semi-solid IDW in the form of soil will be generated during field activities, including during collection of subsurface samples using DPT. Soil will be replaced into the boring from which it was removed.

IDW generated, including personal protective equipment (PPE) and decontamination fluids, will be handled in accordance with [SOP-10](#) (Management of Investigation-Derived Waste, [Appendix A](#)).

Field Decontamination Procedures

Decontamination of sampling equipment will not be necessary for dedicated and disposable hand trowels. Decontamination of reusable sampling equipment (e.g., non-disposable hand trowels, hand augers, and DPT sampling equipment) will be conducted prior to sampling and between samples at each location. Decontamination of equipment will be conducted according to the sequence established in [SOP-08](#) (Decontamination of Field Sampling Equipment, [Appendix A](#)).

Field Documentation Procedures

Field documentation will be performed in accordance with [SOP-03](#) (Sample Custody and Documentation of Field Activity, [Appendix A](#)).

Sample Handling

Methods for sample handling will be in accordance with [SOP-03](#) (Sample Custody and Documentation of Field Activities, [Appendix A](#)). Sample containers will be provided certified-clean (I-Chem 300 or equivalent) from the analytical laboratory. Sample labeling will be in accordance with [SOP-01](#) (Sample Labeling, [Appendix A](#)), and the sample numbering scheme will be in accordance with [Table 8-1](#) and [SOP-02](#) (Sample Identification and Nomenclature, [Appendix A](#)). The selection of sample containers, sample preservation, packaging, and shipping will be in accordance with [Table 8-2](#) and [SOP-04](#) (Sample Preservation, Packaging, and Shipping, [Appendix A](#)).

Quality Control Tasks

QA/QC samples will be collected at frequencies listed in [Worksheet No. 6.0](#).

ADDITIONAL PROJECT-RELATED TASKS

Additional project-related tasks include:

- Analytical tasks
- Data management
- Data review
- Project reports

Analytical Tasks

Chemical analyses will be performed by RTI, which is a Department of Defense (DoD) Environmental Laboratory Accreditation Program (ELAP)-accredited laboratory. A copy of RTI's accreditation and most recent EPA performance evaluation results are included in [Appendix B](#). Analyses will be performed in accordance with the analytical methods identified in [Table 8-2](#). RTI will meet the MCSs specified in [Worksheet No. 9.0](#) and will perform the chemical analyses following laboratory-specific SOPs (see [Table 8-2](#) and [Worksheet 10.0](#)) developed based on the methods listed in [Table 8-2](#).

All soil results will be reported by the laboratory on an adjusted dry-weight basis. Results of percent moisture will be reported in each analytical data package and associated electronic data files. This information will also be captured in the project database, which will eventually be uploaded to the Naval Installation Restoration Information Solution (NIRIS) database. Percent moisture information will also be captured in the CMS Report.

The analytical data packages provided by RTI will be in a Contract Laboratory Program-like format and will be fully validatable and contain raw data, summary forms for all sample and laboratory method blank data, and summary forms containing all method-specific QC (results, recoveries, relative percent differences (RPDs), relative standard deviations (RSD), and/or percent differences, etc.).

Data Management

The principal data generated for this project will be from field data and laboratory analytical data. Field sampling log sheets will be organized by date and medium, and filed in the project files. The field logbooks for this project will be used only for this site and will also be categorized and maintained in the project files after the completion of the field program. Project personnel completing concurrent field sampling activities may maintain multiple field logbooks. When possible, logbooks will be segregated by sampling activity. The field logbooks will be titled based on date and activity.

The data handling procedures to be followed by RTI will meet the requirements of the technical specifications. Electronic data results will be automatically downloaded into the Tetra Tech database in accordance with the proprietary Tetra Tech processes.

The Tetra Tech PM (or designee) is responsible for the overall tracking and control of data generated for the project.

- **Data Tracking.** Data are tracked from generation to archiving in the Tetra Tech project-specific files. The Tetra Tech Project Chemist (or designee) is responsible for tracking the samples collected and shipped to Empirical. Upon receipt of the data packages from RTI, the Tetra Tech Project Chemist will monitor the data validation effort, which includes verifying that the data packages are complete and results for all samples have been delivered by RTI.
- **Data Storage, Archiving, and Retrieval.** The data packages received from RTI are tracked in the data validation logbook. After the data are validated, the data packages are entered into the Tetra Tech Navy CLEAN file system and archived in secure files. The field records including field log books, sample logs, chain-of-custody records, and field calibration logs will be submitted by the Tetra Tech FOL to be entered into the Navy CLEAN file system prior to archiving in secure project files. Project files are audited for accuracy and completeness. At the completion of the Navy contract, the records will be stored by Tetra Tech.
- **Data Security.** Access to Tetra Tech project files is restricted to designated personnel only. Records can only be borrowed temporarily from the project file using a sign-out system. The Tetra Tech Data Manager maintains the electronic data files, and access to the data files is restricted to qualified personnel only. File and data backup procedures are routinely performed.
- **Electronic Data.** All electronic data will be compiled into a NIRIS Electronic Data Deliverable (NEDD) and loaded into NIRIS.
- **Data Review.** This review comprises data verification, validation, and usability assessment. The data verification and validation processes and requirements are described in [Worksheet No. 6.0](#). The data usability assessment will, at a minimum, constitute evaluation of the following characteristics to ensure that the amount, type, and quality of data are sufficient to achieve project objectives. The means of conducting these evaluations will vary depending on the nature of the data. For example, soil borings and well construction logs will generally be evaluated qualitatively or semiquantitatively whereas precision, accuracy, and sensitivity of analytical data will generally be evaluated quantitatively and may be based on, or may supplement, data validation findings. Examples include:

- Comparing actual to intended sampling locations and verifying that the correct datum was used to delineate contamination
- Evaluating trends across sample delivery groups or sampling events
- Assessing quantitative relationships between parameters (e.g., relative magnitudes of TCE and its degradation product concentrations)
- Identifying potential errant or outlier data points
- Assessing planning assumption validity
- Evaluating the potential for contamination of samples by samplers

Data quality indicators to be evaluated during this assessment include:

1. **Precision.** A semiquantitative estimate of the uncertainty in contaminant concentrations as a function of location will be made.
2. **Accuracy.** Accuracy data will be evaluated to ensure sampling and measurement accuracy is within or exceeds analytical method specifications and may depend in part on the data validation findings.
3. **Representativeness.** This evaluation will assess whether the data are adequately representative of intended populations based on the sample collection and data generation requirements specified in this SAP.
4. **Completeness.** Failure to obtain critical data from planned locations will be documented. Minor variations in actual versus intended sampling locations (or depths) that do not adversely affect the attainment of project objectives will not be documented.
5. **Comparability.** This will be accomplished by comparing overall precision and bias among data sets for each matrix and analytical fraction for each sampled area. This will not require quantitative comparisons unless the Tetra Tech Project Chemist indicates that such quantitative analysis is beneficial to the project and the Tetra Tech PM agrees.
6. **Sensitivity.** The Tetra Tech Project Chemist will determine whether project sensitivity goals were achieved by comparing non-detect values to MCSs.

- 7. Other quantitative characteristics.** These may include quantities such as verification of soil volume calculations, soil disposal cost estimates, etc., that are used to determine whether the contaminants are sufficiently well delineated to estimate remediation costs.

If significant data quality deficiencies are detected that prevent the attainment of project objectives, the limitations on the affected data will be described in the project report. The Tetra Tech PM will bring these deficiencies to the attention of the project team for their evaluation and the team will determine an appropriate corrective action depending on the circumstances.

8.2 FIELD SOPs REFERENCE TABLE

([UFP-QAPP Manual Section 3.1.2 – Worksheet #21](#))

| Reference Number | Title, Revision Date, and/or Number | Originating Organization of Sampling SOP | Equipment Type | Modified for Project Work? (Y/N) | Comments |
|-------------------------|---|---|---|---|---|
| SOP-01 | Sample Labeling, 02/11, Revision 0. | Tetra Tech | Not Applicable (NA) | N | Contained in Appendix A |
| SOP-02 | Sample Identification Nomenclature, 02/11, Revision 0. | Tetra Tech | NA | Y | Contained in Appendix A |
| SOP-03 | Sample Custody and Documentation of Field Activities, 02/11, Revision 0. | Tetra Tech | Field logbook, sample log sheets, boring logs | N | Contained in Appendix A |
| SOP-04 | Sample Preservation, Packaging, and Shipping, 02/11, Revision 0. | Tetra Tech | NA | N | Contained in Appendix A |
| SOP-05 | Borehole Advancement and Soil Coring Using Direct-Push Technology (DPT) and Hand Auger Techniques, 02/11, Revision 0. | Tetra Tech | DPT rig, stainless steel augers, extension rods, and T-handle | N | Contained in Appendix A |
| SOP-06 | Soil Sample Logging, 02/11, Revision 0. | Tetra Tech | NA | N | Contained in Appendix A |
| SOP-07 | Surface and Subsurface Soil Sampling, 02/11, Revision 0. | Tetra Tech | Stainless steel auger bucket, extension rods, and T-handle, photoionization detector (PID) | N | Contained in Appendix A |
| SOP-08 | Decontamination of Field Sampling Equipment, 02/11, Revision 0. | Tetra Tech | Decontamination equipment, scrub brushes, 5-gallon buckets, spray bottles, phosphate free detergent, de-ionized water | N | Contained in Appendix A |
| SOP-09 | Global Positioning System, 02/11, Revision 0. | Tetra Tech | GPS unit | N | Contained in Appendix A |
| SOP-10 | Management of Investigation-Derived Waste, 02/11, Revision 0. | Tetra Tech | NA | Y | Contained in Appendix A |

Table 8-1 – Sample Details Table

(UFP-QAPP Manual Section 3.1.1 and 3.5.2.3 – Worksheet #18, 19, 20 and 30)

| Sample Location | Sample ID ⁽¹⁾ | Analyses | | |
|-------------------------------|--------------------------|-----------------------------|---------------------------|--------------------------------------|
| | | TCE Contamination Area VOCs | Metals Contamination Area | UST Area VOCs, TPH-GRO TPH-DRO, Lead |
| SOIL – TCE Contamination Area | | | | |
| 16SB118 | 16SB1180002 | 1 | -- ⁽²⁾ | -- |
| | 16SB1180206 | 1 | -- | -- |
| | 16SB118XXXX | 1 | -- | -- |
| 16SB119 | 16SB1190002 | 1 | -- | -- |
| | 16SB1190206 | 1 | -- | -- |
| | 16SB119XXXX | 1 | -- | -- |
| 16SB120 | 16SB1200002 | 1 | -- | -- |
| | 16SB1200206 | 1 | -- | -- |
| | 16SB120XXXX | 1 | -- | -- |
| 16SB121 | 16SB1210002 | 1 | -- | -- |
| | 16SB1210206 | 1 | -- | -- |
| | 16SB121XXXX | 1 | -- | -- |
| 16SB122 | 16SB1220002 | 1 | -- | -- |
| | 16SB1220206 | 1 | -- | -- |
| | 16SB122XXXX | 1 | -- | -- |
| 16SB123 | 16SB1230002 | 1 | -- | -- |
| | 16SB1230206 | 1 | -- | -- |
| | 16SB123XXXX | 1 | -- | -- |
| 16SB124 | 16SB1240002 | 1 | -- | -- |
| | 16SB1240206 | 1 | -- | -- |
| | 16SB124XXXX | 1 | -- | -- |
| 16SB125 | 16SB1250002 | 1 | -- | -- |
| | 16SB1250206 | 1 | -- | -- |
| | 16SB125XXXX | 1 | -- | -- |
| 16SB126 | 16SB1260002 | 1 | -- | -- |
| | 16SB1260206 | 1 | -- | -- |
| | 16SB126XXXX | 1 | -- | -- |
| 16SB127 | 16SB1270002 | 1 | -- | -- |
| | 16SB1270206 | 1 | -- | -- |
| | 16SB127XXXX | 1 | -- | -- |

| Sample Location | Sample ID ⁽¹⁾ | Analyses | | |
|-----------------|--------------------------|-----------------------------|---------------------------|--------------------------------------|
| | | TCE Contamination Area VOCs | Metals Contamination Area | UST Area VOCs, TPH-GRO TPH-DRO, Lead |
| 16SB128 | 16SB1280002 | 1 | -- | -- |
| | 16SB1280206 | 1 | -- | -- |
| | 16SB128XXXX | 1 | -- | -- |
| 16SB129 | 16SB1290002 | 1 | -- | -- |
| | 16SB1290206 | 1 | -- | -- |
| | 16SB129XXXX | 1 | -- | -- |
| 16SB130 | 16SB1300002 | 1 | -- | -- |
| | 16SB1300206 | 1 | -- | -- |
| | 16SB130XXXX | 1 | -- | -- |
| 16SB131 | 16SB1310002 | 1 | -- | -- |
| | 16SB1310206 | 1 | -- | -- |
| | 16SB131XXXX | 1 | -- | -- |
| 16SB132 | 16SB1320002 | 1 | -- | -- |
| | 16SB1320206 | 1 | -- | -- |
| | 16SB132XXXX | 1 | -- | -- |
| 16SB133 | 16SB1330002 | 1 | -- | -- |
| | 16SB1330206 | 1 | -- | -- |
| | 16SB133XXXX | 1 | -- | -- |
| 16SB134 | 16SB1180002 | 1 | -- | -- |
| | 16SB1340206 | 1 | -- | -- |
| | 16SB134XXXX | 1 | -- | -- |
| 16SB135 | 16SB1350002 | 1 | -- | -- |
| | 16SB1350206 | 1 | -- | -- |
| | 16SB135XXXX | 1 | -- | -- |
| 16SB136 | 16SB1360002 | 1 | -- | -- |
| | 16SB1360206 | 1 | -- | -- |
| | 16SB136XXXX | 1 | -- | -- |
| 16SB137 | 16SB1370002 | 1 | -- | -- |
| | 16SB1370206 | 1 | -- | -- |
| | 16SB137XXXX | 1 | -- | -- |
| 16SB138 | 16SB1380002 | 1 | -- | -- |
| | 16SB1380206 | 1 | -- | -- |
| | 16SB138XXXX | 1 | -- | -- |
| 16SB139 | 16SB1390002 | 1 | -- | -- |
| | 16SB1390206 | 1 | -- | -- |
| | 16SB139XXXX | 1 | -- | -- |

| Sample Location | Sample ID ⁽¹⁾ | Analyses | | |
|-----------------|--------------------------|-----------------------------|---------------------------|--------------------------------------|
| | | TCE Contamination Area VOCs | Metals Contamination Area | UST Area VOCs, TPH-GRO TPH-DRO, Lead |
| 16SB140 | 16SB1400002 | 1 | -- | -- |
| | 16SB1400206 | 1 | -- | -- |
| | 16SB140XXXX | 1 | -- | -- |
| 16SB141 | 16SB1410002 | 1 | -- | -- |
| | 16SB1410206 | 1 | -- | -- |
| | 16SB141XXXX | 1 | -- | -- |
| 16SB142 | 16SB1420002 | 1 | -- | -- |
| | 16SB1420206 | 1 | -- | -- |
| | 16SB142XXXX | 1 | -- | -- |
| 16SB143 | 16SB1430002 | 1 | -- | -- |
| | 16SB1430206 | 1 | -- | -- |
| | 16SB143XXXX | 1 | -- | -- |
| 16SB144 | 16SB1440002 | 1 | -- | -- |
| | 16SB144-0206 | 1 | -- | -- |
| | 16SB144XXXX | 1 | -- | -- |
| 16SB145 | 16SB1240002 | 1 | -- | -- |
| | 16SB1240206 | 1 | -- | -- |
| | 16SB124XXXX | 1 | -- | -- |
| 16SB146 | 16SB1460002 | 1 | -- | -- |
| | 16SB1460206 | 1 | -- | -- |
| | 16SB146XXXX | 1 | -- | -- |
| 16SB147 | 16SB1470002 | 1 | -- | -- |
| | 16SB1470206 | 1 | -- | -- |
| | 16SB147XXXX | 1 | -- | -- |
| 16SB148 | 16SB1480002 | 1 | -- | -- |
| | 16SB1480206 | 1 | -- | -- |
| | 16SB148XXXX | 1 | -- | -- |
| 16SB149 | 16SB1490002 | 1 | -- | -- |
| | 16SB1490206 | 1 | -- | -- |
| | 16SB149XXXX | 1 | -- | -- |
| 16SB150 | 16SB1500002 | 1 | -- | -- |
| | 16SB1500206 | 1 | -- | -- |
| | 16SB150XXXX | 1 | -- | -- |
| 16SB151 | 16SB1510002 | 1 | -- | -- |
| | 16SB1510206 | 1 | -- | -- |
| | 16SB151XXXX | 1 | -- | -- |

| Sample Location | Sample ID ⁽¹⁾ | Analyses | | |
|--|--------------------------|-----------------------------|---------------------------|--------------------------------------|
| | | TCE Contamination Area VOCs | Metals Contamination Area | UST Area VOCs, TPH-GRO TPH-DRO, Lead |
| 16SB152 | 16SB1520002 | 1 | -- | -- |
| | 16SB1520206 | 1 | -- | -- |
| | 16SB152XXXX | 1 | -- | -- |
| 16SB153 | 16SB1530002 | 1 | -- | -- |
| | 16SB1530206 | 1 | -- | -- |
| | 16SB153XXXX | 1 | -- | -- |
| SOIL –Metals Contamination Area | | | | |
| 16SB154 | 16SB1540002 | -- | 1 | -- |
| 16SB155 | 16SB1550002 | -- | 1 | -- |
| 16SB156 | 16SB1560002 | -- | 1 | -- |
| 16SB157 | 16SB1570002 | -- | 1 | -- |
| 16SB158 | 16SB1580002 | -- | 1 | -- |
| 16SB159 | 16SB1590002 | -- | 1 | -- |
| 16SB160 | 16SB1600002 | -- | 1 | -- |
| 16SB161 | 16SB1610002 | -- | 1 | -- |
| 16SB162 | 16SB1620002 | -- | 1 | -- |
| 16SB163 | 16SB1630002 | -- | 1 | -- |
| 16SB164 | 16SB1640002 | -- | 1 | -- |
| 16SB165 | 16SB1650002 | -- | 1 | -- |
| 16SB166 | 16SB1660002 | -- | 1 | -- |
| 16SB167 | 16SB1670002 | -- | 1 | -- |
| 16SB168 | 16SB1680002 | -- | 1 | -- |
| 16SB169 | 16SB1690002 | -- | 1 | -- |
| 16SB170 | 16SB1700002 | -- | 1 | -- |
| 16SB171 | 16SB1710002 | -- | 1 | -- |
| 16SB172 | 16SB1720002 | -- | 1 | -- |
| 16SB173 | 16SB1730002 | -- | 1 | -- |
| 16SB174 | 16SB1740002 | -- | 1 | -- |
| 16SB175 | 16SB1750002 | -- | 1 | -- |
| 16SB176 | 16SB1760002 | -- | 1 | -- |
| 16SB177 | 16SB1770002 | -- | 1 | -- |
| 16SB178 | 16SB1780002 | -- | 1 | -- |
| 16SB179 | 16SB1790002 | -- | 1 | -- |
| 16SB180 | 16SB1800002 | -- | 1 | -- |
| 16SB181 | 16SB1810002 | -- | 1 | -- |
| 16SB182 | 16SB1820002 | -- | 1 | -- |
| 16SB183 | 16SB1830002 | -- | 1 | -- |

| Sample Location | Sample ID ⁽¹⁾ | Analyses | | |
|------------------------|--------------------------|-----------------------------|---------------------------|--------------------------------------|
| | | TCE Contamination Area VOCs | Metals Contamination Area | UST Area VOCs, TPH-GRO TPH-DRO, Lead |
| 16SB184 | 16SB1840002 | -- | 1 | -- |
| 16SB185 | 16SB1850002 | -- | 1 | -- |
| 16SB186 | 16SB1860002 | -- | 1 | -- |
| 16SB187 | 16SB1870002 | -- | 1 | -- |
| 16SB188 | 16SB1880002 | -- | 1 | -- |
| 16SB189 | 16SB1890002 | -- | 1 | -- |
| 16SB190 | 16SB1900002 | -- | 1 | -- |
| SOIL – UST Area | | | | |
| 16SB191 | 16SB1910002 | -- | -- | 1 |
| | 16SB1910206 | -- | -- | 1 |
| | 16SB191XXXX | -- | -- | 1 |
| 16SB192 | 16SB1920002 | -- | -- | 1 |
| | 16SB1920206 | -- | -- | 1 |
| | 16SB192XXXX | -- | -- | 1 |
| 16SB193 | 16SB1930002 | -- | -- | 1 |
| | 16SB1930206 | -- | -- | 1 |
| | 16SB193XXXX | -- | -- | 1 |
| 16SB194 | 16SB1940002 | -- | -- | 1 |
| | 16SB1940206 | -- | -- | 1 |
| | 16SB194XXXX | -- | -- | 1 |
| 16SB195 | 16SB1950002 | -- | -- | 1 |
| | 16SB1950206 | -- | -- | 1 |
| | 16SB195XXXX | -- | -- | 1 |
| 16SB196 | 16SB1960002 | -- | -- | 1 |
| | 16SB1960206 | -- | -- | 1 |
| | 16SB196XXXX | -- | -- | 1 |
| 16SB197 | 16SB1970002 | -- | -- | 1 |
| | 16SB1970206 | -- | -- | 1 |
| | 16SB197XXXX | -- | -- | 1 |
| 16SB198 | 16SB1980002 | -- | -- | 1 |
| | 16SB1980206 | -- | -- | 1 |
| | 16SB198XXXX | -- | -- | 1 |

1. . XXXX represents the interval of the sample from below 2 feet bgs and above top of bedrock. For example, if the sample is collected from 2 to 6 feet bgs, the depth will be recorded as 0206.
2. -- Not analyzed

Table 8-2 -- Analytical SOP Requirements Table

Laboratory point of contact, e-mail address, and phone number: Chino Ortiz, cortiz@rtilab.com, 734-422-8000

Laboratory Name and Address:

RTI Laboratories, Inc.
31627 Glendale Street
Livonia, MI 48150

Data Package Turnaround time: 21 days

Tentative Sampling Dates: To be determined (TBD)

| Matrix | Analytical Group | Analytical And Preparation Method/ SOP Reference ⁽¹⁾ | Containers (number, size, and type) | Sample Volume (units) | Preservation Requirements (chemical, temperature, light protected) | Maximum Holding Time (preparation/ analysis) |
|---------------|--|--|---|------------------------------|---|---|
| Soil | TCE Contamination Area and UST Area VOCs | SW-846 5035A/8260B/RTI SOP 8260B_110810_R7 | Three 5-gram (g) (collected using Terra Cores), three 40-milliliter (mL) glass vials with magnetic stir bars, and One 2-ounce (oz.) wide mouth jar for percent moisture | 5 g | One vial 5-mLVOC-free water, One vial of 5-mL VOC-free water with sodium bisulfate, One vial of 5-mL methanol, cool to $\leq 6^{\circ}\text{C}$; lab to freeze to $< -10^{\circ}\text{C}$ upon receipt | 14 days to analysis |
| Soil | Metals (including Lead only) | SW-846 3050B, 6020A/RTI SOP 3050_091410_R9, 6020_072810_R8, | 4-oz wide-mouth jar | 2 g | Cool to $\leq 6^{\circ}\text{C}$ | 180 days to analysis |
| Soil | TPH DRO | SW-846 3550B/8015B/ RTI SOP 8015BDRO_ORO_100110_R1_1 | One 4-oz glass jar with a Teflon-lined lid | 25 g | Cool to $\leq 6^{\circ}\text{C}$ | 14 days until extraction, 40 days to analysis |

| Matrix | Analytical Group | Analytical And Preparation Method/ SOP Reference ⁽¹⁾ | Containers (number, size, and type) | Sample Volume (units) | Preservation Requirements (chemical, temperature, light protected) | Maximum Holding Time (preparation/ analysis) |
|---------------|-------------------------|--|--|------------------------------|--|---|
| Soil | TPH GRO | SW-846 5035A/8015B/RTI SOP 8015BGRO_110810_R2 | Two 5 g (collected using Terra Cores), two 40-mL glass vials with magnetic stir bars, and One 2- oz. wide mouth jar for percent moisture | 5 g | Two vials of 5 mL methanol, cool to $\leq 6^{\circ}\text{C}$; lab to freeze to $< -10^{\circ}\text{C}$ upon receipt | 14 days to analysis |

Notes:

- 1 Specify the appropriate reference letter or number from the Analytical SOP References table ([Worksheet No. 10.0](#)).

Table 8-3 -- Field Quality Control Sample Summary Table

| Matrix | Analytical Group | No. of Samples | No. of MS/MSDs ⁽¹⁾ | No. of Duplicate Samples ⁽²⁾ | No. of VOC Trip Blanks ⁽³⁾ | Total No. of Samples to Lab |
|-----------------|-----------------------------|----------------|-------------------------------|---|---------------------------------------|-----------------------------|
| Surface Soil | TCE Contamination Area VOCs | 36 | 2/2 | 2 | 5 | 43 |
| | UST Area VOCs | 8 | 1/1 | 1 | 1 | 10 |
| | Metals | 37 | 2/2 | 2 | 0 | 39 |
| | Lead Only | 8 | 1/1 | 1 | 0 | 9 |
| | TPH-DRO | 8 | 1/1 | 1 | 0 | 9 |
| | TPH GRO | 8 | 1/1 | 1 | 0 | 9 |
| Subsurface Soil | TCE Contamination Area VOCs | 72 | 4/4 | 4 | 0 | 76 |
| | UST Area VOCs | 16 | 1/1 | 1 | 0 | 17 |
| | Lead Only | 16 | 1/1 | 1 | 0 | 17 |
| | TPH-DRO | 16 | 1/1 | 1 | 0 | 17 |
| | TPH GRO | 16 | 1/1 | 1 | 0 | 17 |

- 1 Although MS/MSDs are not typically considered field QC samples, they are included here because location determination is often established in the field. The MS/MSDs are not included in the total number of samples sent to the laboratory.
- 2 One duplicate sample will be collected for every 20 environmental samples collected.
- 3 One trip blank per VOC sample cooler per day will be collected; the quantity identified above is an estimate.

9.0 – Reference Limits and Evaluation Tables

(UFP-QAPP Manual Section 2.8.1 – Worksheet #15)

| Analyte | CAS Number | MCS (mg/kg) | MCS Reference ⁽¹⁾ | PQLG (mg/kg) | RTI | | |
|---|------------|-------------|------------------------------|--------------|-------------|-------------|------------|
| | | | | | LOQ (mg/kg) | LOD (mg/kg) | DL (mg/kg) |
| UST Area VOCs (EPA Method 8260B) | | | | | | | |
| 1,1,1,2-Tetrachloroethane | 630-20-6 | 0.004 | CMD | 0.00132 | 0.005 | 0.003 | 0.001205 |
| 1,1,1-Trichloroethane | 71-55-6 | 1.4 | MCL-SSL | 0.462 | 0.005 | 0.003 | 0.00082 |
| 1,1,2,2-Tetrachloroethane | 79-34-5 | 0.00052 | RBSSL | 0.000172 | 0.005 | 0.003 | 0.00153 |
| 1,1,2-trichloro-1,2,2-trifluoroethane (Freon 113) | 76-13-1 | 3,000 | RBSSL | 990 | 0.005 | 0.003 | 0.00152 |
| 1,1,2-Trichloroethane | 79-00-5 | 0.032 | MCL-SSL | 0.01056 | 0.005 | 0.003 | 0.001055 |
| 1,1-Dichloroethane | 75-34-3 | 0.0138 | RBSSL | 0.004554 | 0.005 | 0.003 | 0.00104 |
| 1,1-Dichloroethene | 75-35-4 | 0.05 | MCL-SSL | 0.0165 | 0.005 | 0.003 | 0.001065 |
| 1,2,3- Trichlorobenzene | 87-61-6 | 1.74 | RBSSL | 0.5742 | 0.005 | 0.003 | 0.001495 |
| 1,2,4-Trichlorobenzene | 120-82-1 | 4 | MCL-SSL | 1.32 | 0.025 | 0.003 | 0.00194 |
| 1,2-Dibromo-3-chloropropane (DBCP) | 96-12-8 | 0.00172 | MCL-SSL | 0.0005676 | 0.010 | 0.005 | 0.004275 |
| 1,2-Dibromoethane (EDB) | 106-93-4 | 0.00028 | MCL-SSL | 0.0000924 | 0.005 | 0.003 | 0.00116 |
| 1,2-Dichlorobenzene | 95-50-1 | 11.6 | MCL-SSL | 3.828 | 0.005 | 0.003 | 0.0012 |
| 1,2-Dichloroethane | 107-06-2 | 0.028 | MCL-SSL | 0.00924 | 0.005 | 0.003 | 0.00092 |
| 1,2-Dichloropropane | 78-87-5 | 0.034 | MCL-SSL | 0.01122 | 0.005 | 0.003 | 0.001355 |
| 1,3-Dichlorobenzene | 541-73-1 | 2.3 | IDEM-RDCL | 0.759 | 0.005 | 0.003 | 0.001065 |
| 1,4-Dichlorobenzene | 106-46-7 | 1.44 | MCL-SSL | 0.4752 | 0.005 | 0.003 | 0.000945 |
| 2-Butanone (MEK) | 78-93-3 | 30 | RBSSL | 9.9 | 0.005 | 0.025 | 0.003395 |
| 2-Hexanone | 591-78-6 | 0.22 | RBSSL | 0.0726 | 0.025 | 0.003 | 0.0017 |
| 4-Methyl-2-pentanone (MIBK) | 108-10-1 | 9 | RBSSL | 2.97 | 0.025 | 0.003 | 0.00131 |
| Acetone | 67-64-1 | 90 | RBSSL | 29.7 | 0.025 | 0.020 | 0.002715 |
| Acrolein | 107-02-8 | 0.00017 | RBSSL | 0.0000561 | 0.05 | 0.025 | 0.0137 |
| Benzene | 71-43-2 | 0.052 | MCL-SSL | 0.01716 | 0.003 | 0.003 | 0.000815 |

| Analyte | CAS Number | MCS (mg/kg) | MCS Reference ⁽¹⁾ | PQLG (mg/kg) | RTI | | |
|----------------------------------|-------------------|--------------|------------------------------|----------------|--------------|--------------|-----------------|
| | | | | | LOQ (mg/kg) | LOD (mg/kg) | DL (mg/kg) |
| Bromodichloromethane | 75-27-4 | 0.44 | MCL-SSL | 0.1452 | 0.005 | 0.003 | 0.001505 |
| Bromoform | 75-25-2 | 0.42 | MCL-SSL | 0.1386 | 0.005 | 0.003 | 0.00105 |
| Bromomethane | 74-83-9 | 0.044 | RBSSL | 0.01452 | 0.020 | 0.003 | 0.00807 |
| Carbon disulfide | 75-15-0 | 6.2 | RBSSL | 2.046 | 0.025 | 0.003 | 0.00227 |
| Carbon tetrachloride | 56-23-5 | 0.038 | MCL-SSL | 0.01254 | 0.005 | 0.003 | 0.000965 |
| Chlorobenzene | 108-90-7 | 1.36 | MCL-SSL | 0.4488 | 0.003 | 0.005 | 0.00086 |
| Chloroethane | 75-00-3 | 0.65 | IDEM-RDCL | 0.2145 | 0.025 | 0.003 | 0.00895 |
| Chloroform | 67-66-3 | 0.44 | MCL-SSL | 0.1452 | 0.005 | 0.003 | 0.00082 |
| Chloromethane | 74-87-3 | 0.98 | RBSSL | 0.3234 | 0.010 | 0.003 | 0.00112 |
| cis-1,2-Dichloroethene | 156-59-2 | 0.42 | MCL-SSL | 0.1386 | 0.005 | 0.003 | 0.00107 |
| cis-1,3-Dichloropropene | 10061-01-5 | 0.003 | RBSSL | 0.00099 | 0.005 | 0.003 | 0.000715 |
| Cyclohexane | 110-82-7 | 330 | IDEM-RDCL | 108.9 | 0.005 | 0.003 | NE |
| Dibromochloromethane | 124-48-1 | 0.42 | MCL-SSL | 0.1386 | 0.005 | 0.003 | 0.000835 |
| Dichlorodifluoromethane | 75-71-8 | 12.2 | RBSSL | 4.026 | 0.005 | 0.003 | 0.00098 |
| Ethylbenzene | 100-41-4 | 15.6 | MCL-SSL | 5.148 | 0.005 | 0.003 | 0.00104 |
| Isopropylbenzene | 98-82-8 | 11 | IDEM-RDCL | 3.63 | 0.005 | 0.003 | 0.00086 |
| Methyl acetate | 79-20-9 | 150 | RBSSL | 49.5 | 0.05 | 0.025 | NE |
| Methylene chloride | 75-09-2 | 0.026 | MCL-SSL | 0.00858 | 0.010 | 0.003 | 0.002175 |
| Methyl-tert-butyl ether | 1634-04-4 | 0.56 | RBSSL | 0.1848 | 0.005 | 0.003 | 0.00125 |
| Styrene | 100-42-5 | 2.2 | MCL-SSL | 0.726 | 0.005 | 0.003 | 0.000795 |
| Tetrachloroethene | 127-18-4 | 0.046 | MCL-SSL | 0.01518 | 0.005 | 0.003 | 0.00117 |
| Toluene | 108-88-3 | 13.8 | MCL-SSL | 4.554 | 0.005 | 0.003 | 0.001035 |
| trans-1,2-Dichloroethene | 156-60-5 | 0.58 | MCL-SSL | 0.1914 | 0.005 | 0.003 | 0.000805 |
| trans-1,3-Dichloropropene | 10061-02-6 | 0.003 | RBSSL | 0.00099 | 0.005 | 0.003 | 0.001015 |
| Trichloroethene | 79-01-6 | 0.036 | MCL-SSL | 0.01188 | 0.005 | 0.003 | 0.001915 |
| Trichlorofluoromethane | 75-69-4 | 16.6 | RBSSL | 5.478 | 0.005 | 0.003 | 0.000995 |
| Vinyl acetate | 108-05-4 | 1.76 | RBSSL | 0.5808 | 0.05 | 0.025 | NE |

| Analyte | CAS Number | MCS (mg/kg) | MCS Reference ⁽¹⁾ | PQLG (mg/kg) | RTI | | |
|--|------------|-------------|------------------------------|--------------|-------------|-------------|------------|
| | | | | | LOQ (mg/kg) | LOD (mg/kg) | DL (mg/kg) |
| Vinyl chloride | 75-01-4 | 0.0138 | MCL-SSL | 0.004554 | 0.004 | 0.003 | 0.00098 |
| Xylenes (total) | 1330-20-7 | 196 | MCL-SSL | 64.68 | 0.015 | 7.5 | 0.003055 |
| Total Petroleum Hydrocarbons (EPA Method 8015B) | | | | | | | |
| DRO (C8-C28) Diesel Range | NA | 230 | IDEM-RDCL | 75.9 | 1.7 | NA | 1.3 |
| GRO (C5-C12) Gasoline Range | NA | 120 | IDEM-RDCL | 39.6 | 3.0 | 1.0 | 0.631 |
| Metals Contamination Area (EPA Method 3050B, 6020A) | | | | | | | |
| Antimony | 7440-36-0 | 6.3 | Eco SSL | 2.079 | 0.25 | 0.05 | 0.0046 |
| Copper | 7440-50-8 | 253 | Eco SSL | 83.49 | 0.5 | 0.05 | 0.0076 |
| Lead | 7439-92-1 | 264 | Eco SSL | 87.12 | 0.1 | 0.05 | 0.0031 |
| Zinc | 7440-66-6 | 1716 | Eco SSL | 566.28 | 5.0 | 0.5 | 0.001 |
| TCE Contamination Area VOCs (EPA Method 8260B) | | | | | | | |
| Carbon tetrachloride | 56-23-5 | 0.038 | MCL-SSL | 0.01254 | 0.005 | 0.003 | 0.000965 |
| 1,1,2-Trichloroethane | 79-00-5 | 0.032 | MCL-SSL | 0.01056 | 0.005 | 0.003 | 0.001055 |
| cis-1,2-Dichloroethene | 156-59-2 | 0.42 | MCL-SSL | 0.1386 | 0.005 | 0.003 | 0.00107 |
| trans-1,2-Dichloroethene | 156-60-5 | 0.58 | MCL-SSL | 0.1914 | 0.005 | 0.003 | 0.000805 |
| Tetrachloroethene | 127-18-4 | 0.046 | MCL-SSL | 0.01518 | 0.005 | 0.003 | 0.00117 |
| Trichloroethene | 79-01-6 | 0.036 | MCL-SSL | 0.01188 | 0.005 | 0.003 | 0.001915 |
| Vinyl chloride | 75-01-4 | 0.0138 | MCL-SSL | 0.004554 | 0.004 | 0.003 | 0.00098 |

Notes:

CAS – Chemical Abstracts Service
 mg/kg – milligrams per kilogram
 PQLG – Project Quantitation Limit Goal
 LOQ – Limit of Quantitation
 LOD – Limit of Detection
 DL – Detection Limit
 NE- Not Evaluated

- The MCS references for surface and subsurface soil are, in order of hierarchy: MCL-SSL - USEPA Regions 3, 6, and 9 Risk-Based Soil Screening Level, Migration to Groundwater, MCL-Based Dilution Attenuation Factor (DAF) = 20 (November, 2010); RBSSL - USEPA Regions 3, 6, and 9 Risk-Based Soil Screening Level, Migration to Groundwater, DAF = 20 (November, 2010); IDEM-RDCL – IDEM Residential Default Closure Level, Migration to Groundwater

(May, 2009); Eco SSL – site-specific ecological risk-based values derived from the toxicity/bioaccumulation testing conducted by Tetra Tech (Tetra Tech, 2011c) .

Bolded rows indicate that the MCS is between the laboratory LOQ and LOD. The Project Team has agreed to accept this data for decision making if results below the LOQ are “J” qualified and the results will be discussed in the uncertainties section of the CMD Report.

Bolded and Shaded rows indicate the MCS is less than the LOD; therefore, the Project Team has agreed to report non-detected results at the LOD and any limitations on data use that result from having detection limits (i.e. data qualified U) that are greater than MCSs will be described in the CMD Report.

10.0 – Analytical SOP Reference Table

([UFP-QAPP Manual Section 3.2.1 – Worksheet #23](#))

| Lab SOP Number | Title, Revision Date, and/or Number | Definitive or Screening Data | Matrix and Analytical Group | Instrument | Organization Performing Analysis | Variance to DOD Quality Systems Manual (QSM)? (Y OR N) | Modified for Project Work? (Y/N) |
|------------------------------------|---|------------------------------|------------------------------------|---|----------------------------------|--|----------------------------------|
| RTI 3050_091410_R9 | Acid Digestion of Solid Samples for the Analysis of Total Metals (Revision 9, 09/14/10) | Definitive | Soil – Metals | NA/ Preparation | RTI | N | N |
| RTI 6020_072810_R8 | Analysis of Elements by Inductively Coupled Plasma-Mass Spectrometry (Revision 8, 07/28/10) | Definitive | Soil– Metals | Inductively Coupled Plasma - Mass Spectroscopy (ICP-MS) | RTI | N | N |
| RTI 8260B_110810_R7 | Analysis of Volatile Organic Compounds by GC/MS (Revision 7, 11/08/10) | Definitive | Soil and aqueous QC samples – VOCs | Gas Chromatograph/ Mass Spectrometer (GC/MS) | RTI | N | N |
| RTI 8015BGRO_110810_R2 | Analysis of Gasoline Range Organic Compounds, Revision 2, 11/08/10 | Definitive | Soil samples- TPH GRO | GC/Flame Ionization Detector (FID) | RTI | NA | N |
| RTI SOP- 8015BDRO_ORO_100 110_R1_1 | Analysis Of Diesel And Oil (Residual/Lube) Range Organic Compounds, Revision 1.1, 10/01/10 | Definitive | Soil samples - TPH DRO | GC/Flame Ionization Detector (FID) | RTI | NA | N |

| Lab SOP Number | Title, Revision Date, and/or Number | Definitive or Screening Data | Matrix and Analytical Group | Instrument | Organization Performing Analysis | Variance to DOD Quality Systems Manual (QSM)? (Y OR N) | Modified for Project Work? (Y/N) |
|-----------------|--|------------------------------|-------------------------------|----------------|----------------------------------|--|----------------------------------|
| 3510C_110909_R7 | Liquid-Liquid Extraction Procedure for Semi-volatile Organic Compounds, Revision 7, 11/09/09 | Definitive | Soil samples - DRO extraction | NA/ Extraction | RTI | NA | N |

NA - Not applicable

11.0 – Laboratory QC Samples Tables

(UFP-QAPP Manual Section 3.4 – Worksheet #28)

| Matrix | Soil and Aqueous QC Samples | | | | | |
|--|---|--|---|-------------------------------------|---|------------------------------|
| Analytical Group | TCE Contamination and UST Area VOCs | | | | | |
| Analytical Method / SOP Reference | SW-846 8260B RTI SOP 8260B_110810_R7 | | | | | |
| QC Sample | Frequency / Number | Method / SOP QC Acceptance Limits | Corrective Action (CA) | Person(s) Responsible for CA | DQI | MPC |
| Method Blank | One per preparatory batch of 20 or fewer samples. | All target analytes must be $\leq \frac{1}{2}$ LOQ, except common lab contaminants, which must be < LOQ. | Investigate source of contamination and rerun method blank prior to analysis of samples, if possible. Evaluate the samples and associated QC: if blank results are above LOQ, then report sample results that are <LOQ or >10X the blank concentration. Re-prepare and reanalyze blank and those samples that were >LOQ and <10X the blank. | Analyst, Supervisor | Bias/ Contamination | Same as QC Acceptance Limits |
| Laboratory Control Sample (LCS)/ Laboratory Control Sample Duplicate (LCSD) (not required) | One per preparatory batch of 20 or fewer samples. | Percent Recoveries (%Rs) must meet the DoD QSM Version 4.1 limits as per Appendix G of the DoD QSM. RPD must be $\leq 30\%$ (for LCS/LCSD, if LCSD is performed). | Correct problem, then reprepare and reanalyze the LCS and all samples in the associated preparatory batch for failed analytes, if sufficient sample material is available. Refer to DOD QSM Version 4.1 Table G-1 for number of marginal exceedences allowed. Contact Client if samples cannot be reprepared within hold time. | Analyst, Supervisor | Accuracy/ Bias Precision also, if LCSD is analyzed | Same as QC Acceptance Limits |
| MS/MSD | One per preparatory batch of 20 or fewer samples of similar matrix. | %Rs should meet the DoD QSM Version 4.1 limits as per Appendix G of the DoD QSM. The Relative Percent Difference (RPD) between MS and MSD should be $\leq 30\%$. | CA will not be taken for samples when recoveries are outside limits and surrogate and LCS criteria are met unless RPDs indicate obvious extraction/ analysis difficulties, then re-prepare and reanalyze MS/MSD. | Analyst, Supervisor | Accuracy/ Bias/ Precision | Same as QC Acceptance Limits |

| Matrix | Soil and Aqueous QC Samples | | | | | |
|--|--|---|---|-------------------------------------|-------------------------------------|---|
| Analytical Group | TCE Contamination and UST Area VOCs | | | | | |
| Analytical Method / SOP Reference | SW-846 8260B RTI SOP 8260B_110810_R7 | | | | | |
| QC Sample | Frequency / Number | Method / SOP QC Acceptance Limits | CA | Person(s) Responsible for CA | Data Quality Indicator (DQI) | Measurement Performance Criteria |
| Internal Standards (IS) | Every field sample, standard, and QC sample - three or four internal standards per sample. | Retention times must be within ± 30 seconds and the response areas must be within -50% to +100% of the initial calibration midpoint standard for each IS. | Inspect mass spectrometer and gas chromatograph for malfunctions; mandatory reanalysis of samples analyzed while system was malfunctioning. | Analyst, Supervisor | Accuracy | Same as QC Acceptance Limits |
| Surrogates | All field and QC samples – three or four surrogates per sample | %Rs must meet the DoD QSM Version 4.1 limits as per Appendix G of the DoD QSM. | If sample volume is available, then re-prepare and reanalyze sample for confirmation of matrix interference when appropriate. | Analyst, Supervisor | Accuracy/ Bias | Same as QC Acceptance Limits |
| Results between DL and LOQ | NA. | Apply "J" qualifier to results detected between DL and LOQ. | NA. | Analyst, Supervisor | Accuracy | Same as QC Acceptance Limits |

| Matrix | Soil samples | | | | | |
|---|---|---|---|--|-----------------------------------|---|
| Analytical Group | Metals (and Lead only) | | | | | |
| Analytical Method/ SOP Reference | SW-846 6020A RTI 6020_072810_R8 | | | | | |
| QC Sample | Frequency/Number | Method/SOP QC Acceptance Limits | Corrective Action | Person(s) Responsible for Corrective Action | Data Quality Indicator | Measurement Performance Criteria |
| Method Blank | One per preparatory batch of 20 or fewer samples per matrix. | No analytes $\geq \frac{1}{2}$ LOQ. | Repeat analysis. Evaluate systems for contamination sources and repeat the batch as necessary. | Analyst, Supervisor | Bias / Contamination | Same as QC Acceptance Limits. |
| LCS | One per preparatory batch of 20 or fewer samples per matrix. | %Rs must be 80-120%. | Investigate source of problem. Re-digest and reanalyze all associated samples. | Analyst, Supervisor | Accuracy / Bias | Same as QC Acceptance Limits. |
| MS/MSD | One per preparatory batch of 20 or fewer samples per matrix. | The %R should be within 80-120%, if sample < 4x spike added. RPD between MS and MSD should be $\leq 20\%$. | Dilute and re-spike/re-analyze to determine if interferences can be overcome by sample dilution. Prepare post digestion spike for analytes outside limits. Flag data as possible matrix interference. | Analyst, Supervisor | Accuracy / Bias Precision | Same as QC Acceptance Limits. |
| ICP Serial Dilution | One per preparatory batch of 20 or fewer samples per matrix. | The 5-fold dilution result must agree within $\pm 10\%$ difference of the original sample result. | Flag result or dilute and reanalyzed sample to eliminate interference. | Analyst, Supervisor | Accuracy / Bias Precision | Same as QC Acceptance Limits. |
| Post-Digestion Spike | When serial dilution test fails or when all analyte concentrations are <50 x LOD. | The %R must be within 75-125% of expected value to verify the absence of an interference. Spike addition should produce a concentration of 10-100x LOQ. | Narrate. | Analyst, Supervisor | Accuracy / Bias | Same as QC Acceptance Limits. |
| Results between the DL and LOQ | NA. | Apply "J" qualifier to results detected between DL and LOQ. | None. | Analyst, Supervisor | Accuracy | Same as QC Acceptance Limits. |

| Matrix | Soil Samples | | | | | |
|--|--|---|--|-------------------------------------|-------------------------------------|---|
| Analytical Group | TPH DRO | | | | | |
| Analytical Method / SOP Reference | SW-846 Method 8015B RTI SOP-8015BDRO_ORO_1001 10_R1_1 | | | | | |
| QC Sample | Frequency / Number | Method / SOP QC Acceptance Limits | CA | Person(s) Responsible for CA | Data Quality Indicator (DQI) | Measurement Performance Criteria |
| Method Blank | One per preparatory batch of 20 or fewer samples. | All target analytes must be $\leq \frac{1}{2}$ LOQ. | If the method blank acceptance criteria are not met, identify and correct the source of contamination, and re-prepare and reanalyze the associated samples. | Analyst, Supervisor, Data Validator | Bias/ Contamination | Same as QC Acceptance Limits |
| LCS | One per preparatory batch of 20 or fewer samples of similar matrix. | %R must be within 50-150% of true value. | If LCS acceptance limits are not met, the LCS should be reanalyzed once to confirm that the original analysis is reliable. If the results are still outside control limits, the associated sample must be re-extracted and reanalyzed. | Analyst, Supervisor, Data Validator | Accuracy/ Bias | Same as QC Acceptance Limits |
| MS/MSD | One per preparatory batch of 20 or fewer samples of similar matrix. | %Rs should be within 50-150% of true value (if sample is < 4x spike added). The RPD between MS and MSD should be $\leq 30\%$. | CA will not be taken for samples when %Rs are outside limits and surrogate and LCS criteria are met unless RPDs indicate obvious extraction/ analysis difficulties, then re-prepare and reanalyze MS/MSD. | Analyst, Supervisor, Data Validator | Accuracy/ Bias/ Precision | Same as QC Acceptance Limits |
| Surrogate | All field and QC samples - one surrogate per sample o-Terphenyl. | The %R of the surrogate must fall within 50-150% | If the surrogate %R is outside the established limits due to well-documented matrix effects, the results must be flagged and an explanation included in the report narrative. | Analyst, Supervisor, Data Validator | Accuracy | Same as QC Acceptance Limits |
| Results between DL and LOQ | NA. | Apply "J" qualifier to results detected between DL and LOQ. | NA. | Analyst, Supervisor, Data Validator | Accuracy | Same as QC Acceptance Limits |

| Matrix | Soil Samples | | | | | |
|--|---|---|--|-------------------------------------|-------------------------------------|---|
| Analytical Group | TPH GRO | | | | | |
| Analytical Method / SOP Reference | SW-846 Method 8015B RTI SOP-8015BGRO_110810_R2 | | | | | |
| QC Sample | Frequency / Number | Method / SOP QC Acceptance Limits | CA | Person(s) Responsible for CA | Data Quality Indicator (DQI) | Measurement Performance Criteria |
| Method Blank | One per preparatory batch of 20 or fewer samples. | All target analytes must be $\leq \frac{1}{2}$ LOQ. | If the method blank acceptance criteria are not met, identify and correct the source of contamination, and re-prepare and reanalyze the associated samples. | Analyst, Supervisor, Data Validator | Bias/ Contamination | Same as QC Acceptance Limits |
| LCS | One per preparatory batch of 20 or fewer samples of similar matrix. | %R must be within 50-150% of true value. | If LCS acceptance limits are not met, the LCS should be reanalyzed once to confirm that the original analysis is reliable. If the results are still outside control limits, the associated sample must be re-extracted and reanalyzed. | Analyst, Supervisor, Data Validator | Accuracy/ Bias | Same as QC Acceptance Limits |
| MS/MSD | One per preparatory batch of 20 or fewer samples of similar matrix. | %Rs should be within 50-150% of true value (if sample is < 4x spike added). The RPD between MS and MSD should be $\leq 30\%$. | CA will not be taken for samples when %Rs are outside limits and surrogate and LCS criteria are met unless RPDs indicate obvious extraction/ analysis difficulties, then re-prepare and reanalyze MS/MSD. | Analyst, Supervisor, Data Validator | Accuracy/ Bias/ Precision | Same as QC Acceptance Limits |
| Surrogate | All field and QC samples - one surrogate per sample o-Terphenyl. | The %R of the surrogate must fall within 50-150% | If the surrogate %R is outside the established limits due to well-documented matrix effects, the results must be flagged and an explanation included in the report narrative. | Analyst, Supervisor, Data Validator | Accuracy | Same as QC Acceptance Limits |
| Results between DL and LOQ | NA. | Apply "J" qualifier to results detected between DL and LOQ. | NA. | Analyst, Supervisor, Data Validator | Accuracy | Same as QC Acceptance Limits |

12.0 – Data Verification and Validation (Steps I and IIa/IIb) Process Table

([UFP-QAPP Manual Section 5.2.1](#), [UFP-QAPP Manual Section 5.2.2.](#), [Figure 37 UFP-QAPP Manual](#), [Table 9 UFP-QAPP Manual – Worksheets #34, 35, 36](#))

| Data Review Input | Description | Responsible for Verification (name, organization) | Internal/ External |
|--------------------------------|---|---|--------------------|
| Chain of Custody Forms | The Tetra Tech FOL or designee will review and sign the chain-of-custody form to verify that all samples listed are included in the shipment to the laboratory and the sample information is accurate. The forms will be signed by the sampler and a copy will be retained for the project file, the Tetra Tech PM, and the Tetra Tech Data Validators. The Tetra Tech FOL or designee will review the chain-of-custody form to verify that all samples listed in the SAP have been collected. All deviations should be documented in the report. | Sampler and FOL, Tetra Tech | Internal |
| Chain of Custody Forms | 1 - The Laboratory Sample Custodian will review the sample shipment for completeness and integrity, and sign accepting the shipment. 2- The Tetra Tech Data Validators will check that the chain-of-custody form was signed and dated by the Tetra Tech FOL or designee relinquishing the samples and also by the Laboratory Sample Custodian receiving the samples for analyses. | 1 - Laboratory Sample Custodian, RTI 2 - Data Validators, Tetra Tech | External |
| Chain of Custody Forms and SAP | Ensure that the custody and integrity of the samples was maintained from collection to analysis and the custody records are complete and any deviations are recorded. Review that the samples were shipped and stored at the required temperature and preservation conditions for chemically-preserved samples meet the requirements listed in the SAP. Ensure that the analyses were performed within the holding times listed in the SAP. | Data Validators, Tetra Tech | External |

| Data Review Input | Description | Responsible for Verification (name, organization) | Internal/ External |
|---|---|--|---------------------------|
| Sample Log Sheets, Chain of Custody Forms, SAP, and Laboratory sample login documentation | Verify that information recorded in the log sheets is accurate and complete. Verify that samples were correctly identified, that sampling location coordinates are accurate, and that documentation establishes an unbroken trail of documented chain-of-custody from sample collection to report generation. Verify that the correct sampling and analytical methods/SOPs were applied. Verify that the sampling plan was implemented and carried out as written and that any deviations are documented. Document any discrepancies in the final report. | PM, FOL, or designee, Tetra Tech | Internal |
| SAP, Analytical SOPs, and Analytical Data Packages | Ensure that all laboratory SOPs were followed. Verify that the correct analytical methods/SOPs were applied. Establish that all method QC samples were analyzed and in control as listed in the analytical SOPs. If method QA is not in control, the Laboratory QAM will contact the Tetra Tech PM verbally or via e-mail for guidance prior to report preparation. | Laboratory QAM, RTI | Internal |
| SAP/ Chain-of-Custody Forms | Check that all field QC samples determined necessary were collected as required. | FOL or designee, Tetra Tech | Internal |
| Analytical Data Package | Verify all analytical data packages for completeness. The Laboratory QAM will sign the case narrative for each data package. | Laboratory QAM, RTI | Internal |
| Electronic Data Deliverables (EDDs)/ Analytical Data Packages | Check each EDD against the chain-of-custody and hard copy data package for accuracy and completeness. Compare laboratory analytical results to the electronic analytical results to verify accuracy. Evaluate sample results for laboratory contamination and qualify false detections using the laboratory method/preparation blank summaries. Qualify analyte concentrations between the DL and the LOQ as estimated. Remove extraneous laboratory qualifiers from the validation qualifier. | Data Validators, Tetra Tech | External |
| Analytical Data Package | Verify each data package for completeness. Request missing information from the Laboratory PM. | Data Validators, Tetra Tech | External |

| Data Review Input | Description | Responsible for Verification (name, organization) | Internal/ External |
|-------------------------------------|---|--|---------------------------|
| SAP/ Laboratory Data Packages/ EDDs | Ensure that the laboratory QC samples were analyzed and that the MPCs listed in were met for all field samples and QC analyses. Check that specified field QC samples were collected and analyzed and that the analytical QC criteria set up for this project were met. | Data Validators, Tetra Tech | External |
| SAP/ Laboratory Data Packages/ EDDs | Check the field sampling precision by calculating RPDs for field duplicate samples. Check laboratory precision by reviewing the RPD or percent difference values from laboratory duplicate analyses; MS/MSDs; and LCS/LCSD, if available. Ensure compliance with the methods and project MPCs accuracy goals listed in the SAP. | Data Validators, Tetra Tech | External |
| SAP/ Laboratory Data Packages/ EDDs | Check that the laboratory recorded the temperature at sample receipt and the pH of samples preserved with acid or base to ensure sample integrity from sample collection to analysis. | Data Validators, Tetra Tech | External |
| SAP/ Laboratory Data Packages/ EDDs | Review the chain-of-custody forms generated in the field to ensure that the required analytical samples have been collected, appropriate sample identifications have been used, and correct analytical methods have been applied. The Tetra Tech Data Validator will verify that elements of the data package required for validation are present, and if not, the laboratory will be contacted and the missing information will be requested. Check that all data have been transferred correctly and completely to the Tt SQL database. | Data Validators, Tetra Tech | External |
| SAP/ Laboratory Data Packages/ EDDs | Ensure that the project LOQs listed in SAP were achieved. | Data Validators, Tetra Tech | External |

| Data Review Input | Description | Responsible for Verification (name, organization) | Internal/ External |
|---|--|--|---------------------------|
| SAP/ Laboratory Data Packages/ EDDs | Discuss the impact on DLs that are elevated because of matrix interferences. Be especially cognizant of and evaluate the impact of sample dilutions on low-concentration analytes when the dilution was performed because of the high concentration of one or more other contaminants. Document this usability issue and inform the Tetra Tech PM. Review and add PALs to the laboratory EDDs. Flag samples and notify the Tetra Tech PM of samples that exceed PALs listed in SAP. | Data Validators, Tetra Tech | External |
| SAP/ Laboratory Data Packages/ EDDs | Ensure that all QC samples specified in the SAP were collected and analyzed and that the associated results were within prescribed SAP acceptance limits. Ensure that QC samples and standards prescribed in analytical SOPs were analyzed and within the prescribed control limits. If any significant QC deviations occur, the Laboratory QAM shall have contacted the Tetra Tech PM. | Data Validators, Tetra Tech | External |
| SAP/ Laboratory Data Packages/ EDDs | Summarize deviations from methods, procedures, or contracts in the Data Validation Report. Determine the impact of any deviation from sampling or analytical methods and SOPs requirements and matrix interferences effect on the analytical results. Qualify data results based on method or QC deviation and explain all the data qualifications. Print a copy of qualified data stored the project database to depict data qualifiers and data qualifier codes that summarize the reason for data qualifications. Determine if the data met the MPCs and determine the impact of any deviations on the technical usability of the data. | Data Validators, Tetra Tech | External |
| Surface and Subsurface Soil - TCE Contamination and UST Area VOCs and TPH DRO | Validation will be performed using criteria for SW-846 Methods 8260B and 8015B listed in this SAP and the current DoD QSM. The logic outlined in USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review USEPA-540/R-99-008, (USEPA, October 1999) will be used to apply qualifiers to data to the extent possible. | Data Validators, Tetra Tech | External |

| Data Review Input | Description | Responsible for Verification (name, organization) | Internal/ External |
|---|---|--|---------------------------|
| Surface and Subsurface Soil – Metals (and Lead Only) | Validation will be performed using criteria for SW-846 Method 6020A listed in this SAP and the current DoD QSM. The logic outlined in USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review (USEPA, October 2004) will be used to apply qualifiers to data to the extent possible. | Data Validators, Tetra Tech | External |

REFERENCES


IDEM (Indiana Department of Environmental Management) 2009. Technical Guidance, Appendix I, equations A 1-5 and A 1-6 on page A.1-38, January 31, 2006 (revise May 1, 2009).


IDQTF (Interagency Data Quality Task Force), 2005. Uniform Federal Policy for Quality Assurance Project Plans. Evaluating, Assessing, and Documenting Environmental Data Collection and Use Programs, Parts 1, 2A, 2B, and 2C. Final, Version 1. March.

Tetra Tech (Tetra Tech NUS, Inc.), 2010. Draft Sampling and Analysis Plan (Field Sampling Plan and Quality Assurance Project Plan), SWMU 16 Cast High Explosives Fill/Building 146 Incinerator Toxicity Testing, Naval Support Activity Crane, Crane, Indiana. April.

Tetra Tech, 2011a. Resource Conservation and Recovery Act Facility Investigation Report for Cast High Explosives Fill/B146 Incinerator (SWMU 16), Naval Surface Warfare Center Crane, Crane, Indiana. March.

Tetra Tech, 2011c. Resource Conservation and Recovery Act Facility Investigation Report for Cast High Explosives Fill/B146 Incinerator (SWMU 16) Draft Final Technical Memorandum, Ecological Media Cleanup Goals, Surface Soil, SWMU 16, Naval Surface Warfare Center Crane, Crane, Indiana. April.





Legend

SWMU 16 Boundary

UST To Be Removed

Sump Location

Building

Demolished Building

Road

Railroad

Wall

Fence Line

Stream

Topographic Contour

| | |
|------------|----------|
| DRAWN BY | DATE |
| J. ENGLISH | 04/15/11 |
| CHECKED BY | DATE |
| J. DUCAR | 05/02/11 |
| REVISED BY | DATE |
| T. WHEATON | 05/02/11 |
| SCALE | |
| AS NOTED | |


SITE MAP



SWMU 16 - CAST HIGH EXPLOSIVES FILL / B146 INCINERATOR

NSA CRANE

CRANE, INDIANA

| | |
|-----------------|------|
| CONTRACT NUMBER | |
| CTO 277 | |
| APPROVED BY | DATE |
| APPROVED BY | DATE |
| FIGURE NO. | REV |
| FIGURE 4-2 | 0 |





| | |
|------------|----------|
| DRAWN BY | DATE |
| M. MAGUIRE | 03/30/11 |
| CHECKED BY | DATE |
| J. DUCAR | 05/02/11 |
| REVISED BY | DATE |
| T. WHEATON | 05/02/11 |

SCALE
AS NOTED



TCE AREA OF CONCERN
SWMU 16 CAST HIGH EXPLOSIVES FILL /
BLDG 146 INCINERATOR
NSA CRANE
CRANE, INDIANA

CONTRACT NUMBER

CTO NUMBER

CTO 277

APPROVED BY

DATE

APPROVED BY


DATE


FIGURE NO.


FIGURE 4-4

REV

0



| | | | | | | | |
|---|--|--|--|--------------------------|--|----------------------------|--|
|  | | ANTIMONY CONCENTRATIONS IN SOIL SWMU 16 - HIGH CAST EXPLOSIVES FILL / B146 INCINERATOR NSA CRANE CRANE, INDIANA | | | | CONTRACT NUMBER CTO 277 | |
| DRAWN BY T. WHEATON | | DATE 02/21/11 | | APPROVED BY _____ | | DATE _____ | |
| CHECKED BY J. DUCAR | | DATE 05/02/11 | | APPROVED BY _____ | | DATE _____ | |
| REVISED BY _____ | | DATE _____ | | FIGURE NO. FIGURE 4-5 | | REV 0 | |
| SCALE AS NOTED | | | | | | | |



Notes:
1) Surface soil MCS is 253 mg/kg.
2) Soil concentrations are in mg/kg.
3) For all SB locations, top line is the surface soil concentration, following line(s) are subsurface soil concentrations.

Legend

- Soil Sample with MCS Exceedance
- Soil Sample with No MCS Exceedance
- Sump Location
- SWMU Boundary
- Building
- Railroad
- Road
- Stream
- 50-ft Topographic Contour

MCS Ecological Media Cleanup Standards

16SB### Soil Sample Location ID

(0 - 2) Sample Depth


/---/ Not Sampled at Corresponding Depth


U Not Detected


J Estimated Value


REFUSAL Sample Could Not Be Collected Due To Geological Factors


| | | | | | | | | | |
|------------------------|--|------------------|---|--|--|--|--|--|--|
| DRAWN BY T. WHEATON | | DATE 02/21/11 |  | COPPER CONCENTRATIONS IN SOIL | | | | | |
| CHECKED BY J. DUCAR | | DATE 05/02/11 | | SWMU 16 - HIGH CAST EXPLOSIVES FILL / B146 INCINERATOR | | | | | |
| REVISED BY | | DATE | | NSA CRANE | | | | | |
| | | | | CRANE, INDIANA | | | | | |
| SCALE AS NOTED | | | FIGURE NO. FIGURE 4-6 | | | | | | |
| | | | REV 0 | | | | | | |
| | | | CONTRACT NUMBER CTO 277 | | | | | | |




| | | | | | | | |
|------------------------|--|------------------|---|--|----------|--|--|
| DRAWN BY T. WHEATON | | DATE 02/21/11 |  | ZINC CONCENTRATIONS IN SOIL | | | |
| CHECKED BY J. DUCAR | | DATE 05/03/11 | | SWMU 16 - HIGH CAST EXPLOSIVES FILL / B146 INCINERATOR | | | |
| REVISED BY | | DATE | | NSA CRANE | | | |
| | | | | CRANE, INDIANA | | | |
| SCALE AS NOTED | | | FIGURE NO. | | REV 0 | | |
| | | | FIGURE 4-8 | | | | |









APPENDIX A

SITE-SPECIFIC FIELD STANDARD OPERATING PROCEDURES

STANDARD OPERATING PROCEDURE

SOP-01

SAMPLE LABELING

1.0 PURPOSE

This Standard Operating Procedure (SOP) describes the procedures to be used for labeling sample containers. Sample labels are used to document the sample identification number (ID), date, time, analysis to be performed, preservative, matrix, sampler, and the analytical laboratory. A sample label will be attached to each sample container.

2.0 REQUIRED FIELD FORMS AND EQUIPMENT

Writing utensil (preferably black pen with indelible ink)

Disposable medical-grade gloves (e.g. latex, nitrile)

Sample log sheets

Required sample containers: All sample containers for analysis by fix-based laboratories will be supplied and deemed certified-clean by the laboratory.

Sample labels

Chain-of-custody records

Sealable polyethylene bags

Heavy-duty cooler

Ice

3.0 PROCEDURES

3.1 The following information will be electronically printed on each sample label prior to mobilizing for field activities. Additional "generic" labels will also be printed prior to mobilization to be used for field QC and backups.

- Project Number
- Sample Location ID
- Contract Task Order Number (CTO F277)
- Sample ID

- Sample Matrix
- Preservative
- Analysis to be Performed
- Laboratory Name

- 3.2 Select the container(s) that are appropriate for a given sample. Select the sample-specific ID label(s), complete date, time, and sampler name, and affix to the sample container(s).
- 3.3 Fill the appropriate containers with sample material. Securely close the container lids without overtightening.
- 3.4 Place the sample container in a sealable polyethylene bag and place in a cooler containing ice.

Example of a sample label is attached at the end of this SOP.

4.0 ATTACHMENTS

1. Sample Label

ATTACHMENT 1 SAMPLE LABEL

| | | |
|--|-------|------------|
| Tetra Tech NUS, Inc. 661 Andersen Drive Pittsburgh, 15220 (412)921-7090 | | Project: |
| | | Location: |
| | | CTO: |
| Sample No: | | Matrix: |
| Date: | Time: | Preserve: |
| Analysis: | | |
| Sampled by: | | Laboratory |

STANDARD OPERATING PROCEDURE

SOP-02

SAMPLE IDENTIFICATION NOMENCLATURE

1.0 PURPOSE

The purpose of this Standard Operating Procedure (SOP) is to establish a consistent sample nomenclature system that will facilitate subsequent data management at the Naval Support Activity (NSA) Crane. The sample nomenclature system has been devised such that the following objectives can be attained.

- Sorting of data by site, location, or matrix
- Maintenance of consistency (field, laboratory, and database sample numbers)
- Accommodation of all project-specific requirements
- Accommodation of laboratory sample number length constraints
- Ease of sample identification

The NSA Crane Environmental Protection Department must approve any deviations from this procedure.

2.0 REQUIRED FIELD FORMS AND EQUIPMENT

Writing utensil (preferably black pen with indelible ink)

Sample tags

Sample container labels

3.0 SAMPLE IDENTIFICATION NOMENCLATURE

3.1 Environmental Samples

All environmental samples will be properly labeled with a sample label affixed to the sample container. Each sample will be assigned a unique sample tracking number.

3.1.1 Environmental Sample Numbering Scheme

The sample tracking number will consist of a four- or five-segment alpha-numeric code that identifies the sample's associated Solid Waste Management Unit (SWMU) number, SWMU; sample type, location, and

for soil samples, where applicable, sample depth. For soil samples, the final four tracking numbers will identify the depth in units of feet below ground surface (bgs) at which the sample was collected (rounded to the nearest foot).

The alphanumeric coding to be used is explained in the following diagram and subsequent definitions:

| NN | AA | NNN (-F) | NNNN (Soils) |
|-------------|-----------|------------------------|--|
| SWMU Number | Matrix | Sample Location Number | Sequential depth interval from freshly exposed surface |

Character Type:

A = Alpha
 N = Numeric

SWMU Number (NN):

16 = SWMU 16

Matrix Code (AA):

SS = Surface Soil Sample
 SB = Subsurface Soil Sample

Location Number (NNN):

The sample location number is the soil sample location. The location number for each sample is listed on the figures and tables in the site-specific work plan.

Depth Interval (NNNN):

This code section will be used for soil samples. The depth code is used to note the depth below ground surface (bgs) at which a soil sample is collected. The first two numbers of the four-number code specify the top interval, and the third and fourth numbers specify the bottom interval of the sample depth. The depths will be noted in whole numbers only; further detail, if needed, will be recorded on the sample log sheet, boring log, logbook, etc.

Depth (for soil, in feet bgs)

0002 = soil collected from 0 to 2 feet bgs

0204 = soil collected from 2 to 4 feet bgs

0810 = soil collected from 8 to 10 feet bgs

3.1.2 Examples of Sample Nomenclature

A soil sample collected from soil boring location 003 at SWMU 16, at a depth of 0- to 2-feet bgs would be labeled as "16SB0030002".

3.2 Field Quality Assurance/Quality Control (QA/QC) Sample Nomenclature

Field QA/QC samples are described in the UFP-SAP. They will be designated using a different coding system than the one used for regular field samples.

3.2.1 QC Sample Numbering

The QC code will consist of a four-segment alpha-numeric code that identifies the SWMU number, sample QC type, the date the sample was collected, and the number of this type of QC sample collected on that date.

| NN | AA | NNNNNN | NN |
|----------------|-----------|---------------|------------------------------|
| SWMU Number | QC Type | Date | Sequence Number (per day) |

The QC types are identified as:

TB = Trip Blank

3.2.2 Examples of Field QA/QC Sample Nomenclature

The first trip blank associated with samples collected on June 6, 2011 would be designated as "16TB06061101".

STANDARD OPERATING PROCEDURE

SOP-03

SAMPLE CUSTODY AND DOCUMENTATION OF FIELD ACTIVITIES

1.0 PURPOSE

This Standard Operating Procedure (SOP) establishes the procedures for sample custody and documentation of field sampling and field analyses activities.

2.0 REQUIRED FIELD FORMS AND EQUIPMENT

The following logbooks, forms, labels, and equipment are required.

Writing utensil (preferably black pen with indelible ink)

Site logbook

Field logbook

Sample label

Chain-of-Custody Form

Custody seals

Equipment calibration log

Soil Boring Log

Soil and Sediment Sample Log Sheet

3.0 PROCEDURES

This section describes custody and documentation procedures. All entries made into the logbooks, custody documents, logs, and log sheets described in this SOP must be made in indelible ink (black is preferred). No erasures are permitted. If an incorrect entry is made, the entry will be crossed out with a single strike mark, initialed, and dated.

3.1 Site Logbook

The site logbook is a hard-bound, paginated, controlled-distribution record book in which all major on-site activities are documented. At a minimum, the following activities and events will be recorded (daily) in the site logbook:

- All field personnel present
- Arrival/departure of site visitors
- Arrival/departure of equipment
- Start or completion of sampling activities
- Daily on-site activities performed each day
- Sample pickup information
- Health and safety issues
- Weather conditions

The site logbook is initiated at the start of the first on-site activity (e.g., site visit or initial reconnaissance survey). Entries are to be made for every day that on-site activities take place.

The following information must be recorded on the cover of each site logbook:

- Project name
- Project number
- Book number
- Start date
- End date

Information recorded daily in the site logbook need not be duplicated in other field notebooks but must summarize the contents of these other notebooks and refer to specific page locations in these notebooks for detailed information (where applicable). At the completion of each day's entries, the site logbook must be signed and dated by the Tetra Tech Field Operations Leader (FOL).

3.2 Field Logbooks

The field logbook is a separate, dedicated notebook used by field personnel to document his or her activities in the field. This notebook is hardbound and paginated. At a minimum, the following activities and events will be recorded (daily) in the field logbooks:

- Field personnel for activities in the field logbook
- Arrival/departure of site visitors
- Arrival/departure of equipment

- Start or completion of sampling activities
- Daily on-site activities performed each day
- Sample pickup information
- Health and safety issues
- Weather conditions

Entries are to be made for every day that on-site activities take place.

The following information must be recorded on the cover of each field logbook:

- Project name
- Project number
- Book number
- Start date
- End date

3.3 Sample Labels

Adhesive sample container labels must be completed and applied to every sample container. Information on the label includes the project name, location, sample number, date, time, preservative, analysis, matrix, sampler's initials, and the name of the laboratory performing the analysis. Sample labeling and nomenclature are described in SOP-01 and SOP-02, respectively.

3.4 Chain-of-Custody Form

The Chain-of-Custody Form (COC) is a multi-part form that is initiated as samples are acquired and accompanies a sample (or group of samples) as it is transferred from person to person. This form must accompany any samples collected for laboratory chemical analysis. Each COC will be uniquely numbered. A copy of a blank COC form is attached at the end of this SOP.

The FOL must include the name of the laboratory in the upper right hand corner section to ensure that the samples are forwarded to the correct location. If more than one COC is necessary for any cooler, the FOL will indicate "Page ___ of ___" on each COC. The original (top) signed copy of the COC will be placed inside a sealable polyethylene bag and taped inside the lid of the shipping cooler. Once the samples are received at the laboratory, the sample custodian checks the contents of the cooler(s) against the enclosed COC(s). Any problems are noted on the enclosed

COC Form (bottle breakage, discrepancies between the sample labels, COC form, etc.) and will be resolved through communication between the laboratory point-of-contact and the Tetra Tech Project Manager (PM). The COC form is signed and retained by the laboratory and becomes part of the sample's corresponding analytical data package.

3.5 Custody Seal

The custody seal is an adhesive-backed label and is part of the chain-of-custody process. Custody seals are used to prevent tampering with samples after they have been collected in the field and sealed in coolers for transit to the laboratory. Custody seals will be signed and dated by the samplers and affixed across the opening edges of each cooler (two seals per cooler on opposite sides) containing environmental samples. The laboratory sample custodian will examine the custody seal for evidence of tampering and will notify the Tetra Tech PM if evidence of tampering is observed.

3.6 Equipment Calibration Log

The Equipment Calibration Log is used to document calibration of measuring equipment used in the field. The Equipment Calibration Log documents that the manufacturer's instructions were followed for calibration of the equipment, including frequency and type of standard or calibration device. An Equipment Calibration Log must be maintained for each electronic measuring device requiring calibration. Entries must be made for each day the equipment is used.

3.7 Sample Log Sheets

The Soil and Sediment Sample Log Sheets and Surface Water Sample Log Sheets are used to document the sampling of soil, sediment, and surface water. Copies of the sample log sheets are attached at the end of the SOP. A sample log sheet will be prepared for each sample collected and submitted for laboratory analysis.

4.0 ATTACHMENTS

1. Chain-of-Custody Record
2. Equipment Calibration Log
3. Soil and Sediment Sample Log
4. Surface Water Sample Log

| NUMBER

PAGE ____ OF ____

[illegible]

ATTACHMENT 1
CHAIN-OF-CUSTODY RECORD

EQUIPMENT CALIBRATION LOG

PROJECT NAME : _____

INSTRUMENT NAME/MODEL: _____

SITE NAME: _____

MANUFACTURER: _____

PROJECT No.: _____

SERIAL NUMBER: _____

[illegible]

ATTACHMENT 2

EQUIPMENT CALIBRATION LOG

Page__ of __

| | |
|---|--|
| Project Site Name: _____ Project No.: _____ <input type="checkbox"/> Surface Soil <input type="checkbox"/> Subsurface Soil <input type="checkbox"/> Sediment <input type="checkbox"/> Other: _____ <input type="checkbox"/> QA Sample Type: _____ | Sample ID No.: _____ Sample Location: _____ Sampled By: _____ C.O.C. No.: _____ Type of Sample: <input type="checkbox"/> Low Concentration <input type="checkbox"/> High Concentration |
|---|--|

| GRAB SAMPLE DATA: | | | | |
|------------------------|----------------|-------|--|--|
| Date: | Depth Interval | Color | Description (Sand, Silt, Clay, Moisture, etc.) | |
| Time: | | | | |
| Method: | | | | |
| Monitor Reading (ppm): | | | | |

| COMPOSITE SAMPLE DATA: | | | | |
|-------------------------------------|------|----------------|-------|--|
| Date: | Time | Depth Interval | Color | Description (Sand, Silt, Clay, Moisture, etc.) |
| Method: | | | | |
| | | | | |
| | | | | |
| Monitor Readings (Range in ppm): | | | | |
| | | | | |
| | | | | |

| SAMPLE COLLECTION INFORMATION: | | | |
|--------------------------------|------------------------|-----------|-------|
| Analysis | Container Requirements | Collected | Other |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| OBSERVATIONS / NOTES: | MAP: |
|-----------------------|------|
| | |

| | | | |
|---|-------------------|-------------------|--|
| Circle if Applicable: | Signature(s): | | |
| <table style="width: 100%; border: none;"> <tr> <td style="width: 30%; border: 1px solid black; padding: 2px;">MS/MSD</td> <td style="border: 1px solid black; padding: 2px;">Duplicate ID No.:</td> </tr> </table> | MS/MSD | Duplicate ID No.: | |
| MS/MSD | Duplicate ID No.: | | |

| | |
|--|---|
| Project Site Name: | Sample ID No.: |
| Project No.: | Sample Location: |
| | Sampled By: |
| <input type="checkbox"/> Stream | C.O.C. No.: |
| <input type="checkbox"/> Spring | Type of Sample: |
| <input type="checkbox"/> Pond | <input type="checkbox"/> Low Concentration |
| <input type="checkbox"/> Lake | <input type="checkbox"/> High Concentration |
| <input type="checkbox"/> Other: | |
| <input type="checkbox"/> QA Sample Type: | |

SAMPLING DATA:

| Date: | Color | pH | S.C. | Temp. | Turbidity | DO | Salinity | ORP |
|---------|--------|----------|-------|-----------|-----------|------|----------|-----|
| Time: | Visual | Standard | mS/cm | Degrees C | NTU | mg/l | % | mV |
| Depth: | | | | | | | | |
| Method: | | | | | | | | |

SAMPLE COLLECTION INFORMATION:

| Analysis | Preservative | Container Requirements | Collected |
|----------|--------------|------------------------|-----------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| | |
|------------------------------|-------------|
| OBSERVATIONS / NOTES: | MAP: |
| | |

| | |
|-------------------------------|---------------|
| Circle if Applicable: | Signature(s): |
| MS/MSD Duplicate ID No.: | |
| | |

STANDARD OPERATING PROCEDURE

SOP-04

SAMPLE PRESERVATION, PACKAGING, AND SHIPPING

1.0 PURPOSE

This Standard Operating Procedure (SOP) describes the procedures for sample preservation, packaging, and shipping to be used in handling soil, sediment, and aqueous samples.

2.0 REQUIRED FIELD FORMS AND EQUIPMENT

Shipping labels

Custody seals

Chain-of-custody (COC) form(s)

Sample containers with preservatives: All sample containers for analysis by fixed-base laboratories will be supplied, with preservatives added (if required) and deemed certified clean by the laboratory.

Sample shipping containers (coolers): All sample shipping containers are supplied by the laboratory.

Packaging material: Bubble wrap, sealable polyethylene bags, strapping tape, etc.

3.0 PROCEDURES FOR SAMPLE PRESERVATION, PACKAGING, AND SHIPPING

- 3.1 The laboratory provides sample containers with preservative already included (as required) for the analytical parameter for which the sample is to be analyzed. All samples will be held, stored, and shipped at 4 degrees Celsius (°C). This will be accomplished through refrigeration (used to hold samples prior to shipment) and/or ice.
- 3.2 The sampler shall maintain custody of the samples until the samples are relinquished to another custodian or to the common carrier.
- 3.3 Check that each sample container is properly labeled, the container lid is securely fastened, and the container is sealed in a polyethylene bag.
- 3.4 If the container is glass, place the sample container into a bubble-out shipping bag and seal the bag using the self-sealing, pressure sensitive tape supplied with the bag.

- 3.5 Inspect the insulated shipping cooler. Check for any cracks, holes, broken handles, etc. If the cooler has a drain plug, make certain it is sealed shut, both inside and outside of the cooler. If the cooler is questionable for shipping, the cooler must be discarded.
- 3.6 Line the cooler with large plastic bag, and line the bottom of the cooler with a layer of bubble wrap. Place the sample containers into the shipping cooler in an upright position (containers will be upright, with the exception of any 40-milliliter vials). Continue filling the cooler with ice until the cooler is nearly full and the movement of the sample containers is limited.
- 3.7 Wrap the large plastic bag closed and secure with tape.
- 3.8 Place the original (top) signed copy of the COC form inside a sealable polyethylene bag. Tape the bag to the inside of the lid of the shipping cooler.
- 3.9 Close the cooler and seal the cooler with approximately four wraps of strapping tape at each end of the cooler. Prior to wrapping the last wrap of strapping tape, apply a signed and dated custody seal to each side of the cooler (one per side). Cover the custody seal with the last wrap of tape. This will provide a tamper evident custody seal system for the sample shipment.
- 3.10 Affix shipping labels to each of the coolers, ensuring all of the shipping information is filled in properly. Overnight (e.g., FedEx Priority Overnight) courier services will be used for all sample shipments.
- 3.11 All samples will be shipped to the laboratory no more than 72 hours after collection. Under no circumstances should sample hold times be exceeded.

STANDARD OPERATING PROCEDURE

SOP-05

BOREHOLE ADVANCEMENT AND SOIL CORING USING DIRECT-PUSH TECHNOLOGY AND HAND AUGER TECHNIQUES

1.0 PURPOSE

This Standard Operating Procedure (SOP) describes the procedures for collecting surface and subsurface soil cores from unconsolidated overburden materials using direct-push technology (DPT) and hand augering techniques at the NSA Crane facility.

2.0 REQUIRED FIELD FORMS AND EQUIPMENT

Cut-resistant non-latex Impermeable Gloves

Cotton gloves

Disposable medical-grade gloves (e.g., latex, nitrile)

Writing utensil

Boring log sheets: A copy of this form is included in SOP-06.

DPT Equipment:

DPT Probe Rig

Geoprobe® Macrocore Sampler or equivalent

Geoprobe® Sampling Kit or equivalent

Clear acetate liners: one new liner for each soil core

Hand Auger Equipment:

Stainless Steel Auger Buckets

Stainless Steel Extension Rods

Cross Handle

Required decontamination materials (see SOP-08)

Bentonite pellets

3.0 BOREHOLE ADVANCEMENT AND SOIL SAMPLING USING A DPT

DPT will be employed to collect soil cores. DPT refers to sampling tools and sensors that are driven directly into the ground without the use of conventional rotary drilling equipment. DPT typically utilizes

hydraulic pressure and/or percussion hammers to advance the sampling tools. Geoprobe® is a manufacturer of a hydraulically powered, percussion/probing machine utilizing DPT to collect subsurface environmental samples.

- 3.1 Clear the area to be sampled of any surface debris (herbaceous vegetation, twigs, rocks, litter, etc.).
- 3.2 Place a new clear acetate liner in the detachable sampling core barrel, and attach the coring device to the DPT rig.
- 3.3 Drive the sampler (lined with an acetate sleeve) into the ground to the desired depth using hydraulic pressure.
- 3.4 Retract the sampler from the borehole, and remove the acetate liner and the soil core from the sampler barrel.
- 3.5 Attach the metal trough from the sampling kit firmly to a suitable surface.
- 3.6 Place the acetate liner containing the soil core in the trough.
- 3.7 While wearing cut-resistant gloves (constructed of non-latex over cotton), cut the acetate liner through its entire length using the double-bladed knife that accompanies the Geoprobe® Sampling Kit. Then remove the strip of acetate from the trough to gain access to the collected soils.
CAUTION: Do not attempt to cut the acetate liner while holding it in your hand.
- 3.8 Log the soil core on the Boring Log Sheet (see SOP-06).
- 3.9 Place the soil sample aliquots in the appropriate containers, as described in SOP-07.
- 3.10 Repeat steps 3.2 through 3.11 for the next depth intervals.
- 3.11 Upon completion of the boring, backfill the borehole with the soil from the location. If insufficient soil is available to fill the hole to the ground surface, then bentonite pellets mixed with the soil will be used to backfill the hole. If soil materials from the boring are suspected of being contaminated, the soil boring will be backfilled with bentonite pellets up to the ground surface.

- 3.12 Decontaminate all soil sampling equipment in accordance with SOP-08 before collecting the next sample.

4.0 BOREHOLE ADVANCEMENT AND SOIL SAMPLING USING A HAND AUGER

Hand augers may be employed to collect soil cores when the area is inaccessible by the drill rig. A hand augering system generally consists of a variety of all stainless steel bucket bits (i.e. cylinders 6-1/2" long and 2-3/4", 3-1/4", and 4" in diameter), a series of extension rods (available in 2', 3', 4' and 5' lengths), a cross handle. A larger diameter bucket bit is commonly used to bore a hole to the desired sampling depth and then withdrawn. In turn, the larger diameter bit is replaced with a smaller diameter bit, lowered down the hole, and slowly turned into the soil at the completion depth or refusal. The apparatus is then withdrawn and the soil sample collected.

The hand auger can be used in a wide variety of soil conditions. It can be used to sample soil, both from the surface, or to depths in excess of 12 feet. However, the presence of rock layers and the collapse of the borehole normally contribute to its limiting factors.

- 4.1 Attach a properly decontaminated bucket bit into a clean extension rod and further attach the cross handle to the extension rod.
- 4.2 Clear the area to be sampled of any surface debris (vegetation, twigs, rocks, litter, etc.)
- 4.3 Begin augering to the desired sample depth (periodically removing accumulated soils from the bucket bit into a properly decontaminated stainless steel mixing bowl), and add additional rod extensions as necessary. Discard the top of the core (approximately 1"), which represents any loose material collected by the bucket bit before penetrating the sample material.
- 4.4 Log the soil core each time soil is placed into the mixing bowl on the Boring Log Sheet (see SOP-06). Also, note (in a field notebook or on standardized data sheets) the changes in the color, texture or odor of the soil.
- 4.5 After reaching the desired sample depth, slowly and carefully withdraw the apparatus from the borehole.
- 4.6 Utilizing a properly decontaminated stainless steel trowel or disposable trowel, remove the last of the sample material from the bucket bit and place into the properly decontaminated stainless

steel mixing bowl and thoroughly homogenize the inorganic sample material prior to filling the sample containers, as described in SOP-07.

- 4.7 Excess soil core materials will be returned to the hole and tamped. If insufficient soil is available to fill the hole to the ground surface, then bentonite pellets mixed with the soil will be used to backfill the hole.
- 4.8 Decontaminate all soil sampling equipment in accordance with SOP-08 before collecting the next sample.

STANDARD OPERATING PROCEDURE

SOP-06

SOIL SAMPLE LOGGING

1.0 PURPOSE

This Standard Operating Procedure (SOP) describes the standard procedures and technical guidance on the logging of soil samples.

2.0 FIELD FORMS AND EQUIPMENT

Knife

Ruler (marked in tenths and hundredths of feet)

Boring Log: An example of this form is attached.

Writing utensil (preferably black pen with indelible ink)

3.0 RESPONSIBILITIES

A field geologist or engineer is responsible for supervising all activities and assuring that each soil sample is properly and completely logged.

4.0 PROCEDURES FOR SAMPLE LOGGING

To maintain a consistent classification of soil, it is imperative that the field geologist understands and accurately uses the field classification system described in this SOP. This identification is based on visual examination and manual tests.

4.1 USCS Classification

Soils are to be classified according to the Unified Soil Classification System (USCS). This method of classification is detailed in Figure 1 (attached to this SOP). This method of classification identifies soil types on the basis of grain size and cohesiveness.

Fine-grained soils, or fines, are smaller than the No. 200 sieve and are of two types: silt (M) and clay (C). Some classification systems define size ranges for these soil particles, but for field classification

purposes, they are identified by their respective behaviors. Organic material (O) is a common component of soil but has no distinguishable size range; it is recognized by its composition. The careful study of the USCS will aid in developing the competence and consistency necessary for the classification of soils.

Coarse-grained soils will be divided into categories: rock fragments, sand, or gravel. The terms "sand" (S) and "gravel" (G) not only refer to the size of the soil particles but also to their depositional history. To insure accuracy in description, the term "rock fragments" will be used to indicate angular granular materials resulting from the breakup of rock. The sharp edges that are typically observed indicate little or no transport from their source area; and therefore, the term provides additional information in reconstructing the depositional environment of the soils encountered. When the term "rock fragments" is used, it will be followed by a size designation such as "(1/4-inch or 1/2-inch diameter)" or "coarse-sand size" either immediately after the entry or in the remarks column. The USCS classification would not be affected by this variation in terms.

4.2 Color

Soil colors will be described utilizing a single color descriptor preceded, when necessary, by a modifier to denote variations in shade or color mixtures. A soil could therefore be referred to as "gray" or "light gray" or "blue-gray." Because color can be utilized in correlating units between sampling locations, it is important for color descriptions to be consistent from one boring to another.

Colors must be described while the sample is still moist. Soil samples will be broken or split vertically to describe colors. Samplers tend to smear the sample surface, creating color variations between the sample interior and exterior.

The term "mottled" will be used to indicate soils irregularly marked with spots of different colors. Mottling in soils usually indicates poor aeration and lack of good drainage.

4.3 Relative Density and Consistency

To classify the relative density and/or consistency of a soil, the geologist is to first identify the soil type. Granular soils contain predominantly sands and gravels. They are non-cohesive (particles do not adhere well when compressed). Finer-grained soils (silts and clays) are cohesive (particles will adhere together when compressed).

Granular soils are given the USCS classifications GW, GP, GM, SW, SP, SM, GC, or SC (see Figure 1).

The consistency of cohesive soils is determined by performing field tests and identifying the consistency as shown in the following table.

CONSISTENCY FOR COHESIVE SOILS

| Consistency | Standard Penetration Resistance (Blows per Foot) | Unconfined Compressive Strength (Tons/Sq. Foot by pocket penetration) | Field Identification |
|--------------------|---|--|--|
| Very soft | 0 to 2 | Less than 0.25 | Easily penetrated several inches by fist. |
| Soft | 2 to 4 | 0.25 to 0.50 | Easily penetrated several inches by thumb. |
| Medium stiff | 4 to 8 | 0.50 to 1.0 | Can be penetrated several inches by thumb with moderate effort. |
| Stiff | 8 to 15 | 1.0 to 2.0 | Readily indented by thumb but penetrated only with great effort. |
| Very stiff | 15 to 30 | 2.0 to 4.0 | Readily indented by thumbnail. |
| Hard | Over 30 | More than 4.0 | Indented with difficulty by thumbnail. |

Cohesive soils are given the USCS classifications ML, MH, CL, CH, OL, or OH (see Figure 1).

The consistency of cohesive soils is determined by hand by determining the resistance to penetration by the thumb. The thumb determination methods are conducted on a selected sample of the soil, preferably the lowest 0.5-foot of the sample. The sample will be broken in half and the thumb pushed into the end of the sample to determine the consistency. Do not determine consistency by attempting to penetrate a rock fragment. If the sample is decomposed rock, it is classified as a soft decomposed rock rather than a hard soil. One of the other methods will be used in conjunction with it. The designations used to describe the consistency of cohesive soils are shown in the above-listed table.

4.4 Weight Percentages

In nature, soils are consist of particles of varying size and shape and are combinations of the various grain types. The following terms are useful in the description of soil:

| Terms of Identifying Proportion of the Component | Defining Range of Percentages by Weight |
|---|--|
| Trace | 0 - 10 percent |
| Some | 11 - 30 percent |

| | |
|---|-----------------|
| Adjective form of the soil type (e.g., sandy) | 31 - 50 percent |
|---|-----------------|

Examples:

- Silty fine sand: 50 to 69 percent fine sand, 31 to 50 percent silt.
- Medium to coarse sand, some silt: 70 to 80 percent medium to coarse sand, 11 to 30 percent silt.
- Fine sandy silt, trace clay: 50 to 68 percent silt, 31 to 49 percent fine sand, 1 to 10 percent clay.
- Clayey silt, some coarse sand: 70 to 89 percent clayey silt, 11 to 30 percent coarse sand.

4.5 Moisture

Moisture content is estimated in the field according to four categories: dry, moist, wet, and saturated. In dry soil, there appears to be little or no water. Saturated samples obviously have all the water they can hold. Moist and wet classifications are somewhat subjective and often are determined by the individual's judgment. A suggested parameter for this would be calling a soil wet if rolling it in the gloved hand or on a porous surface liberates water (i.e., dirties or muddies the surface). Whatever method is adopted for describing moisture, it is important that the method used by an individual remains consistent throughout an entire field activity.

4.6 Classification of Soil Grain Size for Chemical Analysis

To determine the gross grain size classification (e.g., clay, silt, and sand) from the USCS classification described above, the following table will be used.

| Gross Soil Grain Size Classification | USCS Abbreviation | Description |
|--------------------------------------|-------------------|--|
| Clay | CL | inorganic clays of low to medium plasticity, gravelly clays, sandy clays, silty clays, lean clays. |
| | CH | inorganic clays of high plasticity, fat clays. |
| | OH | organic clays of medium to high plasticity, organic silts. |
| Silt | ML | inorganic silts and very fine sands, rock four, silty or clayey fine sands with slight plasticity. |
| | OL | organic silts and organic silty clays of low plasticity. |
| | MH | inorganic silts, micaceous or diatomaceous fine sand or silty soils. |
| Sand | SW | well graded sands, gravelly sands, little or no fines. |
| | SP | poorly graded sands, gravelly sands, little or no fines. |
| | SM | silty sands, sand-silt mixtures. |
| | SC | clayey sands, sand-clay mixtures. |

4.7 Summary of Soil Classification

In summary, soils will be classified in a similar manner by each geologist/engineer at a project site. The hierarchy of classification is as follows:

- Density and/or consistency
- Color
- Plasticity (optional)
- Soil types
- Moisture content
- Other distinguishing features
- Grain size
- Depositional environment

5.0 ATTACHMENTS

1. Figure 1 - Unified Soil Classification System
2. Boring Log

ATTACHMENT 1

FIGURE 1 - UNIFIED SOIL CLASSIFICATION SYSTEM

| Unified Soil Classification System | | | | | |
|--|---|------------------------------|--|--|--|
| Coarse Grained Soils (more than half of soil > No. 200 sieve) | Gravels (More than half of coarse fraction > no. 4 sieve size) | | GW | Well graded gravels or gravel-sand mixtures, little or no fines | |
| | | | GP | Poorly graded gravels or gravel-sand mixtures, little or no fines | |
| | | | GM | Sandy gravels, gravel-sand-silt mixtures | |
| | | | GC | Clayey gravels, gravel-sand-silt mixtures | |
| | Sands (More than half of coarse fraction < no. 4 sieve size) | | SW | Well graded sands or gravelly sands, little or no fines | |
| | | | SP | Poorly graded sands or gravelly sands, little or no fines | |
| | | | SM | Silty sands, sand-silt mixtures | |
| | | | SC | Inorganic silts and very fine sands, rock flour, silty or clayey fine sands or clayey silts with slight plasticity | |
| | Fine Grained Soils (more than half of soil < No. 200 sieve) | Silts and Clays LL = < 50 | | ML | Inorganic silts and very fine sands, rock flour, silty fine sands or clayey silts with slight plasticity |
| | | | | CL | Inorganic clays of low to medium plasticity, gravelly clays, sandy clays, lean clays |
| | | | OL | Organic silts and organic silty clays of low plasticity | |
| Silts and Clays LL = > 50 | | | MH | Inorganic silts, micaceous or diatomaceous fine sand or silty soils, elastic silts | |
| | | CH | Inorganic silts of high plasticity, fat clays | | |
| | | OH | Organic clays of high plasticity, organic silty clays, organic silts | | |
| Highly Organic Soils | | | Pt | Peat and other highly organic soils | |

Grain Size Chart

| Classification | Range of Grain Sizes | |
|----------------------------------|--------------------------|---------------------------|
| | U.S. Standard Sieve Size | Grain Size In Millimeters |
| Boulders | Above 12" | Above 305 |
| Cobbles | 12" to 3" | 305 to 76.2 |
| Gravel coarse fine | 3" to No. 4 | 76.2 to 7.76 |
| | 3" to 3/4" | 76.2 to 4.76 |
| | 3/4" to No. 4 | 19.1 to 4.76 |
| Sand coarse medium fine | No. 4 to No. 200 | 4.76 to 0.074 |
| | No. 4 to No. 10 | 4.76 to 2.00 |
| | No. 10 to No. 40 | 2.00 to 0.420 |
| | No. 40 to No. 200 | 0.420 to 0.074 |
| Silt and Clay | Below No. 200 | Below 0.074 |

Relative Density (SPT)

| SANDS AND GRAVELS | BLOWS/FOOT |
|-------------------|------------|
| VERY LOOSE | 0 - 4 |
| LOOSE | 4 - 10 |
| MEDIUM DENSE | 10 - 30 |
| DENSE | 32 - 50 |
| VERY DENSE | OVER 50 |

Consistency (SPT)

| SILTS AND CLAYS | BLOWS/FOOT |
|-----------------|------------|
| VERY SOFT | 0 - 2 |
| SOFT | 2 - 4 |
| MEDIUM STIFF | 4 - 8 |
| STIFF | 8 - 16 |
| VERY STIFF | 16 - 22 |
| HARD | OVER 22 |

STANDARD OPERATING PROCEDURE

SOP-07

SURFACE AND SUBSURFACE SOIL SAMPLING

1.0 PURPOSE

This Standard Operating Procedure (SOP) describes the procedures to be used for surface and subsurface soil sampling using direct-push technology (DPT) or hand augers during field activities at NSA Crane SWMU 16. This procedure also describes the collection of samples for analysis of volatile organic compounds (VOCs), including total petroleum hydrocarbon (TPH)-gasoline range organics (GRO), in accordance with USEPA Method 5035A and the use of field screening [i.e., photoionization detector (PID)] to select the subsurface soil intervals for VOC sampling.

2.0 REQUIRED FIELD FORMS AND EQUIPMENT

Writing utensil (preferably black pen with indelible ink)

Disposable medical-grade gloves (i.e. latex, nitrile)

Boring log

Soil sample logsheets

Stainless-steel mixing bowls

Stainless-steel trowel or soup spoon

Terra Core® samplers

Disposable trowels

Photoionization Detector (PID) or similar

Required sample containers: All sample containers including shipping coolers for analysis by fixed-base laboratories will be supplied and certified clean by the laboratory.

Required decontamination materials

Chain-of-custody records

Required personnel protective equipment (PPE)

Wooden stakes or pin flags

Survey tape

Marking Paint

Sealable polyethylene bags

Heavy-duty cooler

Ice

Razor knife

DPT Probe Rig and sampling equipment

Sample labels

3.0 COLLECTION OF SOIL SAMPLES FOR VOLATILE ORGANIC COMPOUNDS (VOCs) USING DPT

When soil cores are collected using DPT, such as Geoprobe®, 4-foot soil intervals will be collected in clear acetate tubes, which can be extracted from the Geoprobe® macrocore upon retrieval at the surface (see SOP-08). Note: A surface soil sample is collected from the 0- to 2-foot depth. Additional subsurface soil samples each consist of 2-foot core segments. All samples collected for VOC analyses will be collected with the use of a DPT, to the extent possible. The samples must be collected as soon as possible after the macrocores have been brought to the surface. Sample collection should be completed within 3 to 5 minutes after the soil has been exposed to the atmosphere to minimize volatilization. The following presents the sample collection tasks.

- 3.1 Establish a suitable work area near the point of sample collection. Prior to sample collection, ensure all necessary equipment (e.g., PID) is operating properly and calibrated (if necessary).
- 3.2 Slit the macrocore acetate liner lengthwise with an appropriate cutting tool (e.g., razor knife), remove a section of the liner, and expose the length of the soil interval (see SOP-05). Note: the rate of macrocore collection should not proceed faster than the field samplers can process the samples in order to prevent the macrocores from being exposed to the atmosphere for a long period of time to prevent potential volatilization of the soil within the macrocore.

Scan the soil core interval with a PID, slowly moving the intake nozzle along the length of the core where the acetate liner has been slit open. Note on the boring log the range of PID readings that are detected and the specific location(s) along the sample interval where above-background readings are encountered. If elevated volatile organics are measured via the PID, collect the VOC samples from the specific interval where the highest PID reading is measured. If no above-background PID readings are measured, then the VOC sample will be collected from a specific interval where visual signs of contamination (staining, etc.) are observed. If no above-background PID reading is measured, and no discoloration or odor in the soil core indicates potential contamination, then collect the VOC sample from near the center of the core at the

bottom of the interval. The VOC sample will be collected using an appropriate sample collection device (i.e., Terra Core® sampler).

- 3.3 The 0- to 2-foot core interval will be collected as a surface soil sample. Determine where in this core interval the highest PID reading was encountered. Soil samples collected for volatile organics will be obtained directly from soil cores using Terra Core® samplers for each VOC and TPH-GRO sample.

The Terra Core® sampling method is as follows:

Step 1

Have ready a 40mL glass VOA vial containing the appropriate preservative (i.e., methanol, sodium bisulfate, or deionized water). With the plunger seated in the handle, push the Terra Core® into freshly exposed soil until the sample chamber is filled. A filled chamber will deliver approximately 5 grams of soil. Note: The ratio of soil to methanol must be 1:1; consequently, if the vials contain 5 ml of methanol, the soil aliquot must be around 5 g,

Step 2

Wipe all soil or debris from the outside of the Terra Core® sampler. The soil plug should be flush with the mouth of the sampler. Remove any excess soil that extends beyond the mouth of the sampler.

Step 3

Rotate the plunger that was seated in the handle top 90 degrees until it is aligned with the slots in the body. Place the mouth of the sampler into the 40mL VOA vial containing the appropriate preservative and extrude the sample by pushing the plunger down. Quickly place the lid back on the 40mL VOA vial. Note: When capping the 40mL VOA vial, be sure to remove any soil or debris from the top and/or threads of the vial.

In addition, each VOC soil sample will include a separate aliquot to be used for percent moisture analysis. The percent moisture sample will be collected by filling one 2 oz container with sample representing the same location where the 40 mL VOC vial sample was collected. Every effort will be made to obtain the percent moisture soil aliquot as close as possible to the location where the VOC sample aliquots were collected.

Step 4

Place the three sample vials in the sample holder that comes with the sample kit and fill in appropriate information, including sample identification, date, time, and other information on the label. Place the sample vial holders and moisture sample in a plastic bag and place the tag on the bag, identifying the sample identification and other necessary information (see SOP-01). No additional labels will be added to the pre-weighed sample vials received from the laboratory. Be sure that laboratory-provided information (i.e., vial tare weight and/or identification bar codes) are exposed and legible on the vials.

Once the samples are properly labeled and bagged, place the samples into the cooler containing ice and a trip blank. The cooler should be kept at $\leq 6^{\circ}\text{C}$ and shipped to the analytical laboratory for preservation or extraction within 48 hours. Fill in the required information on the Soil Sample Log Sheet (attached at the end of this SOP) and fill in the required information on the Chain-of-Custody (COC) Form.

4.0 COLLECTION OF NON-VOC SOIL SAMPLE ALIQUOTS USING DPT

- 4.1 After the VOC sample has been collected for the soil interval of interest (see Section 3.0 above), the remainder of the remainder of the soil interval will be composited and used to fill the sample containers. Any surface debris (e.g., herbaceous vegetation, twigs, rocks, litter, etc.) should first be removed from the top of the surface soil core. For other core intervals, the top 2 inches of each core should be discarded because it often contains material scraped from the side of the borehole and not fresh material from the bottom of the borehole.
- 4.2 Slide the remaining core material out of the acetate liner and into a clean, decontaminated stainless-steel mixing bowl. Mix the soil thoroughly with a stainless-steel spoon and remove gravel, large pebbles, and other coarse materials. Fill the required sample containers in the following order:
- Container for other organic analyses (i.e., total petroleum hydrocarbons-diesel range organics [TPH-DRO]),
 - Container for metals,
 - Container for moisture.
- 4.3 Complete all required information on the sample labels and secure the label to the sample container (see SOP-01).

4.4 Place the sample container in a ziplock plastic bag and seal closed. Place the bag in a cooler containing ice and cool to $\leq 6^{\circ}\text{C}$.

4.5 Record the required information on the Soil Sample Log Sheet and the COC Record form.

5.0 COLLECTION OF SOIL SAMPLES USING A HAND AUGER

5.1 Utilizing a properly decontaminated stainless steel trowel or disposable trowel, remove the sample material from the hand auger bucket bit, and remove gravel, large pebbles, and other coarse materials. Scan the soil core interval with a PID. Note on the boring log the range of PID readings that are detected and the specific location(s) along the sample interval where above-background readings are encountered.

5.2 If collecting VOC samples, collect the sample aliquot for VOCs directly from an open-sided hand auger bucket prior to disturbing the material, following the applicable VOC sampling procedures stated in Sections 3.0 through 3.3 above.

5.3 Collect sample aliquots for non-VOCs by sliding the remaining core material out of the hand auger bucket and into a clean, decontaminated stainless-steel mixing bowl. Mix the soil thoroughly with a stainless-steel spoon and remove gravel, large pebbles, and other coarse materials.

5.4 Fill the required sample containers in the following order:

- Container for other organic analyses (i.e., TPH-DRO)
- Container for metals

5.5 Complete all required information on the sample labels and secure the label to the sample container (see SOP-01).

5.6 Place the sample container in a ziplock plastic bag and seal closed. Place the bag in a cooler containing ice and cool to $\leq 6^{\circ}\text{C}$.

5.7 Record the required information on the Soil Sample Log Sheet and the COC Record form.

6.0 PACKAGING AND SHIPPING OF SAMPLES

Samples will be packaged and shipped according to SOP-04.

7.0 ATTACHMENTS

1. Soil and Sediment Sample Log Sheet

SOIL AND SEDIMENT SAMPLE LOG SHEET



Page ____ of ____

| | | | |
|---|--|---|--|
| Project Site Name: _____ | | Sample ID No.: _____ | |
| Project No.: _____ | | Sample Location: _____ | |
| <input type="checkbox"/> Surface Soil <input type="checkbox"/> Subsurface Soil <input type="checkbox"/> Sediment <input type="checkbox"/> Other: _____ <input type="checkbox"/> QA Sample Type: _____ | | Sampled By: _____ | |
| | | C.O.C. No.: _____ | |
| | | Type of Sample: | |
| | | <input type="checkbox"/> Low Concentration <input type="checkbox"/> High Concentration | |

| GRAB SAMPLE DATA: | | | |
|------------------------------|----------------|-------|--|
| Date: _____ | Depth Interval | Color | Description (Sand, Silt, Clay, Moisture, etc.) |
| Time: _____ | | | |
| Method: _____ | | | |
| Monitor Reading (ppm): _____ | | | |

| COMPOSITE SAMPLE DATA: | | | | |
|---|------|----------------|-------|--|
| Date: _____ | Time | Depth Interval | Color | Description (Sand, Silt, Clay, Moisture, etc.) |
| Method: _____ | | | | |
| | | | | |
| Monitor Readings (Range in ppm): _____ | | | | |
| | | | | |
| | | | | |
| | | | | |

| SAMPLE COLLECTION INFORMATION: | | | |
|--------------------------------|------------------------|-----------|-------|
| Analysis | Container Requirements | Collected | Other |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| | |
|-----------------------|------|
| OBSERVATIONS / NOTES: | MAP: |
| | |

| | | |
|-----------------------|-------------------------|---------------|
| Circle if Applicable: | | Signature(s): |
| MS/MSD | Duplicate ID No.: _____ | |
| | | |

STANDARD OPERATING PROCEDURE

SOP-08

DECONTAMINATION OF FIELD SAMPLING EQUIPMENT

1.0 PURPOSE

This Standard Operating Procedure (SOP) establishes the procedures to be followed when decontaminating non-dedicated field sampling equipment during the field investigations.

2.0 REQUIRED FIELD FORMS AND EQUIPMENT

Writing utensil (preferably black pen with indelible ink)

Non-latex rubber or plastic gloves

Cotton gloves

Field logbook

Potable water

Deionized water

Isopropanol (optional)

Liqui-Nox® or Alconox® detergent

Brushes, spray bottles, paper towels, etc.

Container to collect and transport decontamination fluids

3.0 DECONTAMINATION PROCEDURES

- 3.1 Don non-latex and/or cotton gloves and decontaminate sampling equipment (in accordance with the following steps) prior to field sampling and between samples.
- 3.2 Rinse the equipment with potable water. Rinsing may be conducted by spraying with water from a spray bottle or by dipping. Collect the potable water rinsate into a container.
- 3.3 Wash the equipment with a solution of Liqui-Nox® or Alconox® detergent. Prepare the detergent wash solution in accordance with the instructions on the detergent container. Collect the wash solution into a container. Use brushes or sprays as appropriate for the equipment. If oily residue has accumulated on the sampling equipment, remove the residue with an isopropanol wash and repeat the detergent wash.

- 3.4 Rinse the equipment with potable water. Rinsing may be conducted by spraying with water from a spray bottle or by dipping. Collect the potable water rinsate into a container.
- 3.5 Rinse the equipment with deionized water. Rinsing may be conducted by spraying with water from a spray bottle or by dipping. Collect the deionized water rinsate into a container.
- 3.6 Remove excess water by air drying and shaking or by wiping with paper towels as necessary.
- 3.7 Document decontamination by recording it in the field logbook.
- 3.8 Containerized decontamination solutions will be managed in accordance with the procedures described in SOP-10.

STANDARD OPERATING PROCEDURE

SOP-09

GLOBAL POSITIONING SYSTEM

1.0 PURPOSE

The purpose of this Standard Operating Procedure (SOP) is to provide the field personnel with basic instructions for operating a handheld Global Positioning System (GPS) unit allowing them to set GPS parameters in the receiver, record GPS positions on the field device, and update existing Geographic Information System (GIS) data. This SOP is specific to GIS quality data collection for Trimble®-specific hardware and software.

If possible, the Trimble® GeoXM™ or GeoXH™ operators manual should be downloaded onto the operator's personal computer for reference before or while in the field. The manual can be downloaded at <http://trl.trimble.com/docushare/dsweb/Get/Document-311749/TerraSyncReferenceManual.pdf>

Unless the operator is proficient in the setup and operation of the GPS unit, the Project Manager (or designee) should have the GPS unit shipped to the project-specific contact listed below in the Pittsburgh, Pennsylvania, office at least five working days prior to field mobilization so project-specific shape files, data points, background images, and correct coordinate systems can be uploaded into the unit.

Tetra Tech NUS, Inc.
Attn: John Wright
661 Anderson Drive, Bldg #7
Pittsburgh, PA 15220

2.0 REQUIRED EQUIPMENT

The following hardware and software should be utilized for locating and establishing GPS points in the field:

2.1 Required GPS Hardware

- Hand-held GPS unit capable of sub-meter accuracy (i.e. Trimble® GeoXM™ or Trimble® GeoXH™). This includes the docking cradle, A/C adapter, stylus, and USB cable for data transfer.

Optional Accessories:

- External antenna
- Range pole
- Hardware clamp (for mounting GPS unit to range pole)
- GeoBeacon
- Writing utensil (preferably black pen with indelible ink)
- Non-metallic pin flags for temporary marking of positions

2.2 Required GPS Software

The following software is required to transfer data from the handheld GPS unit to a personal computer:

- Trimble® TerraSync version 2.6 or later (pre-loaded onto GPS unit from vendor)
- Microsoft® ActiveSync® version 4.5 or later. Download to personal computer from:
<http://www.microsoft.com/windowsmobile/en-us/downloads/microsoft/activesync-download.mspx>
- Trimble® Data Transfer Utility (freeware version 2.1 or later). Download to personal computer from:
<http://www.trimble.com/datatransfer.shtml>

3.0 START-UP PROCEDURES

Prior to utilizing the GPS in the field, ensure the unit is fully charged. The unit may come charged from the vendor, but an overnight charge is recommended prior to fieldwork.

The Geo-series GPS units require a docking cradle for both charging and data transfer. The Geo-series GPS unit is docked in the cradle by first inserting the domed end in the top of the cradle, then gently seating the contact end into the latch. The power charger is then connected to the cradle at the back end using the twist-lock connector. Attach a USB cable as needed between the cradle (B end) and the laptop/PC (A end).

It is recommended that the user also be familiar and check various Windows Mobile settings. One critical setting is the Power Options. The backlight should be set as needed to conserve power when not in use.

Start Up:

- 1) Power on the GPS unit by pushing the small green button located on the lower right front of the unit.
- 2) Utilizing the stylus that came with the GPS unit, launch **TerraSync** from the Windows Operating System by tapping on the start icon located in the upper left hand corner of the screen and then tap on **TerraSync** from the drop-down list.
- 3) If the unit does not default to the Setup screen, tap the Main Menu (uppermost left tab, just below the Windows icon) and select Setup.
- 4) If the unit was previously shipped to the Pittsburgh office for setup, you can skip directly to Section 4.0. However, to confirm or change settings, continue on to Section 3.1.

3.1 Confirm Setup Settings

Use the Setup section to confirm the TerraSync software settings. To open the Setup section, tap the Main Menu and select Setup.

- 1) Coordinate System
 - a. Tap on the Coordinate System.
 - b. Verify the project specs are correct for your specific project by scrolling through the various settings. Edit as needed and then tap OK; otherwise, tap Cancel to return to Setup Menu.
Note: It is always best to utilize the Cancel tab rather than the OK tab if no changes are made since configurations are easily changed by mistake.
 - c. Tap on the Units.
 - d. Verify the user preferences are correct for your specific project by scrolling through the various settings. Edit as needed and then tap OK; otherwise, tap Cancel to return to Setup Menu.
 - e. Tap Real-time Settings.
 - f. Verify the Real-time Settings are correct for your specific project by scrolling through the various settings. Edit as needed and then tap OK; otherwise, tap Cancel to return to Setup Menu.
 - g. The GPS unit is now configured correctly for your specific project.

4.0 ANTENNA CONNECTION

- 1) If a connection has been properly made with the internal antenna, a satellite icon along with the number of usable satellites will appear at the top of the screen next to the battery icon. If no connection is made (e.g.: no satellite icon), tap on the GPS tab to connect antenna.
- 2) At this point the GPS unit is ready to begin collecting data.

5.0 COLLECTING NEW DATA IN THE FIELD

- 1) From the Main Menu select Data.
- 2) From the Sub Menu (located below the Data tab) select New which will bring up the New Data File menu.
- 3) An auto-generated filename appears and should be edited for your specific project. If the integral keyboard does not appear, tap the small keyboard icon at the bottom of the screen.
- 4) After entering the file name, tap Create to create the new file.
- 5) Confirm antenna height if screen appears. Antenna height is the height that the GPS unit will be held from the ground surface (Typically 3 to 4 feet).
- 6) The Choose Feature screen appears.

5.1 Collecting Features

- 1) If not already open, the Collect Feature screen can be opened by tapping the Main Menu and selecting Data. The Sub Menu should default to Collect.
- 2) **Do not begin the data logging process until you are at the specific location for which you intend to log the data.**
- 3) A known reference or two should be shot at the beginning and at the end of each day in which the GPS unit is being used. This allows for greater accuracy during post-processing of the data.
- 4) Upon arriving at the specific location, tap on Point_generic as the Feature Name.
- 5) Tap Create to begin data logging.
- 6) In the Comment Box enter sample ID or location-specific information.
- 7) Data logging can be confirmed by viewing the writing pencil icon in the upper part of the screen. Also, the logging counter will begin. As a Rule of Thumb, accumulate a minimum of 20 readings on the counter, per point, as indicated by the logging counter before saving the GPS data.
- 8) Once the counter has reached a minimum number of counts (i.e. 20), tap on OK to save the data point to the GPS unit. Confirm the feature. All data points are automatically saved within the GPS unit.
- 9) Repeat steps 2 through 8, giving each data point a unique name or number.

Note: If the small satellite icon or the pencil icon is blinking, this is an indication the GPS unit is not collecting data. A possible problem may be too few satellites. While still in data collection mode, tap on Main Menu in upper left hand corner of the screen and select Status. Skyplot will display as the default showing the number of available satellites. To increase productivity (number of usable satellites) use the stylus to move the pointer on the productivity and precision line to the left. This will decrease precision, but increase productivity. The precision and productivity of the GPS unit can be adjusted as the number of usable satellites changes throughout the day. To determine if GPS is correctly recording data, see Section 5.2.

5.2 Viewing Data or Entering Additional Data Points to the Current File

- 1) To view the stored data points in the current file, tap on the Main Menu and select Map. Stored data points for that particular file will appear. Use the +/- and <-/> icons in lower left hand corner of screen to zoom in/out and to manipulate current view.
- 2) To return to data collection, tap on the Main Menu and select Data. You are now ready to continue to collect additional data points.

5.3 Viewing Data or Entering Data Points from an Existing File

- 1) To view data points from a previous file, tap on Main Menu and select Data, then select File Manager from the Sub Menu.
- 4) Highlight the file you want to view and select Map from the Main Menu.
- 5) To add data points to this file, tap on Main Menu and select Data. Continue to collect additional data points.

6.0 NAVIGATION

This section provides instructions on navigating to saved data points in an existing file within the GPS unit.

- 1) From the Main Menu select Map.
- 2) Using the Select tool, pick the point on the map to where you want to navigate.
- 3) The location you select will have a box placed around the point.
- 4) From the Options menu, choose the Set Nav Target (aka set navigation target).
- 5) The location will now have double blue flags indicating this point is you navigation target.
- 6) From the Main Menu select Navigation.

- 7) The dial and data on this page will indicate what distance and direction you need to travel to reach the desired target.
- 8) Follow the navigation guide until you reach the point you select.
- 9) Repeat as needed for any map point by going back to Step 1.

7.0 PULLING IN A BACKGROUND FILE

This section provides instructions on pulling in a pre-loaded background file. These files are helpful in visualizing your current location.

- 1) From the Main Menu select Map, then tap on Layers, select the background file from drop down list.
- 2) Select the project-specific background file from the list of available files.
- 3) Once the selected background file appears, the operator can manipulate the screen utilizing the +/- and <-/-> functions at the bottom of the screen.
- 4) In operating mode, the operator's location will show up on the background file as a floating "X".

8.0 DATA TRANSFER

This section provides instructions on how to transfer stored data on the handheld GPS unit to a personal computer. Prior to transferring data from the GPS unit to a computer, Microsoft ActiveSync and Trimble Data Transfer Utility software must be downloaded to the computer from the links provided in Section 2.2 (Required GPS Software). If a leased computer is utilized in which the operator cannot download files, see the Note at the end of Section 8.0.

- 1) See Attachment A at the end of this SOP for instructions on how to transfer data from the GPS to a personal computer.

Note: If you are unable to properly transfer data from the GPS unit to a personal computer, the unit should be shipped to the project-specific contact listed in Section 1.0 where the data will be transferred and the GPS unit then shipped back to the vendor.

9.0 SHUTTING DOWN

This section provides instruction for properly shutting down the GPS unit.

- 1) When shutting down the GPS unit for the day, first click on the "X" in the upper right hand corner.

- 2) You will be prompted to ensure you want to exit TerraSync. Select Yes.
- 3) Power off the GPS unit by pushing the small green button located on the bottom face of the unit.
- 4) Place the GPS unit in its cradle to recharge the battery overnight. Ensure the green charge light is visible on the charging cradle.

ATTACHMENT A

How to Transfer Trimble GPS Data between Data Collector and PC

original 11/21/06 (5/1/08 update) – John Wright

Remember – Coordinate System, Datum, and Units are critical!!!

Trimble Data Collection Devices:

Standard rental systems include the Trimble® ProXR/XRS backpack and the newer handheld GeoXT™ or GeoXH™ units. Some of the older backpack system may come with either a RECON “PDA-style” or a TSCe or TSC1 alpha-numeric style data collector.

The software on all of the above units should be Trimble® TerraSync (v 2.53 or higher – current version is 3.20) and to the user should basically look and function similar. The newer units and software versions (which should always be requested when renting) include enhancements for data processing, real-time display functions, and other features.

Data Transfer:

Trimble provides a free transfer utility program to aid in the transfer of GIS and field data. The Data Transfer Utility is a standalone program that will run on a standard office PC or laptop.

To connect a field data collector such as a RECON, GeoXM, GeoXT, GeoXH, or ProXH, you must first have Microsoft® ActiveSync® installed to allow the PC and the data collector to talk to one another. A standard USB cable is also needed to connect the two devices.

A CD or USB drive is provided with the data collector for use in data transfer. If needed, these programs are also available without charge via the web at:

- **Trimble Data Transfer Utility** (v 1.38) program to download the RECON or GeoXH field data to your PC: <http://www.trimble.com/datatransfer.shtml>

- **ActiveSync** from Microsoft to connect the data collector to the PC. The latest version (v4.5) can be found at: <http://www.microsoft.com/windowsmobile/en-us/downloads/microsoft/activesync-download.msp>

(see page 2 for data transfer instructions)

To Transfer Data Collected in the Field:

- Install the Data Transfer and ActiveSync software installed on your PC
- Connect the RECON or GeoXH to your PC via an A/B USB cable (blade end and square end type "HP printer" style)
- ActiveSync should auto-detect the connection and recognize the data collector
- Make sure the data file desired is CLOSED in TerraSync prior to transfer
- Connect via ActiveSync as a guest (not a partnership)
- Run the Trimble Data Transfer Utility program on your PC
- Select "**GIS Datalogger on Windows CE**" or similar selection
- Hit the green connect icon to the right - the far right area should say "**Connected to**" if successful
- Select the "**Receive**" data tab (under device)
- Select "**Data**" from file types on the right
- Find the file(s) needed for data transfer. You can sort the data files by clicking on the date/time header
- Select or browse to a C-drive folder you can put this file for emailing
- When the file appears on the list, hit the "**Transfer All**"
- Go to your Outlook or other email, send a message to: John.Wright@tetrattech.com (or GIS department)
- Attach the file(s) you downloaded from your C-drive. For each TerraSync data file created you should have a packet of multiple data files. All need to be sent as a group – make sure you attach all files (the number of files may vary – examples include: ssf, obx, obs, gix, giw, gis, gip, gic, dd, and car)

To Transfer GIS Data from PC to the Field Device (must be converted in Pathfinder Office):

- Obtain GIS file(s) desired from GIS Department and have converted to Trimble extension
- Contact John Wright (John.Wright@tetrattech.com) if needed for file conversion and upload support
- The GIS file(s) can be quickly converted if requested and sent back to the field user in the needed "Trimble xxx.imp" extension via email – then quickly downloaded from Outlook to your PC for transfer
- Install the Data Transfer and ActiveSync software installed on your PC
- Connect the RECON or GeoXH to your PC via an A/B USB cable (blade end and square end type "HP printer" style)
- ActiveSync should auto-detect the connection and recognize the data collector
- Connect via ActiveSync as a guest (not a partnership)
- Run the Trimble Data Transfer Utility program on your PC
- Select "**GIS Datalogger on Windows CE**" or similar selection
- Hit the green connect icon to the right - the far right area should say "**Connected to**" if successful
- Select the "**Send**" data tab (under device)
- Select "**Data**" from file types on the right (you can also send background files)
- Browse to the location of the data on your PC (obtain the file from Pathfinder Office or from the person who converted the data for field use)
- Select the options as appropriate for the name and location of the data file to go on the data collector (usually you can choose main memory or a data storage card)
- When the file(s) appears on the list, hit the "**Transfer All**"
- Run TerraSync on the field device and open the existing data files. Your transferred file should appear (make sure you have selected Main Memory, Default, or Storage Card as appropriate)

STANDARD OPERATING PROCEDURE

SOP-10

MANAGEMENT OF INVESTIGATION-DERIVED WASTE

1.0 PURPOSE

This Standard Operating Procedure (SOP) describes how investigation-derived waste (IDW) will be collected, segregated, classified, and managed during the field investigations at Naval Support Activity (NSA) Crane. The following types of IDW may be generated during this investigation:

- Decontamination solutions
- Personal protective equipment (PPE) and clothing
- Miscellaneous trash and incidental items

2.0 REQUIRED FIELD FORMS AND EQUIPMENT

Health and safety equipment (with PPE)

Bucket (with collected development/purge water)

Decontamination equipment

Field logbook

Writing utensil (preferably black pen with indelible ink)

Plastic sheeting and/or tarps

55-gallon drums with sealable lids

IDW labels for drums

Plastic garbage bags

3.0 PROCEDURES

Management of IDW includes the collection, segregation, temporary storage, classification, final disposal, and documentation of the waste-handling activities if necessary.

3.1 Liquid Wastes

Liquid wastes that may be generated during the site activities include decontamination solutions from sampling equipment. These wastes will be collected and containerized in a central location at NSA Crane for proper disposal.

3.2 Solid Wastes

No solid wastes are expected to be generated during this investigation. Excess soil core/sampling materials will be returned to the hole and tamped. If insufficient soil is available to fill the hole to the ground surface, then bentonite pellets mixed with the soil will be used to backfill the hole and hydrated with potable water. The disposition of this materials will be carried out in a manner such as not to contribute further environmental degradation or pose a threat to public health or safety.

3.3 PPE and Incidental Trash

All PPE wastes and incidental trash materials (e.g., wrapping or packing materials from supply cartons, waste paper, etc.) will be decontaminated (if contaminated), double bagged, securely tied shut, and placed in a designated waste receptacle at NSA Crane.

APPENDIX B

LABORATORY DoD ELAP ACCREDITATION



SCOPE OF ACCREDITATION TO ISO/IEC 17025:2005

RTI LABORATORIES, INC.
31628 Glendale
Livonia, Michigan 48150
Charles O'Bryan 734-422-8000 ext. 215
cobryan@rtilab.com

ENVIRONMENTAL

Valid To: October 31, 2012

Certificate Number: 0570.03

In recognition of the successful completion of the A2LA evaluation process, (including an assessment of the laboratory's compliance with the NELAC Chapter 5 Standard and the DOD QSM v4.1) accreditation is granted to this laboratory to perform recognized EPA methods using the following testing technologies and in the analyte categories identified below:

Testing Technologies

ICP/MS, Gas Chromatography, Gas Chromatography/Mass Spectrometry, Gravimetry, High Performance Liquid Chromatography, Ion Chromatography, Methylene Blue Active Substances, Microbiology, Misc.- Electronic Probes (pH, O₂), Oxygen Demand, Hazardous Waste Characteristics Tests, Spectrophotometry (Visible), Spectrophotometry (Automated), Titrimetry, Total Organic Carbon, Turbidity

| <u>Parameter/Analyte</u> | <u>Potable Water</u> | <u>Nonpotable Water</u> | <u>Solid Hazardous Waste</u> |
|--------------------------|----------------------|-------------------------|------------------------------|
| <u>Metals</u> | | | |
| Aluminum | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Antimony | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Arsenic | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Barium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Beryllium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Boron | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Cadmium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Calcium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Chromium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Cobalt | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Copper | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Iron | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Lead | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Magnesium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Manganese | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Mercury | EPA 245.1 | EPA 245.1/1631/7470A | EPA 7471A |
| Molybdenum | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Nickel | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |

| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste |
|---------------------------|---|--|-----------------------|
| Potassium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Selenium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Silicon | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Silver | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Sodium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Thallium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Tin | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Titanium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Uranium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Vanadium | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Zinc | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Preparation Methods | ----- | EPA 3020 | EPA 3050 |
| <u>Nutrients</u> | | | |
| Ammonia (as N) | SM4500 NH3-D | SM4500 NH3-D | ----- |
| Kjeldahl Nitrogen | EPA 351.2 | EPA 351.2 | ----- |
| Nitrate (as N) | EPA 300.0 SM 4500-NO3 E SM 4500-NO3 H | EPA 300.0/9056 SM 4500-NO3 E SM 4500-NO3 H | EPA 9056 |
| Nitrate-nitrite (as N) | EPA 300.0 | EPA 300.0/9056 | EPA 9056 |
| Nitrite (as N) | EPA 300.0 SM 4500-NO2 B | EPA 300.0/9056 SM 4500-NO2 B | EPA 9056 |
| Orthophosphate (as P) | EPA 300.0/ SM4500 P F | EPA 300.0/9056 SM4500 P-F | EPA 9056 |
| Total Phosphorus | SM4500 P-F | SM4500 P-F | ----- |
| <u>Demands</u> | | | |
| Biochemical Oxygen Demand | SM5210 B | SM5210 B | ----- |
| Carbonaceous BOD | SM5210 B | SM5210 B | ----- |
| Chemical Oxygen Demand | EPA 410.4 | EPA 410.4 | ----- |
| Total Organic Carbon | SM5310 B | SM5310 B | EPA 9060 |
| <u>Wet Chemistry</u> | | | |
| Alkalinity | SM2320 B | EPA 310.1 | ----- |
| Chloride | EPA 300.0 | EPA 300.0/9056 | EPA 9056 |
| Chlorine (residual) | SM4500-Cl I | SM4500 Cl-I | |
| Cyanide | SM4500 CN-E | SM4500 CN-E EPA 9012B | EPA 9012B |
| Available Cyanide | ASTM D6888 | ASTM D6888 | ----- |
| Fluoride | EPA 300.0 | EPA 300.0/9056 | EPA 9056 |
| Hardness | EPA 200.8 | EPA 200.8/6020 | EPA 6020 |
| Hexavalent Chromium | ----- | SM 4500 CR-B EPA 7196 | EPA 7196/3060 |
| pH | SM4500-H ⁺ B | SM4500-H ⁺ B EPA 9040C/9041A | EPA 9045C |
| Oil and Grease | EPA 1664A | EPA 1664A | EPA 9071B |
| Phenols | EPA 420.1 | EPA 420.1/9065 | EPA 9065 |
| Total Residue | SM2540 B | SM2540 B | ----- |

| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste |
|---|---------------|------------------|-----------------------|
| Filterable Residue | SM2540 C | SM2540 C | ----- |
| Nonfilterable Residue | SM2540 D | SM2540 D | ----- |
| Specific Conductance | SM2510 B | SM2510 B | ----- |
| Sulfate | EPA 300.0 | EPA 300.0/9056 | EPA 9056 |
| Surfactants | SM5540 C | SM5540 C | ----- |
| Turbidity | SM2130 B | SM2130 B | ----- |
| <u>Purgeable Organics</u> <u>(volatiles)</u> | | | |
| Acetone | ----- | EPA 624/8260B | EPA 8260B |
| Acetonitrile | ----- | EPA 624/8260B | EPA 8260B |
| Acrolein | ----- | EPA 624/8260B | EPA 8260B |
| Acrylamide | ----- | EPA 624/8260B | ----- |
| Acrylonitrile | ----- | EPA 624/8260B | EPA 8260B |
| Benzene | ----- | EPA 624/8260B | EPA 8260B |
| Bromobenzene | ----- | EPA 624/8260B | EPA 8260B |
| Bromodichloromethane | ----- | EPA 624/8260B | EPA 8260B |
| Bromoform | ----- | EPA 624/8260B | EPA 8260B |
| Bromomethane | ----- | EPA 624/8260B | EPA 8260B |
| 2-Butanone | ----- | EPA 624/8260B | EPA 8260B |
| n-Butylbenzene | ----- | EPA 624/8260B | EPA 8260B |
| sec-Butylbenzene | ----- | EPA 624/8260B | EPA 8260B |
| tert-Butylbenzene | ----- | EPA 624/8260B | EPA 8260B |
| Carbon Disulfide | ----- | EPA 624/8260B | EPA 8260B |
| Carbon Tetrachloride | ----- | EPA 624/8260B | EPA 8260B |
| Chlorobenzene | ----- | EPA 624/8260B | EPA 8260B |
| Chloroethane | ----- | EPA 624/8260B | EPA 8260B |
| 2-Chloroethyl Vinyl Ether | ----- | EPA 624/8260B | EPA 8260B |
| Chloroform | ----- | EPA 624/8260B | EPA 8260B |
| Chloromethane | ----- | EPA 624/8260B | EPA 8260B |
| Chlorotoluene | ----- | EPA 624/8260B | EPA 8260B |
| Dibromochloromethane | ----- | EPA 624/8260B | EPA 8260B |
| 1,2-Dibromo-3-Chloropropane (DBCP) | ----- | EPA 624/8260B | EPA 8260B |
| Dibromomethane | ----- | EPA 624/8260B | EPA 8260B |
| 1,2 Dibromomethane (EDB) | ----- | EPA 624/8260B | EPA 8260B |
| 1,4-Dichloro-2-butane | ----- | EPA 624/8260B | EPA 8260B |
| 1,2-Dichlorobenzene | ----- | EPA 624/8260B | EPA 8260B |
| 1,3-Dichlorobenzene | ----- | EPA 624/8260B | EPA 8260B |
| 1,4-Dichlorobenzene | ----- | EPA 624/8260B | EPA 8260B |
| Dichlorodifluoromethane | ----- | EPA 624/8260B | EPA 8260B |
| 1,1-Dichloroethane | ----- | EPA 624/8260B | EPA 8260B |
| 1,2-Dichloroethane | ----- | EPA 624/8260B | EPA 8260B |
| 1,1-Dichloroethene | ----- | EPA 624/8260B | EPA 8260B |
| cis-1,2-Dichloroethene | ----- | EPA 624/8260B | EPA 8260B |
| trans-1,2-Dichloroethene | ----- | EPA 624/8260B | EPA 8260B |
| 1,2-Dichloropropane | ----- | EPA 624/8260B | EPA 8260B |

| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste |
|--|---------------|------------------|-----------------------|
| 1,3-Dichloropropane | ----- | EPA 624/8260B | EPA 8260B |
| 2,2-Dichloropropane | ----- | EPA 624/8260B | EPA 8260B |
| 1,1-Dichloropropene | ----- | EPA 624/8260B | EPA 8260B |
| cis-1,3-Dichloropropene | ----- | EPA 624/8260B | EPA 8260B |
| trans-1,3-Dichloropropene | ----- | EPA 624/8260B | EPA 8260B |
| Diethyl Ether | ----- | EPA 624/8260B | EPA 8260B |
| Ethanol | ----- | EPA 624/8260B | EPA 8260B |
| Ethyl Benzene | ----- | EPA 624/8260B | EPA 8260B |
| Ethyl Methacrylate | ----- | EPA 624/8260B | EPA 8260B |
| Gas Range Organics (GRO) | ----- | EPA 8015B | EPA 8015B |
| 2-Hexanone | ----- | EPA 624/8260B | EPA 8260B |
| Hexachlorobutadiene | ----- | EPA 624/8260B | EPA 8260B |
| Isopropylbenzene | ----- | EPA 624/8260B | EPA 8260B |
| 1,4-Isopropyltoluene | ----- | EPA 624/8260B | EPA 8260B |
| Iodomethane | ----- | EPA 624/8260B | EPA 8260B |
| Methylene Chloride | ----- | EPA 624/8260B | EPA 8260B |
| Methyl Ethyle Ketone (MEK) | ----- | EPA 624/8260B | EPA 8260B |
| Methyl Isobutyl Ketone | ----- | EPA 624/8260B | EPA 8260B |
| 4-Methyl-2-pentanone | ----- | EPA 624/8260B | EPA 8260B |
| Naphthalene | ----- | EPA 624/8260B | EPA 8260B |
| n-Propylbenzene | ----- | EPA 624/8260B | EPA 8260B |
| Polynuclear Aromatic Hydrocarbons (PAHs) | ----- | EPA 625/8270D | EPA 8270D |
| Styrene | ----- | EPA 624/8260B | EPA 8260B |
| 1,1,1,2-Tetrachloroethane | ----- | EPA 624/8260B | EPA 8260B |
| 1,1,2,2-Tetrachloroethane | ----- | EPA 624/8260B | EPA 8260B |
| Tetrachloroethene | ----- | EPA 624/8260B | EPA 8260B |
| Toluene | ----- | EPA 624/8260B | EPA 8260B |
| Total Petroleum Hydrocarbons (TPH) | ----- | EPA 1664A | EPA 1664A |
| 1,1,1-Trichloroethane | ----- | EPA 624/8260B | EPA 8260B |
| 1,1,2-Trichloroethane | ----- | EPA 624/8260B | EPA 8260B |
| Trichloroethene | ----- | EPA 624/8260B | EPA 8260B |
| Trichlorofluoromethane | ----- | EPA 624/8260B | EPA 8260B |
| 1,2,3-Trichloropropane | ----- | EPA 624/8260B | EPA 8260B |
| 1,2,4-Trimethylbenzene | ----- | EPA 624/8260B | EPA 8260B |
| 1,3,5-Trimethylbenzene | ----- | EPA 624/8260B | EPA 8260B |
| Trihalomethanes | ----- | EPA 624/8260B | EPA 8260B |
| Vinyl Chloride | ----- | EPA 624/8260B | EPA 8260B |
| Xylenes, Total | ----- | EPA 624/8260B | EPA 8260B |
| 1,2-Xylene | ----- | EPA 624/8260B | EPA 8260B |
| 1,3-Xylene | ----- | EPA 624/8260B | EPA 8260B |
| 1,4-Xylene | ----- | EPA 624/8260B | EPA 8260B |
| Carbon Dioxide | RSKSOP-175 | RSKSOP-175 | ----- |
| Ethane | RSKSOP-175 | RSKSOP-175 | ----- |
| Ethylene | RSKSOP-175 | RSKSOP-175 | ----- |

| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste |
|--|---------------|------------------|-----------------------|
| Methane | RSKSOP-175 | RSKSOP-175 | ----- |
| Preparation Methods | ----- | EPA 5030B | EPA 5035 |
| <u>Extractable Organics</u> (semivolatiles) | | | |
| Acenaphthene | ----- | EPA 625/8270D | EPA 8270D |
| Acenaphthylene | ----- | EPA 625/8270D | EPA 8270D |
| Acetophenone | ----- | EPA 625/8270D | EPA 8270D |
| 4-Aminobiphenyl | ----- | EPA 625/8270D | EPA 8270D |
| Aniline | ----- | EPA 625/8270D | EPA 8270D |
| Anthracene | ----- | EPA 625/8270D | EPA 8270D |
| Benzydine | ----- | EPA 625/8270D | EPA 8270D |
| Benzoic Acid | ----- | EPA 625/8270D | EPA 8270D |
| Benzo (a) Anthracene | ----- | EPA 625/8270D | EPA 8270D |
| Benzo (b) Fluoranthene | ----- | EPA 625/8270D | EPA 8270D |
| Benzo (k) Fluoranthene | ----- | EPA 625/8270D | EPA 8270D |
| Benzo (ghi) Fluoranthene | ----- | EPA 625/8270D | EPA 8270D |
| Benzo (a) Pyrene | ----- | EPA 625/8270D | EPA 8270D |
| Benzyl Alcohol | ----- | EPA 625/8270D | EPA 8270D |
| Benzyl Chloride | ----- | EPA 625/8270D | EPA 8270D |
| Bis (2-chloroethoxy) Methane | ----- | EPA 625/8270D | EPA 8270D |
| Bis (2-chloroethoxy) Ether | ----- | EPA 625/8270D | EPA 8270D |
| Bis (2-chloroisopropyl) Ether | ----- | EPA 625/8270D | EPA 8270D |
| Bis (2-ethylhexyl) Phthalate | ----- | EPA 625/8270D | EPA 8270D |
| 4-Bromophenylphenyl) Phthalate | ----- | EPA 625/8270D | EPA 8270D |
| Butyl Benzyl Phthalate | ----- | EPA 625/8270D | EPA 8270D |
| 2-sec-Butyl-4,6- dinitrophenol | ----- | EPA 625/8270D | EPA 8270D |
| 4-Chloroaniline | ----- | EPA 625/8270D | EPA 8270D |
| 4-Chloro-3-methylphenol | ----- | EPA 625/8270D | EPA 8270D |
| 1-Chloronaphthalene | ----- | EPA 625/8270D | EPA 8270D |
| 2-Chloronaphthalene | ----- | EPA 625/8270D | EPA 8270D |
| 2-Chlorophenol | ----- | EPA 625/8270D | EPA 8270D |
| 4-Chlorophenyl Phenyl Ether | ----- | EPA 625/8270D | EPA 8270D |
| Chrysene | ----- | EPA 625/8270D | EPA 8270D |
| Cresols | ----- | EPA 625/8270D | EPA 8270D |
| 2-Cyclohexyl-4,6- dinitrophenol | ----- | EPA 625/8270D | EPA 8270D |
| Dibenzo (a,h) Anthracene | ----- | EPA 625/8270D | EPA 8270D |
| Dibenzofuran | ----- | EPA 625/8270D | EPA 8270D |
| 1,2-Dichlorobenzene | ----- | EPA 625/8270D | EPA 8270D |
| 1,3-Dichlorobenzene | ----- | EPA 625/8270D | EPA 8270D |
| 1,4-Dichlorobenzene | ----- | EPA 625/8270D | EPA 8270D |

| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste |
|-----------------------------|---------------|------------------|-----------------------|
| 3,3'-Dichlorobenzidine | ----- | EPA 625/8270D | EPA 8270D |
| 2,4-Dichlorophenol | ----- | EPA 625/8270D | EPA 8270D |
| 2,6-Dichlorophenol | ----- | EPA 625/8270D | EPA 8270D |
| Diethyl phthalate | ----- | EPA 625/8270D | EPA 8270D |
| 2,4-Dimethylphenol | ----- | EPA 625/8270D | EPA 8270D |
| Dimethyl Phthalate | ----- | EPA 625/8270D | EPA 8270D |
| Di-n-butyl Phthalate | ----- | EPA 625/8270D | EPA 8270D |
| Di-n-octyl Phthalate | ----- | EPA 625/8270D | EPA 8270D |
| Dinitrobenzene | ----- | EPA 625/8270D | EPA 8270D |
| 2,4-Dinitrophenol | ----- | EPA 625/8270D | EPA 8270D |
| 2,4-Dinitrotoluene | ----- | EPA 625/8270D | EPA 8270D |
| 2,6-Dinitrotoluene | ----- | EPA 625/8270D | EPA 8270D |
| Diphenylamine | ----- | EPA 625/8270D | EPA 8270D |
| DRO | ----- | EPA 8015B | EPA 8015B |
| Fluoroanthene | ----- | EPA 625/8270D | EPA 8270D |
| Fluorene | ----- | EPA 625/8270D | EPA 8270D |
| Hexachlorobenzene | ----- | EPA 625/8270D | EPA 8270D |
| Hexachlorobutadiene | ----- | EPA 625/8270D | EPA 8270D |
| Hexachlorocyclopentadiene | ----- | EPA 625/8270D | EPA 8270D |
| Hexachloroethane | ----- | EPA 625/8270D | EPA 8270D |
| Indeno (1,2,3-cd) Pyrene | ----- | EPA 625/8270D | EPA 8270D |
| Isophorone | ----- | EPA 625/8270D | EPA 8270D |
| 2-Methyl-4,6-Dinitrophenol | ----- | EPA 625/8270D | EPA 8270D |
| 2-Methylphenol | ----- | EPA 625/8270D | EPA 8270D |
| 4-Methylphenol | ----- | EPA 625/8270D | EPA 8270D |
| Naphthalene | ----- | EPA 625/8270D | EPA 8270D |
| 2-Nitroaniline | ----- | EPA 625/8270D | EPA 8270D |
| 3-Nitroaniline | ----- | EPA 625/8270D | EPA 8270D |
| 4-Nitroaniline | ----- | EPA 625/8270D | EPA 8270D |
| Nitrobenzene | ----- | EPA 625/8270D | EPA 8270D |
| 2-Nitrophenol | ----- | EPA 625/8270D | EPA 8270D |
| 4-Nitrophenol | ----- | EPA 625/8270D | EPA 8270D |
| N-Nitrosodi-n-propylamine | ----- | EPA 625/8270D | EPA 8270D |
| N-Nitrosodiphenylamine | ----- | EPA 625/8270D | EPA 8270D |
| 2,2-oxybis(1-chloropropane) | ----- | EPA 625/8270D | EPA 8270D |
| Pentachlorobenzene | ----- | EPA 625/8270D | EPA 8270D |
| Pentachloronitobenzene | ----- | EPA 625/8270D | EPA 8270D |
| Pentachlorophenol | ----- | EPA 625/8270D | EPA 8270D |
| Phenanthrene | ----- | EPA 625/8270D | EPA 8270D |
| Phenol | ----- | EPA 625/8270D | EPA 8270D |
| Pyrene | ----- | EPA 625/8270D | EPA 8270D |
| Styrene | ----- | EPA 625/8270D | EPA 8270D |
| Tetrachlorobenzenes | ----- | EPA 625/8270D | EPA 8270D |
| 1,2,4,5-Tetrachlorobenzene | ----- | EPA 625/8270D | EPA 8270D |
| 2,3,4,5-Tetrachlorophenol | ----- | EPA 625/8270D | EPA 8270D |
| 2,4,6-Tribromophenol | ----- | EPA 625/8270D | EPA 8270D |

| Parameter/Analyte | Potable Water | Nonpotable Water | Solid Hazardous Waste |
|----------------------------|---------------|------------------|-----------------------|
| 1,2,4-Trichlorobenzene | ----- | EPA 625/8270D | EPA 8270D |
| 2,4,5-Trichlorophenol | ----- | EPA 625/8270D | EPA 8270D |
| 2,4,6-Trichlorophenol | ----- | EPA 625/8270D | EPA 8270D |
| Preparation Methods | ----- | EPA 3510 | EPA 3545/3550 |
| Pesticides/Herbicides/PCBs | | | |
| Aldrin | ----- | EPA 608/8081A | EPA 8081A |
| Atrazine | ----- | ----- | ----- |
| Azinophos Methyl | ----- | ----- | ----- |
| alpha-BHC | ----- | EPA 608/8081A | EPA 8081A |
| beta-BHC | ----- | EPA 608/8081A | EPA 8081A |
| delta-BHC | ----- | EPA 608/8081A | EPA 8081A |
| gamma-BHC | ----- | EPA 608/8081A | EPA 8081A |
| Bolstar | ----- | ----- | ----- |
| Chlordane (technical) | ----- | EPA 608/8081A | EPA 8081A |
| Chlorpyrifos | ----- | ----- | ----- |
| 2,4-D | ----- | EPA 8151A | EPA 8151A |
| Dalapon | ----- | EPA 8151A | EPA 8151A |
| 2,4-DB | ----- | EPA 8151A | EPA 8151A |
| 4,4'-DDD | ----- | EPA 608/8081A | EPA 8081A |
| 4,4'-DDE | ----- | EPA 608/8081A | EPA 8081A |
| 4,4',-DDT | ----- | EPA 608/8081A | EPA 8081A |
| Demeton-O | ----- | ----- | ----- |
| Demeton-S | ----- | ----- | ----- |
| Diazinon | ----- | ----- | ----- |
| Dicamba | ----- | EPA 8151A | EPA 8151A |
| Dichlofention | ----- | ----- | ----- |
| Dichlorvos | ----- | ----- | ----- |
| Dichloroprop | ----- | EPA 8151A - | EPA 8151A |
| Dieldrin | ----- | EPA 608/8081A | EPA 8081A |
| Dinoseb | ----- | EPA 8151A | EPA 8151A |
| Disulfoton | ----- | ----- | ----- |
| Endosulfan I | ----- | EPA 608/8081A | EPA 8081A |
| Endosulfan II | ----- | EPA 608/8081A | EPA 8081A |
| Endonsulfan Sulfate | ----- | EPA 608/8081A | EPA 8081A |
| Endrin | ----- | EPA 608/8081A | EPA 8081A |
| Endrin Aldehyde | ----- | EPA 608/8081A | EPA 8081A |
| Endrin Ketone | ----- | EPA 608/8081A | EPA 8081A |
| Ethion | ----- | ----- | ----- |
| Ethoprop | ----- | ----- | ----- |
| Heptachlor | ----- | EPA 608/8081A | EPA 8081A |
| Heptachlor Epoxide | ----- | EPA 608/8081A | EPA 8081A |
| Malathion | ----- | ----- | ----- |
| MCPA | ----- | EPA 8151A | EPA 8151A |
| MCPP | ----- | EPA 8151A | EPA 8151A |
| Methoxychlor | ----- | EPA 608/8081A | EPA 8081A |
| PCB-1016 (Arochlor) | ----- | EPA 608/8082 | EPA 8082 |
| PCB-1221 | ----- | EPA 608/8082 | EPA 8082 |

| <u>Parameter/Analyte</u> | <u>Potable Water</u> | <u>Nonpotable Water</u> | <u>Solid Hazardous Waste</u> |
|--|----------------------|-------------------------|------------------------------|
| PCB-1232 | ----- | EPA 608/8082 | EPA 8082 |
| PCB-1242 | ----- | EPA 608/8082 | EPA 8082 |
| PCB-1248 | ----- | EPA 608/8082 | EPA 8082 |
| PCB-1254 | ----- | EPA 608/8082 | EPA 8082 |
| PCB-1260 | ----- | EPA 608/8082 | EPA 8082 |
| PCB-1262 | ----- | EPA 608/8082 | EPA 8082 |
| PCB-1268 | ----- | EPA 608/8082 | EPA 8082 |
| 2,4,5-T | ----- | EPA 8151A | EPA 8151A |
| 2,4,5-TP | ----- | EPA 8151A | EPA 8151A |
| Toxaphene | ----- | EPA 608/8081a | EPA 8081A |
| Conductivity | ----- | EPA 9050A | ----- |
| Corrosivity | ----- | EPA 9040C | SW 846 Ch7/9040C/9045C |
| Explosives | ----- | EPA 8330B | EPA 8330B |
| Ignatibility | ----- | ----- | EPA 1010/1030 |
| Paint Filter Liquids Test | ----- | ----- | EPA 9095A |
| Nitroglycerine | ----- | EPA 8330B | EPA 8330B |
| Synthetic Precipitation Leaching Procedure (SPLP) | ----- | ----- | EPA 1312 |
| Toxicity Characteristic Leaching Procedure | ----- | ----- | EPA 1311 |
| Preparation Methods | ----- | EPA 3510 | EPA 3545/3550 |

| <u>Analyte</u> | <u>Air</u> |
|---------------------------------------|------------|
| 1,1,1-Trichloroethane | EPA TO-15 |
| 1,1,2,2-Tetrachloroethane | EPA TO-15 |
| 1,1,2-Trichloro-1,2,2-trifluoroethane | EPA TO-15 |
| 1,1,2-Trichloroethane | EPA TO-15 |
| 1,1-Dichloroethane | EPA TO-15 |
| 1,1-Dichloroethene | EPA TO-15 |
| 1,2,4-Trichlorobenzene | EPA TO-15 |
| 1,2,4-Trimethylbenzene | EPA TO-15 |
| 1,2-Dibromoethane | EPA TO-15 |
| 1,2-Dichlorobenzene | EPA TO-15 |
| 1,2-Dichloroethane | EPA TO-15 |
| 1,2-Dichloropropane | EPA TO-15 |
| 1,3,5-Trimethylbenzene | EPA TO-15 |
| 1,3-Butadiene | EPA TO-15 |
| 1,3-Dichlorobenzene | EPA TO-15 |
| 1,4-Dichlorobenzene | EPA TO-15 |
| 1,4-Dioxane | EPA TO-15 |
| 2-Butanone | EPA TO-15 |
| 2-Hexanone | EPA TO-15 |
| 2-Propanol | EPA TO-15 |
| 4-Methyl-2-pentanone | EPA TO-15 |
| Acetone | EPA TO-15 |

| Analyte | Air |
|---------------------------|--------------------|
| Benzene | EPA TO-15 |
| Benzyl chloride | EPA TO-15 |
| Bromodichloromethane | EPA TO-15 |
| Bromoform | EPA TO-15 |
| Bromomethane | EPA TO-15 |
| Carbon disulfide | EPA TO-15 |
| Carbon tetrachloride | EPA TO-15 |
| Chlorobenzene | EPA TO-15 |
| Chlorodibromomethane | EPA TO-15 |
| Chloroethane | EPA TO-15 |
| Chloroform | EPA TO-15 |
| Chloromethane | EPA TO-15 |
| cis-1,2-Dichloroethene | EPA TO-15 |
| cis-1,3-dichloropropene | EPA TO-15 |
| Cyclohexane | EPA TO-15 |
| Dichlorodifluoromethane | EPA TO-15 |
| Ethanol | EPA TO-15 |
| Ethyl acetate | EPA TO-15 |
| Ethylbenzene | EPA TO-15 |
| Heptane | EPA TO-15 |
| Hexachlorobutadiene | EPA TO-15 |
| m,p-Xylene | EPA TO-15 |
| Methylene chloride | EPA TO-15 |
| n-Hexane | EPA TO-15 |
| o-Xylene | EPA TO-15 |
| Propylene | EPA TO-15 |
| Styrene | EPA TO-15 |
| tert-Butyl Methyl Ether | EPA TO-15 |
| Tetrachloroethene | EPA TO-15 |
| Tetrahydrofuran | EPA TO-15 |
| Toluene | EPA TO-15 |
| trans-1,3-dichloropropene | EPA TO-15 |
| Trichloroethene | EPA TO-15 |
| Trichlorofluoromethane | EPA TO-15 |
| Vinyl acetate | EPA TO-15 |
| Vinyl chloride | EPA TO-15 |
| Xylenes, Total | EPA TO-15 |
| PCBs as Aroclors | |
| Aroclor 1016 | EPA TO-4/EPA TO-10 |
| Aroclor 1221 | EPA TO-4/EPA TO-10 |
| Aroclor 1232 | EPA TO-4/EPA TO-10 |
| Aroclor 1242 | EPA TO-4/EPA TO-10 |
| Aroclor 1248 | EPA TO-4/EPA TO-10 |
| Aroclor 1254 | EPA TO-4/EPA TO-10 |
| Aroclor 1260 | EPA TO-4/EPA TO-10 |
| Total PCBs | EPA TO-4/EPA TO-10 |
| Pesticides | |
| 4,4'-DDD | EPA TO-4/EPA TO-10 |

| Analyte | Air |
|--------------------|--------------------|
| 4,4'-DDE | EPA TO-4/EPA TO-10 |
| 4,4'-DDT | EPA TO-4/EPA TO-10 |
| Aldrin | EPA TO-4/EPA TO-10 |
| alpha-BHC | EPA TO-4/EPA TO-10 |
| beta-BHC | EPA TO-4/EPA TO-10 |
| Chlordane, total | EPA TO-4/EPA TO-10 |
| Dieldrin | EPA TO-4/EPA TO-10 |
| Endosulfan I | EPA TO-4/EPA TO-10 |
| Endosulfan II | EPA TO-4/EPA TO-10 |
| Endosulfan sulfate | EPA TO-4/EPA TO-10 |
| Endrin | EPA TO-4/EPA TO-10 |
| Endrin aldehyde | EPA TO-4/EPA TO-10 |
| Endrin ketone | EPA TO-4/EPA TO-10 |
| gamma-BHC | EPA TO-4/EPA TO-10 |
| Heptachlor | EPA TO-4/EPA TO-10 |
| Heptachlor epoxide | EPA TO-4/EPA TO-10 |
| Hexachlorobenzene | EPA TO-4/EPA TO-10 |
| Methoxychlor | EPA TO-4/EPA TO-10 |
| Total PCBs | EPA TO-4/EPA TO-10 |
| Toxaphene | EPA TO-4/EPA TO-10 |
| 4,4'-DDD | EPA TO-4/EPA TO-10 |



The American Association for Laboratory Accreditation

Accredited DoD ELAP Laboratory

A2LA has accredited

RTI LABORATORIES, INC.

Livonia, MI

for technical competence in the field of

Environmental Testing

In recognition of the successful completion of the A2LA evaluation process that includes an assessment of the laboratory's compliance with ISO/IEC 17025:2005, the 2003 NELAC Chapter 5 Standard, and the requirements of the Department of Defense Environmental Laboratory Accreditation Program (DoD ELAP) as detailed in the DoD Quality Systems Manual for Environmental Laboratories (QSM v4.1); accreditation is granted to this laboratory to perform recognized EPA methods as defined on the associated A2LA Environmental Scope of Accreditation. This accreditation demonstrates technical competence for this defined scope and the operation of a laboratory quality management system (refer to joint ISO-ILAC-IAF Communiqué dated 8 January 2009).

Presented this 15th day of March 2011.



A handwritten signature in black ink, reading "Peter Mlynar".

President & CEO
For the Accreditation Council
Certificate Number 0570.03
Valid to October 31, 2012

For the tests or types of tests to which this accreditation applies, please refer to the laboratory's Environmental Scope of Accreditation.



State of Utah
GARY R HERBERT
Governor
GREGORY S BELL
Lieutenant Governor

Utah Department of Health

W. David Patton, Ph.D

Executive Director

Disease Control and Prevention

Patrick F. Luedtke, MD, MPH.

Director Unified State Labs: Public Health

Bureau of Laboratory Improvement

David B Mendenhall, MPA, MT (ASCP)

Bureau Director



**STATE OF UTAH
DEPARTMENT OF HEALTH**

ENVIRONMENTAL LABORATORY CERTIFICATION PROGRAM

CERTIFICATION

is hereby granted to

RTI Laboratories, Inc.

**31628 Glendale Street
Livonia MI 48150**

Scope of accreditation is limited to the
State of Utah Accredited Fields of Accreditation
Which accompanies this Certificate

Continued accredited status depends on successful
Ongoing participation in the program

EPA Number: MI00147
Expiration Date: 1/31/2012

Patrick F. Luedtke, MD, MPH.

Director of Public Health Laboratories

Deputy Director of Epidemiology and Laboratory Services



4431 South 2700 West • Taylorsville, UT 84119 • phone (801) 965-2400 • fax (801) 965-2544
www.health.utah.gov/els/labimp/



State of Utah
GARY R HERBERT
Governor
GREGORY S BELL
Lieutenant Governor

Utah Department of Health

W. David Patton, Ph.D

Executive Director

Disease Control and Prevention

Patrick F. Luedtke, MD, MPH.

Director Unified State Labs: Public Health

Bureau of Laboratory Improvement

David B Mendenhall, MPA, MT (ASCP)

Bureau Director



4/1/2011

RTI Laboratories, Inc.
Fred Hoitash
31628 Glendale Street
Livonia MI 48150

Director,

ID # RTI
EPA ID: MI00147

On the basis of your most recent assessment, Proficiency Testing results and continuing compliance with the ELCP requirements, the laboratory listed is certified for environmental monitoring under the Clean Water Act and authorized to perform the following methods, for the analytes and matrix listed:

Non-Potable Water

Inorganics and Metals

| | |
|------------------|--|
| 120.1 [1982] | Conductance (Specific Conductance, umhos at 25-C) |
| 1631 E | Mercury in Water by Oxidation, Purge and Trap, and Cold Vapor Atomic Fluorescence Spectrometry |
| 1664 A [1999] | Oil & Grease and Total Petroleum Hydrocarbons |
| 200.8 [1994] | Aluminum |
| 200.8 [1994] | Antimony |
| 200.8 [1994] | Arsenic |
| 200.8 [1994] | Barium |
| 200.8 [1994] | Beryllium |
| 200.8 [1994] | Boron |
| 200.8 [1994] | Cadmium |
| 200.8 [1994] | Chromium |
| 200.8 [1994] | Cobalt |
| 200.8 [1994] | Copper |
| 200.8 [1994] | Iron |
| 200.8 [1994] | Lead |
| 200.8 [1994] | Manganese |
| 200.8 [1994] | Molybdenum |
| 200.8 [1994] | Nickel |
| 200.8 [1994] | Selenium |
| 200.8 [1994] | Silver |
| 200.8 [1994] | Thallium |
| 200.8 [1994] | Tin |
| 200.8 [1994] | Vanadium |
| 200.8 [1994] | Zinc |
| 2320 B [20th ED] | Alkalinity (Titration) [SM 20th ED] |
| 245.1 [1994] | Mercury |
| 2540 B [20th ED] | Total Solids Dried at 103-105-C [SM 20th ED] |
| 2540 C [20th ED] | Total Dissolved Solids Dried at 180-C [SM 20th ED] |
| 2540 D [20th ED] | Total Suspended Solids Dried at 103-105-C [SM 20th ED] |
| 300.0 [1993] | Bromide |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

Inorganics and Metals

| | |
|------------------|---|
| 300.0 [1993] | Chloride |
| 300.0 [1993] | Fluoride |
| 300.0 [1993] | Nitrate |
| 300.0 [1993] | Nitrite |
| 300.0 [1993] | ortho-Phosphate |
| 300.0 [1993] | Phosphate |
| 300.0 [1993] | Sulfate |
| 300.0 [1993] | Nitrate/Nitrite |
| 330.1 [1978] | Chlorine, Total Residual |
| 351.2 [1978] | Nitrogen, Total Kjeldahl |
| 410.4 [1993] | Chemical Oxygen Demand |
| 420.1 [1978] | Phenolics |
| 4500 (Cl) G [20t | Chlorine, Residual (Colorimetric, DPD) [SM 20th ED] |
| 4500 (CN-) D [20 | Cyanide (Titrimetric) [SM 20th ED] |
| 4500 (CN-) G [2 | Cyanides Amenable to Chlorination after Distillation [SM 20th ED] |
| 4500 (H+) B [20t | pH (Electrometric) [SM 20th ED] |
| 4500 (NH3) D [2 | Nitrogen (Ammonia) (Ammonia-Selective Electrode) [SM 20th ED] |
| 4500 (NO3-) E [2 | Nitrogen (Nitrate, Cadmium Reduction) [SM 20th ED] |
| 4500 (P) F [20th | Ortho-Phosphate (Automated Ascorbic Acid Reduction) [SM 20th ED] |
| 5210 B [20th ED] | Biochemical Oxygen Demand 5-Day Test [SM 20th ED] |
| 5210 B [20th ED] | Carboneous Biochemical Oxygen Demand (CBOD) [SM 20th ED] |

Microbiological

| | |
|------------------|--|
| 9222 B [20th ED] | Total Coliform - MF Technique [SM 20th ED] |
| 9222 D [20th ED] | Fecal Coliform - MF Technique [SM 20th ED] |

Organics

| | |
|-----|---|
| 608 | Organochlorine Pesticides and Polychlorinated Biphenyls |
| 608 | Aldrin |
| 608 | alpha-BHC |
| 608 | beta-BHC |
| 608 | delta-BHC |
| 608 | gamma-BHC (Lindane) |
| 608 | Chlordane |
| 608 | 4,4'-DDD |
| 608 | 4,4'-DDE |
| 608 | 4,4'-DDT |
| 608 | Dieldrin |
| 608 | Endosulfan I |
| 608 | Endosulfan II |
| 608 | Endosulfan Sulfate |
| 608 | Endrin |
| 608 | Endrin Aldehyde |
| 608 | Heptachlor |
| 608 | Heptachlor Epoxide |
| 608 | Methoxychlor |
| 608 | Toxaphene |
| 608 | Aroclor 1016 |
| 608 | Aroclor 1221 |
| 608 | Aroclor 1232 |
| 608 | Aroclor 1242 |
| 608 | Aroclor 1248 |
| 608 | Aroclor 1254 |
| 608 | Aroclor 1260 |
| 624 | Purgeables |
| 624 | Acrolein |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

Organics

| | |
|-----|---|
| 624 | Acrylonitrile |
| 624 | Benzene |
| 624 | Bromodichloromethane |
| 624 | Bromoform |
| 624 | Bromomethane |
| 624 | Carbon Tetrachloride |
| 624 | Chlorobenzene |
| 624 | Chloroethane |
| 624 | 2-Chloroethylvinyl Ether |
| 624 | Chloroform |
| 624 | Chloromethane |
| 624 | Dibromochloromethane |
| 624 | 1,2-Dichlorobenzene |
| 624 | 1,3-Dichlorobenzene |
| 624 | 1,4-Dichlorobenzene |
| 624 | 1,1-Dichloroethane |
| 624 | 1,2-Dichloroethane |
| 624 | 1,1-Dichloroethene (Vinylidene Chloride) |
| 624 | trans-1,2-Dichloroethene |
| 624 | cis-1,3-Dichloropropene |
| 624 | trans-1,3-Dichloropropene |
| 624 | Ethylbenzene |
| 624 | Dichloromethane (DCM, Methylene chloride) |
| 624 | 1,1,2,2-Tetrachloroethane |
| 624 | Tetrachloroethylene |
| 624 | Toluene |
| 624 | 1,1,1-Trichloroethane |
| 624 | 1,1,2-Trichloroethane |
| 624 | Trichloroethene |
| 624 | Trichlorofluoromethane |
| 624 | Vinyl Chloride |
| 624 | Xylenes, total |
| 625 | Base/Neutrals and Acids |
| 625 | Acenaphthene |
| 625 | Acenaphthylene |
| 625 | Anthracene |
| 625 | Benzidine |
| 625 | Benzo(a)anthracene |
| 625 | Benzo(b)fluoranthene |
| 625 | Benzo(k)fluoranthene |
| 625 | Benzo(g,h,i)perylene |
| 625 | Benzo(a)pyrene |
| 625 | Benzyl Butyl Phthalate |
| 625 | bis(2-Chloroethyl)ether |
| 625 | bis(2-Chloroethoxy)methane |
| 625 | bis(2-Ethylhexyl)phthalate |
| 625 | bis(2-Chloroisopropyl)ether |
| 625 | 4-Bromophenyl Phenyl Ether |
| 625 | 4-Chlorophenyl Phenyl Ether |
| 625 | Chrysene |
| 625 | Dibenz(a,h)anthracene |
| 625 | Di-n-butylphthalate |
| 625 | 1,2-Dichlorobenzene |
| 625 | 1,3-Dichlorobenzene |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.


Organics

| | |
|-----|-----------------------------|
| 625 | 1,4-Dichlorobenzene |
| 625 | 3,3'-Dichlorobenzidine |
| 625 | Diethyl phthalate |
| 625 | Dimethyl phthalate |
| 625 | Di-n-octylphthalate |
| 625 | Fluoranthene |
| 625 | Fluorene |
| 625 | Hexachlorobenzene |
| 625 | Hexachlorobutadiene |
| 625 | Hexachlorocyclopentadiene |
| 625 | Hexachloroethane |
| 625 | Indeno(1,2,3-cd)pyrene |
| 625 | Isophorone |
| 625 | Naphthalene |
| 625 | Nitrobenzene |
| 625 | N-Nitrosodimethylamine |
| 625 | N-Nitrosodi-n-propylamine |
| 625 | N-Nitrosodiphenylamine |
| 625 | Phenanthrene |
| 625 | Pyrene |
| 625 | 1,2,4-Trichlorobenzene |
| 625 | 4-Chloro-3-methylphenol |
| 625 | 2-Chlorophenol |
| 625 | 2,4-Dichlorophenol |
| 625 | 2,4-Dimethylphenol |
| 625 | 2,4-Dinitrophenol |
| 625 | 2-Methyl- 4,6-dinitrophenol |
| 625 | 2-Nitrophenol |
| 625 | 4-Nitrophenol |
| 625 | Pentachlorophenol |
| 625 | Phenol |
| 625 | 2,4,5-Trichlorophenol |
| 625 | 2,4,6-Trichlorophenol |

The effective date of this certificate letter is: 2/1/2011.

The analytes by method which a laboratory is authorized to perform at any given time will be those indicated in the most recent certificate letter. The most recent certification letter supersedes all previous certification or authorization letters. It is the certified laboratory's responsibility to review this letter for discrepancies. The certified laboratory must document any discrepancies in this letter and send notice to this bureau within 15 days of receipt. This certificate letter will be recalled in the event your laboratory's certification is revoked.

Respectfully,



Patrick F. Luedtke, MD, MPH.

Director of Public Health Laboratories

Deputy Director of Epidemiology and Laboratory Services

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.



State of Utah
GARY R HERBERT
Governor
GREGORY S BELL
Lieutenant Governor

Utah Department of Health

W. David Patton, Ph.D

Executive Director

Disease Control and Prevention

Patrick F. Luedtke, MD, MPH.

Director Unified State Labs: Public Health

Bureau of Laboratory Improvement

David B Mendenhall, MPA, MT (ASCP)

Bureau Director



4/1/2011

RTI Laboratories, Inc.
 Fred Hoitash
 31628 Glendale Street
 Livonia MI 48150

ID # RTI
 EPA ID: MI00147

Director,

On the basis of your most recent assessment, Proficiency Testing results and continuing compliance with the ELCP requirements, the laboratory listed is certified for environmental monitoring under the Resource Conservation and Recovery Act and authorized to perform the following methods, for the analytes and matrix listed:

Characteristics

| | Solid | Non-Potable Water | |
|------|-------------------------------------|--------------------------|--|
| 1010 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Ignitability |
| 1030 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Ignitability |
| 1311 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Toxicity Characteristic Leaching Procedure Metals |
| 1311 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Toxicity Characteristic Leaching Procedure Semi-Volatiles |
| 1311 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Toxicity Characteristic Leaching Procedure Volatiles |
| 1312 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Synthetic Precipitation Leaching Procedure (TCLP Approval) |

Inorganics

| | Solid | Non-Potable Water | |
|--------|-------------------------------------|-------------------------------------|--------------------------------|
| 9012 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Amenable Cyanide |
| 9012 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Total Cyanide |
| 9030 B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Sulfide Distillation Procedure |
| 9031 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Extractable Sulfides |
| 9045 C | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Soil and Waste pH |
| 9050 A | <input type="checkbox"/> | <input checked="" type="checkbox"/> | Specific Conductance |
| 9056 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Bromide |
| 9056 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Chloride |
| 9056 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Fluoride |
| 9056 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Nitrate |
| 9056 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Nitrite |
| 9056 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Ortho Phosphate |
| 9056 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Sulfates |
| 9065 | <input type="checkbox"/> | <input checked="" type="checkbox"/> | Phenolics |
| 9095 A | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Paint Filter Liquids Test |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.



Metal Digestion

| | Solid | Non-Potable Water | |
|--------|-------------------------------------|-------------------------------------|--|
| 3020 A | <input type="checkbox"/> | <input checked="" type="checkbox"/> | Acid Digestion for Total Metals |
| 3050 B | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Acid Digestion of Sediments, Sludges and Soils |
| 3052 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Microwave Acid Digestion of Siliceous and Organic Matrixes |
| 3060 A | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Alkaline Digestion for Hexavalent Chromium |

Metals

| | Solid | Non-Potable Water | |
|--------|-------------------------------------|-------------------------------------|-------------------------------------|
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aluminum |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Antimony |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Arsenic |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Barium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Beryllium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Cadmium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Calcium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Chromium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Cobalt |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Copper |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Iron |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Lead |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Magnesium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Manganese |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Molybdenum |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Nickel |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Potassium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Selenium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Silver |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Thallium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Vanadium |
| 6020 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Zinc |
| 7196 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Chromium, Hexavalent (Chromium, VI) |
| 7470 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Mercury |
| 7471 A | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Mercury |

Miscellaneous

| | Solid | Non-Potable Water | |
|------|-------------------------------------|--------------------------|------------------|
| 5050 | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Bomb Preparation |

Organic Cleanup

| | Solid | Non-Potable Water | |
|--------|-------------------------------------|-------------------------------------|------------------------------------|
| 3620 C | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Florisil Cleanup |
| 3660 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Sulfur Cleanup |
| 3665 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Sulfuric Acid/Permanganate Cleanup |

Organic Extraction

| | Solid | Non-Potable Water | |
|--------|-------------------------------------|-------------------------------------|---|
| 3510 C | <input type="checkbox"/> | <input checked="" type="checkbox"/> | Separatory Funnel Liquid-Liquid Extractions |
| 3535 A | <input type="checkbox"/> | <input checked="" type="checkbox"/> | Solid Phase Extraction |
| 3545 A | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Pressurized Fluid Extraction |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

Organic Extraction

| | Solid | Non-Potable Water | |
|--------|-------------------------------------|--------------------------|-----------------------|
| 3550 B | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Ultrasonic Extraction |

Organic Instrumentation

| | Solid | Non-Potable Water | |
|--------|-------------------------------------|-------------------------------------|--|
| 8015B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Diesel Range Organics (DROs) |
| 8015B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Ethanol |
| 8015B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Ethylene Glycol |
| 8015B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Gasoline Range Organics (GROs) |
| 8015B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Methanol |
| 8015B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Nonhalogenated Organics Using GC/FID |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 4,4'-DDD |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 4,4'-DDE |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 4,4'-DDT |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aldrin |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | alpha-BHC(alpha-hexachlorocyclohexane) |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | alpha-Chlordane |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | beta-BHC(beta-hexachlorocyclohexane) |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | delta-BHC(delta-hexachlorocyclohexane) |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Dieldrin |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Endosulfan I |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Endosulfan II |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Endosulfan sulfate |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Endrin |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Endrin Aldehyde |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Endrin Ketone |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | gamma-BHC (Lindane, gamma-hexachlorocyclohexane) |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | gamma-Chlordane |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Heptachlor |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Heptachlor Epoxide |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Methoxychlor |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Organochlorine Pesticides |
| 8081A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Toxaphene [Chlorinated camphene] |
| 8082 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aroclor-1016 [PCB-1016] |
| 8082 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aroclor-1221 [PCB-1221] |
| 8082 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aroclor-1232 [PCB-1232] |
| 8082 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aroclor-1242 [PCB-1242] |
| 8082 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aroclor-1248 [PCB-1248] |
| 8082 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aroclor-1254 [PCB-1254] |
| 8082 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Aroclor-1260 [PCB-1260] |
| 8082 | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | PCBs |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2,4,5-T |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2,4,5-TP (Silvex) |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2,4-D |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2,4-DB |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Chlorinated Herbicides |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Dalapon |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | DCPA [di acid degradate] |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Dicamba |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Dichlorprop(Dichloroprop) |
| 8151 A | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Dinoseb (DNBP, 2-sec-butyl-4,6-dinitrophenol) |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

Organic Instrumentation

| | Solid | Non-Potable Water | |
|--------|-------|-------------------|--|
| 8151 A | ✓ | ✓ | MCPA |
| 8151 A | ✓ | ✓ | MCPP |
| 8151 A | ✓ | ✓ | Pentachlorophenol |
| 8151 A | ✓ | ✓ | Picloram |
| 8260 B | ✓ | ✓ | 1,1,1,2-Tetrachloroethane |
| 8260 B | ✓ | ✓ | 1,1,1-Trichloroethane |
| 8260 B | ✓ | ✓ | 1,1,2,2-Tetrachloroethane |
| 8260 B | ✓ | ✓ | 1,1,2-Trichloroethane |
| 8260 B | ✓ | ✓ | 1,1-Dichloroethane |
| 8260 B | ✓ | ✓ | 1,1-Dichloroethylene (-ethene)[Vinylidene Chloride] |
| 8260 B | ✓ | ✓ | 1,1-Dichloropropene |
| 8260 B | ✓ | ✓ | 1,2,3-Trichlorobenzene |
| 8260 B | ✓ | ✓ | 1,2,3-Trichloropropane |
| 8260 B | ✓ | ✓ | 1,2,4-Trichlorobenzene |
| 8260 B | ✓ | ✓ | 1,2,4-Trimethylbenzene |
| 8260 B | ✓ | ✓ | 1,2-Dibromo-3-chloropropane (DBCP, Dibromochloropropane) |
| 8260 B | ✓ | ✓ | 1,2-Dibromoethane (EDB, Ethylene dibromide) |
| 8260 B | ✓ | ✓ | 1,2-Dichlorobenzene |
| 8260 B | ✓ | ✓ | 1,2-Dichloroethane |
| 8260 B | ✓ | ✓ | 1,2-Dichloropropane |
| 8260 B | ✓ | ✓ | 1,3,5-Trimethylbenzene |
| 8260 B | ✓ | ✓ | 1,3-Dichlorobenzene |
| 8260 B | ✓ | ✓ | 1,3-Dichloropropane |
| 8260 B | ✓ | ✓ | 1,4-Dichlorobenzene |
| 8260 B | ✓ | ✓ | 2,2-Dichloropropane |
| 8260 B | ✓ | ✓ | 2-Chloroethyl Vinyl Ether |
| 8260 B | ✓ | ✓ | 2-Chlorotoluene |
| 8260 B | ✓ | ✓ | 2-Hexanone |
| 8260 B | ✓ | ✓ | 4-Chlorotoluene |
| 8260 B | ✓ | ✓ | 4-Methyl-2-pentanone (MIBK, Isopropylacetone, Hexone) |
| 8260 B | ✓ | ✓ | Acetone |
| 8260 B | ✓ | ✓ | Acrylonitrile |
| 8260 B | ✓ | ✓ | Benzene |
| 8260 B | ✓ | ✓ | Bromobenzene |
| 8260 B | ✓ | ✓ | Bromochloromethane |
| 8260 B | ✓ | ✓ | Bromodichloromethane |
| 8260 B | ✓ | ✓ | Bromoform |
| 8260 B | ✓ | ✓ | Carbon Disulfide |
| 8260 B | ✓ | ✓ | Carbon Tetrachloride |
| 8260 B | ✓ | ✓ | Chlorobenzene |
| 8260 B | ✓ | ✓ | Chlorodibromomethane [Dibromochloromethane] |
| 8260 B | ✓ | ✓ | Chloroethane |
| 8260 B | ✓ | ✓ | Chloroform |
| 8260 B | ✓ | ✓ | cis-1,2-Dichloroethene (-ethylene) |
| 8260 B | ✓ | ✓ | cis-1,3-dichloropropene |
| 8260 B | ✓ | ✓ | Dibromomethane |
| 8260 B | ✓ | ✓ | Dichlorodifluoromethane |
| 8260 B | ✓ | ✓ | Dichloromethane (DCM, Methylene chloride) |
| 8260 B | ✓ | ✓ | Diethyl Ether (Ethyl Ether) |
| 8260 B | ✓ | ✓ | Ethyl Methacrylate |
| 8260 B | ✓ | ✓ | Ethylbenzene |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

Organic Instrumentation

| | Solid | Non-Potable Water | |
|--------|-------|-------------------|---|
| 8260 B | ✓ | ✓ | Hexachlorobutadiene |
| 8260 B | ✓ | ✓ | Hexachloroethane |
| 8260 B | ✓ | ✓ | Iodomethane (Methyl iodide) |
| 8260 B | ✓ | ✓ | Isopropylbenzene |
| 8260 B | ✓ | ✓ | meta-Xylene |
| 8260 B | ✓ | ✓ | Methyl bromide [Bromomethane] |
| 8260 B | ✓ | ✓ | Methyl chloride [Chloromethane] |
| 8260 B | ✓ | ✓ | Methyl Ethyl Ketone (MEK, 2-Butanone) |
| 8260 B | ✓ | ✓ | Methyl-t-Butyl Ether (MTBE) |
| 8260 B | ✓ | ✓ | Naphthalene |
| 8260 B | ✓ | ✓ | n-Butylbenzene |
| 8260 B | ✓ | ✓ | n-Propylbenzene |
| 8260 B | ✓ | ✓ | ortho-Xylene |
| 8260 B | ✓ | ✓ | para-Xylene |
| 8260 B | ✓ | ✓ | p-Isopropyltoluene |
| 8260 B | ✓ | ✓ | sec-Butylbenzene |
| 8260 B | ✓ | ✓ | Styrene |
| 8260 B | ✓ | ✓ | tert-Butyl Alcohol (TBA) |
| 8260 B | ✓ | ✓ | tert-Butylbenzene |
| 8260 B | ✓ | ✓ | Tetrachloroethylene (Perchloroethylene -ethene) |
| 8260 B | ✓ | ✓ | Toluene |
| 8260 B | ✓ | ✓ | trans-1,2-Dichloroethylene (-ethene) |
| 8260 B | ✓ | ✓ | trans-1,3-Dichloropropylene (-propene) |
| 8260 B | ✓ | ✓ | trans-1,4-dichloro-2-butene |
| 8260 B | ✓ | ✓ | Trichloroethene (Trichloroethylene) |
| 8260 B | ✓ | ✓ | Trichlorofluoromethane |
| 8260 B | ✓ | ✓ | Vinyl Acetate |
| 8260 B | ✓ | ✓ | Vinyl Chloride |
| 8260 B | ✓ | ✓ | Volatile Organic Compounds |
| 8260 B | ✓ | ✓ | Xylenes, Total |
| 8270 D | ✓ | ✓ | 1,2,4-Trichlorobenzene |
| 8270 D | ✓ | ✓ | 1,2-Dichlorobenzene |
| 8270 D | ✓ | ✓ | 1,3-Dichlorobenzene |
| 8270 D | ✓ | ✓ | 1,4-Dichlorobenzene |
| 8270 D | ✓ | ✓ | 2,3,4,6-Tetrachlorophenol |
| 8270 D | ✓ | ✓ | 2,4,5-Trichlorophenol |
| 8270 D | ✓ | ✓ | 2,4,6-Trichlorophenol |
| 8270 D | ✓ | ✓ | 2,4-Dichlorophenol |
| 8270 D | ✓ | ✓ | 2,4-Dimethylphenol |
| 8270 D | ✓ | ✓ | 2,4-Dinitrophenol |
| 8270 D | ✓ | ✓ | 2,4-Dinitrotoluene (2,4-DNT) |
| 8270 D | ✓ | ✓ | 2,6-Dichlorophenol |
| 8270 D | ✓ | ✓ | 2,6-Dinitrotoluene (2,6-DNT) |
| 8270 D | ✓ | ✓ | 2-Chloronaphthalene |
| 8270 D | ✓ | ✓ | 2-Methyl-4,6-dinitrophenol (4,6-Dinitro-2-methylphenol) |
| 8270 D | ✓ | ✓ | 2-Methylnaphthalene |
| 8270 D | ✓ | ✓ | 2-Methylphenol (o-cresol, 2-Hydroxytoluene) |
| 8270 D | ✓ | ✓ | 2-Nitroaniline |
| 8270 D | ✓ | ✓ | 2-Nitrophenol |
| 8270 D | ✓ | ✓ | 3,3'-Dichlorobenzidine |
| 8270 D | ✓ | ✓ | 3-Methylphenol (m-cresol, 3-Hydroxytoluene) |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

Organic Instrumentation

| | Solid | Non-Potable Water | |
|--------|-------|-------------------|---|
| 8270 D | ✓ | ✓ | 3-Nitroaniline |
| 8270 D | ✓ | ✓ | 4-Bromophenyl Phenyl Ether |
| 8270 D | ✓ | ✓ | 4-Chloro-3-methylphenol |
| 8270 D | ✓ | ✓ | 4-Chloroaniline |
| 8270 D | ✓ | ✓ | 4-Chlorophenyl Phenyl Ether |
| 8270 D | ✓ | ✓ | 4-Methylphenol (p-cresol, 4-Hydroxytoluene) |
| 8270 D | ✓ | ✓ | 4-Nitroaniline |
| 8270 D | ✓ | ✓ | 4-Nitrophenol |
| 8270 D | ✓ | ✓ | Acenaphthene |
| 8270 D | ✓ | ✓ | Acenaphthylene |
| 8270 D | ✓ | ✓ | Aniline |
| 8270 D | ✓ | ✓ | Anthracene |
| 8270 D | ✓ | ✓ | Benzidine |
| 8270 D | ✓ | ✓ | Benzo(a)anthracene |
| 8270 D | ✓ | ✓ | Benzo(a)pyrene |
| 8270 D | ✓ | ✓ | Benzo(b)fluoranthene |
| 8270 D | ✓ | ✓ | Benzo(g,h,i)perylene |
| 8270 D | ✓ | ✓ | Benzo(k)fluoranthene |
| 8270 D | ✓ | ✓ | Benzoic Acid |
| 8270 D | ✓ | ✓ | Benzyl alcohol |
| 8270 D | ✓ | ✓ | bis(2-chloroethoxy)methane |
| 8270 D | ✓ | ✓ | bis(2-Chloroethyl)ether |
| 8270 D | ✓ | ✓ | bis(2-chloroisopropyl)ether |
| 8270 D | ✓ | ✓ | bis(2-Ethylhexyl) phthalate (DEHP) |
| 8270 D | ✓ | ✓ | Butyl Benzyl Phthalate |
| 8270 D | ✓ | ✓ | Chrysene |
| 8270 D | ✓ | ✓ | Dibenzo(a,h)anthracene |
| 8270 D | ✓ | ✓ | Dibenzofuran |
| 8270 D | ✓ | ✓ | Diethyl Phthalate |
| 8270 D | ✓ | ✓ | Dimethyl Phthalate |
| 8270 D | ✓ | ✓ | Di-n-butyl phthalate |
| 8270 D | ✓ | ✓ | Di-n-octyl Phthalate |
| 8270 D | ✓ | ✓ | Fluoranthene |
| 8270 D | ✓ | ✓ | Fluorene |
| 8270 D | ✓ | ✓ | Hexachlorobenzene |
| 8270 D | ✓ | ✓ | Hexachlorobutadiene |
| 8270 D | ✓ | ✓ | Hexachlorocyclopentadiene |
| 8270 D | ✓ | ✓ | Hexachloroethane |
| 8270 D | ✓ | ✓ | Indeno(1,2,3-cd)pyrene |
| 8270 D | ✓ | ✓ | Isophorone |
| 8270 D | ✓ | ✓ | Naphthalene |
| 8270 D | ✓ | ✓ | Nitrobenzene |
| 8270 D | ✓ | ✓ | N-Nitrosodiethylamine |
| 8270 D | ✓ | ✓ | n-Nitrosodimethylamine |
| 8270 D | ✓ | ✓ | n-Nitroso-di-n-Propylamine |
| 8270 D | ✓ | ✓ | n-Nitrosodiphenylamine |
| 8270 D | ✓ | ✓ | Pentachlorophenol |
| 8270 D | ✓ | ✓ | Phenanthrene |
| 8270 D | ✓ | ✓ | Phenol |
| 8270 D | ✓ | ✓ | Pyrene |
| 8270 D | ✓ | ✓ | Semivolatile Organic Compounds |

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.

Organic Instrumentation

| | Solid | Non-Potable Water | |
|-------|-------------------------------------|-------------------------------------|--|
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 1,3,5-Trinitrobenzene (1,3,5-TNB) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 1,3-Dinitrobenzene (1,3-DNB) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2,4,6-Trinitrotoluene (2,4,6-TNT) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2,4-Dinitrotoluene (2,4-DNT) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2,6-Dinitrotoluene (2,6-DNT) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2-Amino-4,6-Dinitrotoluene (2-Am-DNT) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 2-Nitrotoluene (2-NT) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 3,5-Dinitroaniline |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 3-Nitrotoluene (3-NT) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 4-Amino-2,6-Dinitrotoluene (4-Am-DNT) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | 4-Nitrotoluene (4-NT) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Hexahydro-1, 3, 5-tritro-1, 3, 5-triazine (RDX) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Methyl-2,4,6-Trinitrophenylnitramine (TETRYL) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Nitroaromatics and Nitramines |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Nitrobenzene |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Nitroglycerin |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Octahydro-1,3,5,7-Tetranitro-1,3,5,7-Tetrazocine (HMX) |
| 8330B | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | Pentaerythrite tetranitrate (PETN) |

Volatile Organic Preparation

| | Solid | Non-Potable Water | |
|--------|-------------------------------------|-------------------------------------|---|
| 5030 C | <input type="checkbox"/> | <input checked="" type="checkbox"/> | Purge-and-Trap for Aqueous Samples |
| 5035A | <input checked="" type="checkbox"/> | <input type="checkbox"/> | Purge-and-Trap and Extraction for Volatile Organics |

The effective date of this certificate letter is: 2/1/2011.

The analytes by method which a laboratory is authorized to perform at any given time will be those indicated in the most recent certificate letter. The most recent certification letter supersedes all previous certification or authorization letters. It is the certified laboratory's responsibility to review this letter for discrepancies. The certified laboratory must document any discrepancies in this letter and send notice to this bureau within 15 days of receipt. This certificate letter will be recalled in the event your laboratory's certification is revoked.

Respectfully,



Patrick F. Luedtke, MD, MPH.

Director of Public Health Laboratories

Deputy Director of Epidemiology and Laboratory

The expiration for the laboratory's certification is 1/31/2012. The Utah Environmental Laboratory Certification Program (ELCP) encourages clients and data users to verify the most current certification letter for the authorized method.



A Waters Company

SOIL-74 Final Complete Report

Charles O'Bryan
Director, Quality Management
RTI Laboratories
31628 Glendale Avenue
Livonia, MI 48150
(734) 422-8000

EPA ID:
ERA Customer Number:
Report Issued:
Study Dates:

MI00147
R751701
06/23/11
04/18/11 - 06/02/11

| Anal. No. | Analyte | Units | Reported Value | Assigned Value | Acceptance Limits | Performance Evaluation | Method Description |
|-----------|---------|-------|----------------|----------------|-------------------|------------------------|--------------------|
|-----------|---------|-------|----------------|----------------|-------------------|------------------------|--------------------|

SOIL Volatiles in Soil (cat# 623)

| | | | | | | | |
|------|------------------------------------|-------|------|------|-------------|--------------|-----------|
| 4315 | Acetone | µg/kg | 278 | 361 | 40.0 - 637 | Acceptable | EPA 8260B |
| 4320 | Acetonitrile | µg/kg | - | 739 | 0.00 - 1500 | Not Reported | |
| 4325 | Acrolein | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4375 | Benzene | µg/kg | 74.6 | 93.5 | 55.6 - 128 | Acceptable | EPA 8260B |
| 4385 | Bromobenzene | µg/kg | 139 | 166 | 70.3 - 258 | Acceptable | EPA 8260B |
| 4395 | Bromodichloromethane | µg/kg | 157 | 190 | 126 - 261 | Acceptable | EPA 8260B |
| 4400 | Bromoform | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4950 | Bromomethane | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4410 | 2-Butanone (MEK) | µg/kg | 258 | 280 | 62.5 - 456 | Acceptable | EPA 8260B |
| 5000 | tert-Butyl methyl ether (MTBE) | µg/kg | 85.0 | 87.2 | 36.5 - 132 | Acceptable | EPA 8260B |
| 4450 | Carbon disulfide | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4455 | Carbon tetrachloride | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4475 | Chlorobenzene | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4575 | Chlorodibromomethane | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4485 | Chloroethane | µg/kg | 106 | 171 | 56.0 - 272 | Acceptable | EPA 8260B |
| 4500 | 2-Chloroethylvinylether | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4505 | Chloroform | µg/kg | 102 | 124 | 75.1 - 173 | Acceptable | EPA 8260B |
| 4960 | Chloromethane | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4570 | 1,2-Dibromo-3-chloropropane (DBCP) | µg/kg | 111 | 89.9 | 49.6 - 149 | Acceptable | EPA 8260B |
| 4585 | 1,2-Dibromoethane (EDB) | µg/kg | 134 | 145 | 87.3 - 199 | Acceptable | EPA 8260B |
| 4595 | Dibromomethane | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4610 | 1,2-Dichlorobenzene | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4615 | 1,3-Dichlorobenzene | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4620 | 1,4-Dichlorobenzene | µg/kg | 54.2 | 67.3 | 23.3 - 95.7 | Acceptable | EPA 8260B |
| 4625 | Dichlorodifluoromethane (Freon 12) | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4630 | 1,1-Dichloroethane | µg/kg | 136 | 170 | 96.8 - 245 | Acceptable | EPA 8260B |
| 4635 | 1,2-Dichloroethane | µg/kg | 185 | 197 | 114 - 272 | Acceptable | EPA 8260B |
| 4640 | 1,1-Dichloroethylene | µg/kg | 59.3 | 77.6 | 55.3 - 116 | Acceptable | EPA 8260B |
| 4645 | cis-1,2-Dichloroethylene | µg/kg | 117 | 194 | 111 - 276 | Acceptable | EPA 8260B |
| 4700 | trans-1,2-Dichloroethylene | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4655 | 1,2-Dichloropropane | µg/kg | 100 | 115 | 67.4 - 154 | Acceptable | EPA 8260B |
| 4680 | cis-1,3-Dichloropropylene | µg/kg | 145 | 193 | 103 - 257 | Acceptable | EPA 8260B |





A Waters Company

SOIL-74 Final Complete Report

Charles O'Bryan
Director, Quality Management
RTI Laboratories
31628 Glendale Avenue
Livonia, MI 48150
(734) 422-8000

EPA ID:
ERA Customer Number:
Report Issued:
Study Dates:

MI00147
R751701
06/23/11
04/18/11 - 06/02/11

| Anal. No. | Analyte | Units | Reported Value | Assigned Value | Acceptance Limits | Performance Evaluation | Method Description |
|--|------------------------------|-------|----------------|----------------|-------------------|------------------------|--------------------|
| SOIL Volatiles in Soil (cat# 623) (Continued) | | | | | | | |
| 4685 | trans-1,3-Dichloropropylene | µg/kg | 35.4 | 42.5 | 22.8 - 55.6 | Acceptable | EPA 8260B |
| 4765 | Ethylbenzene | µg/kg | 33.3 | 42.1 | 22.1 - 62.7 | Acceptable | EPA 8260B |
| 4860 | 2-Hexanone | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4900 | Isopropylbenzene | µg/kg | 124 | 166 | 77.0 - 275 | Acceptable | EPA 8260B |
| 4975 | Methylene chloride | µg/kg | 20.8 | 29.5 | 13.4 - 46.1 | Acceptable | EPA 8260B |
| 4995 | 4-Methyl-2-pentanone (MIBK) | µg/kg | 199 | 205 | 89.6 - 299 | Acceptable | EPA 8260B |
| 5005 | Naphthalene | µg/kg | 189 | 190 | 104 - 260 | Acceptable | EPA 8260B |
| 5100 | Styrene | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 5105 | 1,1,1,2-Tetrachloroethane | µg/kg | 80.8 | 92.0 | 59.8 - 126 | Acceptable | EPA 8260B |
| 5110 | 1,1,2,2-Tetrachloroethane | µg/kg | 46.2 | 48.0 | 23.8 - 72.0 | Acceptable | EPA 8260B |
| 5115 | Tetrachloroethylene | µg/kg | 84.4 | 136 | 61.2 - 197 | Acceptable | EPA 8260B |
| 5140 | Toluene | µg/kg | 69.0 | 97.1 | 55.7 - 136 | Acceptable | EPA 8260B |
| 5155 | 1,2,4-Trichlorobenzene | µg/kg | 60.2 | 94.5 | 27.2 - 141 | Acceptable | EPA 8260B |
| 5160 | 1,1,1-Trichloroethane | µg/kg | 44.1 | 55.7 | 30.0 - 79.1 | Acceptable | EPA 8260B |
| 5165 | 1,1,2-Trichloroethane | µg/kg | 109 | 122 | 71.5 - 168 | Acceptable | EPA 8260B |
| 5170 | Trichloroethylene | µg/kg | 88.6 | 103 | 52.8 - 147 | Acceptable | EPA 8260B |
| 5175 | Trichlorofluoromethane | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 5180 | 1,2,3-Trichloropropane (TCP) | µg/kg | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 5225 | Vinyl acetate | µg/kg | | 0.00 | | Not Reported | |
| 5235 | Vinyl chloride | µg/kg | 70.3 | 111 | 30.5 - 199 | Acceptable | EPA 8260B |
| 5260 | Xylenes, total | µg/kg | 150 | 188 | 92.2 - 277 | Acceptable | EPA 8260B |





A Waters Company

SOIL-74 Final Complete Report

Charles O'Bryan
Director, Quality Management
RTI Laboratories
31628 Glendale Avenue
Livonia, MI 48150
(734) 422-8000

EPA ID:
ERA Customer Number:
Report Issued:
Study Dates:

MI00147
R751701
06/23/11
04/18/11 - 06/02/11

| Anal. No. | Analyte | Units | Reported Value | Assigned Value | Acceptance Limits | Performance Evaluation | Method Description |
|-----------|---------|-------|----------------|----------------|-------------------|------------------------|--------------------|
|-----------|---------|-------|----------------|----------------|-------------------|------------------------|--------------------|

SOIL Ready-to-Use VOAs In Soil (cat# 870)

| | | | | | | | |
|------|------------------------------------|-------|-------|-------|--------------|----------------|-----------|
| 4315 | Acetone | µg/kg | 10900 | 15600 | 4450 - 23800 | Acceptable | EPA 8260B |
| 4320 | Acetonitrile | µg/kg | | 0.00 | | Not Reported | |
| 4325 | Acrolein | µg/kg | < 500 | 0.00 | | Acceptable | EPA 8260B |
| 4375 | Benzene | µg/kg | 8030 | 7740 | 5650 - 10000 | Acceptable | EPA 8260B |
| 4385 | Bromobenzene | µg/kg | 6880 | 7660 | 5700 - 9130 | Acceptable | EPA 8260B |
| 4395 | Bromodichloromethane | µg/kg | 4660 | 4730 | 3220 - 6660 | Acceptable | EPA 8260B |
| 4400 | Bromoform | µg/kg | 7630 | 8060 | 5450 - 10700 | Acceptable | EPA 8260B |
| 4950 | Bromomethane | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4410 | 2-Butanone (MEK) | µg/kg | 15100 | 18900 | 5360 - 28400 | Acceptable | EPA 8260B |
| 5000 | tert-Butyl methyl ether (MTBE) | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4450 | Carbon disulfide | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4455 | Carbon tetrachloride | µg/kg | 4740 | 4170 | 2570 - 5720 | Acceptable | EPA 8260B |
| 4475 | Chlorobenzene | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4575 | Chlorodibromomethane | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4485 | Chloroethane | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4500 | 2-Chloroethylvinylether | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4505 | Chloroform | µg/kg | 8220 | 7870 | 5430 - 10300 | Acceptable | EPA 8260B |
| 4960 | Chloromethane | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4570 | 1,2-Dibromo-3-chloropropane (DBCP) | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4585 | 1,2-Dibromoethane (EDB) | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4595 | Dibromomethane | µg/kg | 6720 | 6700 | 5140 - 7640 | Acceptable | EPA 8260B |
| 4610 | 1,2-Dichlorobenzene | µg/kg | 3460 | 3680 | 2640 - 4830 | Acceptable | EPA 8260B |
| 4615 | 1,3-Dichlorobenzene | µg/kg | 6010 | 6800 | 4890 - 8840 | Acceptable | EPA 8260B |
| 4620 | 1,4-Dichlorobenzene | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4625 | Dichlorodifluoromethane (Freon 12) | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4630 | 1,1-Dichloroethane | µg/kg | 3220 | 3480 | 2310 - 4840 | Acceptable | EPA 8260B |
| 4635 | 1,2-Dichloroethane | µg/kg | 8840 | 8480 | 6290 - 10800 | Acceptable | EPA 8260B |
| 4640 | 1,1-Dichloroethylene | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4645 | cis-1,2-Dichloroethylene | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4700 | trans-1,2-Dichloroethylene | µg/kg | < 50 | 9810 | 6920 - 12900 | Not Acceptable | EPA 8260B |
| 4655 | 1,2-Dichloropropane | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4680 | cis-1,3-Dichloropropylene | µg/kg | 3180 | 3940 | 2530 - 4570 | Acceptable | EPA 8260B |





A Waters Company

SOIL-74 Final Complete Report

Charles O'Bryan
Director, Quality Management
RTI Laboratories
31628 Glendale Avenue
Livonia, MI 48150
(734) 422-8000

EPA ID:
ERA Customer Number:
Report Issued:
Study Dates:

MI00147
R751701
06/23/11
04/18/11 - 06/02/11

| Anal. No. | Analyte | Units | Reported Value | Assigned Value | Acceptance Limits | Performance Evaluation | Method Description |
|-----------|---------|-------|----------------|----------------|-------------------|------------------------|--------------------|
|-----------|---------|-------|----------------|----------------|-------------------|------------------------|--------------------|

SOIL Ready-to-Use VOAs in Soil (cat# 870) (Continued)

| | | | | | | | |
|------|------------------------------|-------|-------|-------|---------------|--------------|-----------|
| 4685 | trans-1,3-Dichloropropylene | µg/kg | 7790 | 9720 | 4730 - 13300 | Acceptable | EPA 8260B |
| 4765 | Ethylbenzene | µg/kg | 5650 | 5840 | 4010 - 7880 | Acceptable | EPA 8260B |
| 4835 | Hexachlorobutadiene | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 4840 | Hexachloroethane | µg/kg | 1320 | 1720 | 818 - 2050 | Acceptable | EPA 8260B |
| 4860 | 2-Hexanone | µg/kg | 13800 | 18700 | 11200 - 23600 | Acceptable | EPA 8260B |
| 4900 | Isopropylbenzene | µg/kg | 2420 | 2800 | 1940 - 3780 | Acceptable | EPA 8260B |
| 4975 | Methylene chloride | µg/kg | 6940 | 8160 | 4510 - 11500 | Acceptable | EPA 8260B |
| 4995 | 4-Methyl-2-pentanone (MIBK) | µg/kg | 11400 | 14100 | 8220 - 18600 | Acceptable | EPA 8260B |
| 5005 | Naphthalene | µg/kg | 4350 | 5120 | 2870 - 6890 | Acceptable | EPA 8260B |
| 5015 | Nitrobenzene | µg/kg | | 0.00 | | Not Reported | |
| 5100 | Styrene | µg/kg | 4120 | 4570 | 3530 - 5440 | Acceptable | EPA 8260B |
| 5105 | 1,1,1,2-Tetrachloroethane | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 5110 | 1,1,2,2-Tetrachloroethane | µg/kg | 2740 | 3150 | 1630 - 4510 | Acceptable | EPA 8260B |
| 5115 | Tetrachloroethylene | µg/kg | 5420 | 6240 | 4080 - 8570 | Acceptable | EPA 8260B |
| 5140 | Toluene | µg/kg | 4590 | 5140 | 3620 - 6750 | Acceptable | EPA 8260B |
| 5155 | 1,2,4-Trichlorobenzene | µg/kg | 3130 | 4090 | 2820 - 4870 | Acceptable | EPA 8260B |
| 5160 | 1,1,1-Trichloroethane | µg/kg | 4750 | 4390 | 3140 - 5700 | Acceptable | EPA 8260B |
| 5165 | 1,1,2-Trichloroethane | µg/kg | 8570 | 9150 | 6380 - 12000 | Acceptable | EPA 8260B |
| 5170 | Trichloroethylene | µg/kg | 7590 | 7190 | 5020 - 9530 | Acceptable | EPA 8260B |
| 5175 | Trichlorofluoromethane | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 5180 | 1,2,3-Trichloropropane (TCP) | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8260B |
| 5225 | Vinyl acetate | µg/kg | | 0.00 | | Not Reported | |
| 5235 | Vinyl chloride | µg/kg | 7470 | 9200 | 3060 - 14400 | Acceptable | EPA 8260B |
| 5260 | Xylenes, total | µg/kg | 10400 | 11200 | 7970 - 14900 | Acceptable | EPA 8260B |

SOIL Nitroaromatics & Nitramines in Soil (cat# 871)

| | | | | | | | |
|------|----------------------------|-------|-------|------|--------------|----------------|-----------|
| 9306 | 4-Amino-2,6-dinitrotoluene | µg/kg | 988 | 2280 | 674 - 3020 | Acceptable | EPA 8330B |
| 9303 | 2-Amino-4,6-dinitrotoluene | µg/kg | 1320 | 2860 | 1010 - 3720 | Acceptable | EPA 8330B |
| 6160 | 1,3-Dinitrobenzene | µg/kg | 1120 | 2320 | 768 - 3430 | Acceptable | EPA 8330B |
| 6185 | 2,4-Dinitrotoluene | µg/kg | 1730 | 3580 | 594 - 5690 | Acceptable | EPA 8330B |
| 6190 | 2,6-Dinitrotoluene | µg/kg | 1670 | 3600 | 1120 - 5120 | Acceptable | EPA 8330B |
| 9522 | HMX | µg/kg | < 50 | 0.00 | | Acceptable | EPA 8330B |
| 5015 | Nitrobenzene | µg/kg | 4160 | 8400 | 2020 - 12800 | Acceptable | EPA 8330B |
| 9507 | 2-Nitrotoluene | µg/kg | 3710 | 7650 | 2690 - 10900 | Acceptable | EPA 8330B |
| 9510 | 3-Nitrotoluene | µg/kg | 4520 | 9420 | 3150 - 13200 | Acceptable | EPA 8330B |
| 9513 | 4-Nitrotoluene | µg/kg | 2010 | 4330 | 3200 - 5070 | Not Acceptable | EPA 8330B |
| 9432 | RDX | µg/kg | 2600 | 5920 | 1400 - 8010 | Acceptable | EPA 8330B |
| 6415 | Tetryl | µg/kg | < 200 | 0.00 | | Acceptable | EPA 8330B |
| 6885 | 1,3,5-Trinitrobenzene | µg/kg | 4010 | 8720 | 872 - 12800 | Acceptable | EPA 8330B |
| 9651 | 2,4,6-Trinitrotoluene | µg/kg | 3680 | 8800 | 5570 - 9680 | Not Acceptable | EPA 8330B |





A Waters Company

WP-195 Final Complete Report

Charles O'Bryan
Director, Quality Management
RTI Laboratories
31628 Glendale Avenue
Livonia, MI 48150
734-422-8000

EPA ID:
ERA Customer Number:
Report Issued:
Study Dates:

MI00147
R751701
06/16/11
04/11/11 - 05/26/11

| Anal. No. | Analyte | Units | Reported Value | Assigned Value | Acceptance Limits | Performance Evaluation | Method Description |
|--------------------------------|------------------------------------|-------|----------------|----------------|-------------------|------------------------|--------------------|
| WP Volatiles (cat# 830) | | | | | | | |
| 4315 | Acetone | µg/L | 49.1 | 48.2 | 9.34 - 78.0 | Acceptable | EPA 8260B |
| 4320 | Acetonitrile | µg/L | | 0.00 | | Not Reported | |
| 4325 | Acrolein | µg/L | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 4340 | Acrylonitrile | µg/L | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 0065 | Benzene | µg/L | 20.4 | 18.9 | 12.8 - 25.0 | Acceptable | EPA 8260B |
| 0060 | Bromodichloromethane | µg/L | 75.9 | 70.0 | 49.6 - 94.5 | Acceptable | EPA 8260B |
| 0062 | Bromoform | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4950 | Bromomethane | µg/L | 31.8 | 32.0 | 12.8 - 51.2 | Acceptable | EPA 8260B |
| 4410 | 2-Butanone (MEK) | µg/L | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 5000 | tert-Butyl methyl ether (MTBE) | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4450 | Carbon disulfide | µg/L | < 5 | 0.00 | | Acceptable | EPA 8260B |
| 0058 | Carbon tetrachloride | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 0064 | Chlorobenzene | µg/L | 66.6 | 63.4 | 45.7 - 79.4 | Acceptable | EPA 8260B |
| 0061 | Chlorodibromomethane | µg/L | 91.0 | 85.2 | 58.4 - 113 | Acceptable | EPA 8260B |
| 4485 | Chloroethane | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4500 | 2-Chloroethylvinylether | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 0055 | Chloroform | µg/L | 48.8 | 45.9 | 31.7 - 59.5 | Acceptable | EPA 8260B |
| 4960 | Chloromethane | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4570 | 1,2-Dibromo-3-chloropropane (DBCP) | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4585 | 1,2-Dibromoethane (EDB) | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4595 | Dibromomethane | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 0094 | 1,2-Dichlorobenzene | µg/L | 74.3 | 70.3 | 48.8 - 91.2 | Acceptable | EPA 8260B |
| 0096 | 1,3-Dichlorobenzene | µg/L | 55.7 | 52.2 | 35.2 - 66.6 | Acceptable | EPA 8260B |
| 0095 | 1,4-Dichlorobenzene | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4625 | Dichlorodifluoromethane (Freon 12) | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4630 | 1,1-Dichloroethane | µg/L | 19.2 | 17.0 | 11.1 - 23.1 | Acceptable | EPA 8260B |
| 0054 | 1,2-Dichloroethane | µg/L | 20.1 | 17.5 | 12.1 - 24.0 | Acceptable | EPA 8260B |
| 4640 | 1,1-Dichloroethylene | µg/L | 42.8 | 34.2 | 17.9 - 49.8 | Acceptable | EPA 8260B |
| 4645 | cis-1,2-Dichloroethylene | µg/L | 24.6 | 28.8 | 20.0 - 38.5 | Acceptable | EPA 8260B |
| 4700 | trans-1,2-Dichloroethylene | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4655 | 1,2-Dichloropropane | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4680 | cis-1,3-Dichloropropylene | µg/L | 18.7 | 18.7 | 13.1 - 24.3 | Acceptable | EPA 8260B |





A Waters Company

WP-195 Final Complete Report

Charles O'Bryan
Director, Quality Management
RTI Laboratories
31628 Glendale Avenue
Livonia, MI 48150
734-422-8000

EPA ID:
ERA Customer Number:
Report Issued:
Study Dates:

MI00147
R751701
06/16/11
04/11/11 - 05/26/11

| Anal. No. | Analyte | Units | Reported Value | Assigned Value | Acceptance Limits | Performance Evaluation | Method Description |
|--|------------------------------|-------|----------------|----------------|-------------------|------------------------|--------------------|
| WP Volatiles (cat# 830) (Continued) | | | | | | | |
| 4685 | trans-1,3-Dichloropropylene | µg/L | 54.1 | 57.2 | 36.7 - 77.3 | Acceptable | EPA 8260B |
| 0066 | Ethylbenzene | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4835 | Hexachlorobutadiene | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 4860 | 2-Hexanone | µg/L | 79.2 | 78.3 | 39.2 - 114 | Acceptable | EPA 8260B |
| 0063 | Methylene chloride | µg/L | 56.0 | 52.7 | 32.2 - 73.7 | Acceptable | EPA 8260B |
| 4995 | 4-Methyl-2-pentanone (MIBK) | µg/L | 71.7 | 67.5 | 30.2 - 102 | Acceptable | EPA 8260B |
| 5005 | Naphthalene | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 5100 | Styrene | µg/L | 78.9 | 76.7 | 48.9 - 105 | Acceptable | EPA 8260B |
| 5105 | 1,1,1,2-Tetrachloroethane | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 5110 | 1,1,2,2-Tetrachloroethane | µg/L | 29.2 | 25.7 | 13.5 - 39.9 | Acceptable | EPA 8260B |
| 0059 | Tetrachloroethylene | µg/L | 55.3 | 62.2 | 34.8 - 81.3 | Acceptable | EPA 8260B |
| 0067 | Toluene | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 5155 | 1,2,4-Trichlorobenzene | µg/L | 66.9 | 67.0 | 13.8 - 82.0 | Acceptable | EPA 8260B |
| 0056 | 1,1,1-Trichloroethane | µg/L | 31.6 | 28.2 | 17.7 - 37.7 | Acceptable | EPA 8260B |
| 5165 | 1,1,2-Trichloroethane | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 0057 | Trichloroethylene | µg/L | 66.3 | 63.2 | 40.2 - 82.5 | Acceptable | EPA 8260B |
| 5175 | Trichlorofluoromethane | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 5180 | 1,2,3-Trichloropropane (TCP) | µg/L | < 1 | 0.00 | | Acceptable | EPA 8260B |
| 5225 | Vinyl acetate | µg/L | | 0.00 | | Not Reported | |
| 5235 | Vinyl chloride | µg/L | 32.0 | 28.4 | 11.4 - 45.4 | Acceptable | EPA 8260B |
| 5260 | Xylenes, total | µg/L | 154 | 150 | 86.0 - 201 | Acceptable | EPA 8260B |

WP Chlorinated Acid Herbicides (cat# 829)

| | | | | | | | |
|------|--------------------------|------|------|------|--------------|----------------|-----------|
| 8505 | Acifluorfen | µg/L | 4.12 | 4.93 | 0.875 - 7.34 | Acceptable | EPA 8151A |
| 8530 | Bentazon | µg/L | 6.43 | 6.29 | 0.629 - 12.0 | Acceptable | EPA 8151A |
| 8540 | Chloramben | µg/L | 7.32 | 8.25 | 0.825 - 12.1 | Acceptable | EPA 8151A |
| 8545 | 2,4-D | µg/L | 2.15 | 2.52 | 0.252 - 4.35 | Acceptable | EPA 8151A |
| 8560 | 2,4-DB | µg/L | 1.86 | 5.76 | 0.576 - 11.0 | Acceptable | EPA 8151A |
| 8550 | Oacthal diacid (DCPA) | µg/L | 3.24 | 4.37 | 0.437 - 7.90 | Acceptable | EPA 8151A |
| 8555 | Dalapon | µg/L | 2.93 | 6.74 | 0.674 - 11.2 | Acceptable | EPA 8151A |
| 8595 | Dicamba | µg/L | 6.43 | 6.95 | 0.695 - 10.1 | Acceptable | EPA 8151A |
| 8600 | 3,5-Dichlorobenzoic acid | µg/L | 5.57 | 7.27 | 1.92 - 10.8 | Acceptable | EPA 8151A |
| 8605 | Dichloroprop | µg/L | 3.82 | 4.03 | 0.645 - 6.01 | Acceptable | EPA 8151A |
| 8620 | Dinoseb | µg/L | 4.08 | 4.35 | 0.435 - 6.76 | Acceptable | EPA 8151A |
| 7775 | MCPA | µg/L | < 10 | 0.00 | | Acceptable | EPA 8151A |
| 7780 | MCPP | µg/L | < 10 | 0.00 | | Acceptable | EPA 8151A |
| 6500 | 4-Nitrophenol | µg/L | < 1 | 8.53 | 0.853 - 14.3 | Not Acceptable | EPA 8151A |
| 6605 | Pentachlorophenol | µg/L | 7.47 | 8.70 | 0.870 - 13.9 | Acceptable | EPA 8151A |
| 8645 | Picloram | µg/L | 5.88 | 6.60 | 0.660 - 11.8 | Acceptable | EPA 8151A |
| 8655 | 2,4,5-T | µg/L | 8.46 | 9.90 | 1.17 - 14.3 | Acceptable | EPA 8151A |
| 8650 | 2,4,5-TP (Silvex) | µg/L | 6.94 | 7.55 | 1.15 - 10.9 | Acceptable | EPA 8151A |

